Self Diagnosis
Supported model

SERVICE MANUAL BG3R CHASSIS

MODEL	COMMANDER	DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
KV-AR29M90	RM-993	Hong Kong	SCC-U50F-A				

TRINITRON ® COLOR TV

SONY ®

SPECIFICATIONS

				Note
Power requirements	220-240 V AC, 50/60Hz			
Power consumption (W)	Indicated on the rear of the TV			
Television system	B/G, I, D/K, M			
Color system	PAL, PAL 60, SECAM, NTSC3.58, NTSC4.43			
Stereo/Bilingual System	NICAM Stereo/Bilingual B/G, I, A2 Stereo/Bilingual B/G			
Channel coverage				
B/G	VHF: E2 to E12 / UHF: E21 to E69 CATV: S01 to S03, S1 to S41			
I	UHF: B21 to B68 / CATV: S01 to S03, S1 to S41			
D/K	VHF: C1 to C12, R1 to R12 UHF: C13 to C57, R21 to R60 CATV: S01 to S03, S1 to S41, Z1 to Z39			
M	VHF: A2 to A13 / UHF: A14 to A79 CATV: A-8 to A-2, A to W+4, W+6 to W+84			
(Antenna)	75-ohm external terminal			
Audio output (Speaker)	8W + 8W			
Number of terminal				
Video	Input: 4*	Output: 1	* Three input lines available	Phone jacks; 1 Vp-p, 75 ohms
(Audio)	Input: 4*	Output: 1	* Three input lines available	Phone jacks; 500 mVrms
(S Video)	Input : 2			Y: 1 Vp-p, 75 ohms unbalanced, sync negative C: 0.286 Vp-p, 75 ohms
(Component Video)	Input : 1			Phono jacks: Y: 1 Vp-p, 75 ohms sync negative C_B: 0.7 Vp-p, 75 ohms C_R: 0.7 Vp-p, 75 ohms Audio: 500mVrms
(Headphone)	Output: 1			Stereo minijack
Picture tube	29 in			
Tube size (cm)	72			measured diagonally
Screen size (cm)	68			measured diagonally
Dimension (w/h/d,mm)	765 × 578 × 502			
Mass (kg)	49			

Design and specifications are subject to change without notice.

CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK ⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

TABLE OF CONTENTS

Section	Title	Page
SELF DIAGNOSTIC FUNCTION		4
1. DISASSEMBLY		
1-1.	Rear Cover Removal	7
1-2.	Speaker Removal	7
1-3.	Chassis Assy Removal	7
1-4.	F Board Removal	7
1-5.	Service Position	7
1-6.	Terminal Bracket and J Board Removal	7
1-7.	D3 Board Removal	8
1-8.	B1 Board Removal	8
1-9.	H1 and H2 Boards Removal	8
1-10.	A and B10 Boards Removal	8
1-11.	Picture Tube Removal	9
2. ADVANCE OPERATION		
2-1.	"RESET" Function	10
3. SET-UP ADJUSTMENTS		
3-1.	Beam Landing	11
3-2.	Convergence	12
3-3.	Focus Adjustment	14
3-4.	G2 (SCREEN) and White Balance Adjustment	15
4. CIRCUIT ADJUSTMENTS		
4-1.	Adjustment With Commander	16
4-2.	Adjustment Method	16
4-3.	Adjustment for Non Digital Texture Enchancer (DTE) Model	24
4-4.	Adjustment for Digital Texture Enchancer (DTE) Model	24
4-5.	Display Position Adjustment	25
4-6.	Deflection Adjustment	25
4-7.	Picture Distortion Adjustment	26
5. DIAGRAMS		
5-1.	Block Diagram	27
5-2.	Circuit Boards Location	29
5-3.	Schematic Diagram	30
	(1) C6 Board Schematic Diagram	31
	(2) A Board Schematic Diagram	33
	(3) B10 Board Schematic Diagram	37
	(4) B1 and D3 Boards Schematic Diagrams	39
	(5) F and VM1 Boards Schematic Diagrams	41
	(6) H1 Board Schematic Diagram	43
	(7) J Board Schematic Diagram	45
	(8) H2 Board Schematic Diagram	46
5-4.	Voltage List and Waveforms	48
5-5.	Printed Wiring Boards and Parts Location	53
5-6.	Semiconductors	61
6. EXPLODED VIEWS		
6-1.	Speaker Bracket	62
6-2.	Chassis	63
6-3.	Picture Tube	64
7. ELECTRICAL PARTS LIST		65
OPERATING MANUAL		

SELF DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash.
The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

1. DIAGNOSTIC TEST INDICATORS

When an errors occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen. No error has occured if the screen displays a "0".

Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/Diagnostic result	Probable Cause Location	Detected Symptoms
• Power does not turn on	Does not light	—	• Power cord is not plugged in. • Fuse is burned out F4601 (F)	• Power does not come on. • No power is supplied to the TV. • AC power supply is faulty.
• +B overcurrent (OCP) or overvoltage (OVP) • Vertical deflection stopped • Horizontal deflection overdrive	2 times	002:000 or 002:001~255 003:001~255 004:001~255 at the same time	• H.OUT Q511 is shorted. (A board) • Q701, Q702, Q703 is shorted (C6 board) • -13V is not supplied. (A board) • IC 503 faulty (A board)	• Power does not come on. • Load on power line is shorted. • Has entered standby state after horizontal raster. • Vertical deflection pulse is stopped. • Power line is shorted or power supply is stopped.
• White balance failure (no PICTURE)	5 times	005:000 or 005:001~225	• G2 is improperly adjusted. (Note 2) • CRT problem. • R(Q703), G(Q702) or B(Q701) out is faulty (C6 board) • IC301 is faulty. (A board) • No connection A board to C6 board.	• No raster is generated. • CRT cathode current detection reference pulse output is small.
• Micro reset	—	101:00 or 101:001~225	• Discharge CRT (C6 Board) • Static discharge • External noise	• Power is shut down shortly, after this return back to normal. • Detect Micro latch up.

Note 1: If a + B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.
The symptom that is diagnosed first by the microcontroller is displayed on the screen.
Note 2: Refer to screen (G2) Adjustment in section 3-4 of this manual.
* R(Q703), G(Q702) or B(Q701) out is faulty (C6 board).

2. DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



Diagnostic Item	Flash Count*
+B overcurrent/overvoltage Vertical deflection stopped	2 times
White balance failure	5 times

* One flash count is not used for self-diagnostic.



STANDBY/SLEEP lamp

3. STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

4. SELF-DIAGNOSTIC SCREEN DIPLAY

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurances of failure for confirmation on the screen:

[To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display ➡ channel 5 ➡ Sound volume - ➡ Power ON

⇧

Note that this differs from entering the service mode (mode volume +).

Self-Diagnosis screen display


SELF DIAGNOSTIC
002 : 000
003 : 000
004 : 000
005 : 001
101 : 000
Numeral "0" means that no fault has been detected.
Numeral "1" means a fault has been detected.

5. HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to “0”.

Unless the result display is cleared to “0”, the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.

[Clearing the result display]

To clear the result display to “0”, press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel [8] ➡ 0

[Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.

6. SELF-DIANOSTIC CIRCUIT



+B overcurrent (OCP)	Occurs when an overcurrent on the +B(135) line is detected by Q604. If Q604 go to ON and the voltage to pin 18 of IC301 should go down when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.
Vertical deflection stopped	Occurs when an absence of the vertical deflection pulse is detected by Q509 and IC001 shut down the power supply.
Vertical deflection overcurrent	Occurs when an overcurrent on V drive line is detected by Q507. Power supply will be shut down when detect this by IC001.
White balance failure	If the RGB levels* do not balance or become low level within 5 seconds, this error will be detected by IC301. TV will stay on, but there will be no picture. * (Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)

SECTION 1
DISASSEMBLY

1-1. REAR COVER REMOVAL



1-2. SPEAKER REMOVAL



1-3. CHASSIS ASSY REMOVAL



1-4. F BOARD REMOVAL



1-5. SERVICE POSITION



1-6. TERMINAL BRACKET AND J BOARD REMOVAL



1-7. D3 BOARD REMOVAL



1-8. B1 BOARD REMOVAL



1-9. H1 AND H2 BOARDS REMOVAL



1-10. A AND B10 BOARDS REMOVAL



1-11. PICTURE TUBE REMOVAL

Note:

- Please make sure the TV set is not in standing posotion before removing necessary CRT support located on bottom right and left.

1) Place the TV set with the CRT face down on a cushion jig.
2) Removal the rear cover.


① Anode Cap Removal
⑪ Earth Coating Assy
⑫ Nut, locking
⑦ Band, DGC Removal
⑨ Degaussing Coil
⑧ Holder, DGC(2) Removal
③ Loosen the Neck Assembly fixing screw and removal
⑩ Spring Tension(2) Removal
② C6 Board Removal
⑤ Loosen the Neck Assembly fixing screw and removal
⑥ Chassis Assy Removal
④ VM1 Board Removal

• REMOVAL OF ANODE-CAP

Note:

- After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.

- **REMOVING PROCEDURES**



① Turn up one side of the rubber cap in the direction indicated by the arrow ⓐ.



② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ⓑ.



③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow ⓒ.

- **HOW TO HANDLE AN ANODE-CAP**

① Do not damage the surface of anode-caps with sharp shaped objects.
② Do not press the rubber too hard so as not to damage the inside of anode-cap.
A metal fitting called the shatter-hook terminal is built into the rubber.
③ Do not turn the foot of rubber over too hard.
The shatter-hook terminal will stick out or damage the rubber.



SECTION 2
ADVANCE OPERATION

2-1. "RESET" FUNCTION

1. Purpose

If a customer faces some setting problem that cannot be solved, using the "RESET" function some items will be reset to its original setting (shipment condition)

2. How to Operate

The way to access to the "RESET" Function:-

a) By pressing "MENU" button or "SELECT" button (for non-menu models) on the Front Key Input and hold it down for 5 seconds.

3. Subsequent of Operation

Sequential to the resetting operation (either methods being used in No. 2), TV set would shut down once and automatically turn on again. The power-off duration is expected to be about 500msec. An OSD message, "RESET" tentatively will be displayed for 10 sec after IK status gets stable.
As a result, some items will be reset to an initial condition (shipment condition) wheareas some other remains at the last selection by user.

Items that remains at the last selection by user

Channel No., Favourite CH Setup, PIC rotation, OSD Language, Fine tuning, TV System, Skip

Reset Items

Video input	RF	Antenna sensitivity	HIGH*
Volume	30	Stereo mode	STEREO
Picture mode	DYNAMIC	Bilingual mode	MAIN*
PICSI		High-deviation mode	AUTO
Sound mode	DYNAMIC	Child lock	OFF*
Surround mode	OFF	Wide mode	OFF
Favourite CH mode	AUTO	Game mode	OFF
Multi Picture (PIP)	OFF	Sleep timer	OFF
PIP position	Bottom Right	Wake-up timer	OFF
OSD recall	OFF	Sound muting	OFF
Antenna sensitivity	OFF		

*= only when in RF mode

SECTION 3
SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switches should be set as follows unless otherwise noted:
PICTURE control ..... normal
BRIGHTNESS control ..... normal

Perform the adjustments in the following order :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

Note : Test Equipment Required.

1. Pattern Generator
2. Degausser
3. Oscilloscope

. . . . . .

Preparation :

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the set's power and degauss with the degausser.

3-1. BEAM LANDING

1. Input a white signal with the pattern generator.
   Contrast, Brightness } normal
2. Position neck assy as shown in Fig3-2.
3. Set the pattern generator raster signal to a green raster.
4. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side. (See Figures 3-1 through 3-4.)
5. Move the deflection yoke forward and adjust so that the entire screen is green. (See Figure 3-2.)
6. Switch the raster signal to blue, then to red and verify the condition.
7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws and DY spacers.
8. If the beam does not land correctly in all the corners, use a magnet to adjust it. (See Figure 3-5.)



Fig. 3-1



Fig. 3-2



Fig. 3-3



Fig. 3-4



Fig. 3-5

3-2. CONVERGENCE

Preparation :

- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Receive dot/hatch signal.
- Pic mode: Personal (Pic 90%, Brightness 50%, Colour 50 %, Hue 50%, Sharpness 50%).

(1) Horizontal and Vertical Static Convergence



1. (Moving horizontally), adjust the H.STAT control so that the red, green and blue dots are on top of each other at the center of the screen.
2. (Moving vertically), adjust the V.STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.
3. If the H.STAT variable resistor cannot bring the red, green and blue dots together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V.STAT magnet in the manner given below.
   (In this case, the H.STAT variable resistor and the V.STAT magnet influence each other, so be sure to perform adjustments while tracking.)





④ BMC (Hexapole) Magnet.

If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust in the manner described below.





⑤ Y separation axis correction magnet adjustment.

1. Receive the cross-hatch signal and adjust [PICTURE] to [MIN] and [BRIGHTNESS] to [STANDARD] .
2. Adjust the Y separation axis correction magnet on the neck assembly so that the horizontal lines at the top and bottom of the screen are straight.

Note

1. The Red and Blue magnets should be equally far from the horizontal center line.
2. Do not separate the Red and Blue magnets too far. (Less than 8 mm)

(2) Dynamic Convergence Adjustment

Preparation:

- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence



TLV	Rotate	TLV-2	VOL (29”, 34”) on DY
XCV	Rotate	XCV	Adj core on DY
YCH	Rotate	YCH	VOL on DY
TLH	Insert	TLH	Correction Plate to DY Pocket (Left or Right)

ON DY:



(3) Screen-corner Convergence



Fix a Permalloy assy corresponding to the misconverged areas.



3-3. FOCUS ADJUSTMENT

FOCUS adjustment should be completed before W/B adjustment.



FLYBACK TRANSFORMER (T503)

1. Receive digital monoscope pattern.
2. Set "Picture Mode" to "Standard".
3. Set S2801 to mechanical center position.
4. Adjust focus VR so that the center of the screen becomes just focus.
5. Adjust S2801 when corner focus is unbalance is right and left.
6. Change the receiving signal to white pattern blue back.
7. Confirm Magenta ring is not noticable. Incase magneta ring is obvious, reset S2801 to mechanical center position and then adjust FOCUS VR to balance between MAGENTA RING and FOCUS.

3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

1. G2 (SCREEN) ADJUSTMENT

1) Set the PICTURE to normal.
2) Put to VIDEO input mode without signals.
3) Connect R, G and B of the C6 board cathode to the oscilloscope.
4) Adjust BRIGHTNESS to obtain the cathode voltage to the value below.
5) Adjust G2 (screen) on the FBT until picture shows the point before cut off.



2. WHITE BALANCE ADJUSTMENT

1) Set to Service Mode (Refer Section 4-1: ADJUSTMENTS WITH COMMANDER).
2) Input white raster signal.
3) Set the PICTURE to minimum.
4) Select GCT (WHB 4) and BCT (WHB 5) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
5) Set the PICTURE to maximum.
6) Select GDR (WHB 1) and BDR (WHB 2) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
7) Write into the memory by pressing [MUTING] then [0].

3. SUB BRIGHT ADJUSTMENT

1) Set to service mode.
2) Input a staircase signal of black to white from the pattern generator.
3) BRIGHTNESS .... 50%.
   PICTURE ..... MINIMUM
4) Select SBR (WHB7) with [1] and [4], and adjust SBR (WHB7) level with [3] and [6] so that the second stripe from the right is dimly lit.



SECTION 4
CIRCUIT ADJUSTMENTS

4-1. ADJUSTMENTS WITH COMMANDER

Service adjustments to this model can be performed using the supplied Remote Commander RM-993.

a. ENTERING SERVICE MODE

With the unit on standby

→ DISPLAY → 5 → VOL (+) → POWER

This operation sequence puts the unit into service mode.

The screen display is :



b. METHOD OF CANCELLATION FROM SERVICE MODE

Set the standby condition (Press POWER button on the commander), then press POWER button again, hereupon it becomes TV mode.

c. METHOD OF WRITE INTO MEMORY

1) Set to Service Mode.
2) Press 1 (UP) and 4 (DOWN), to select the adjustment.
4) Press MUTING button to indicate WRITE on the screen.
5) Press 0 button to write into memory.

d. MEMORY WRITE CONFIRMATION METHOD

1) After adjustment, pull out the plug from AC outlet, and then plug into AC outlet again.
2) Turn the power switch ON and set to Service Mode.
3) Call the adjusted items again to confirm adjustments were made.

1, 4 ↓	Select the adjustment item.
3, 6 ↓	Raise/lower the data value.
MUTING ↓	Writes.
0	Executes the writing.

7, 0	All the data becomes the values in memory.
8, 0	All user control goes to the standard state.
5, 0	Service data initialization (Be sure not to use usually.)
MUTING + 0	Write 50Hz adjustment data to 60Hz, or vice versa.
2, 0	Copy and write all data.

4-2. ADJUSTMENT METHOD

Item Number 00 of device GEO

This explanation uses H-Position as an example.

1. Select "GEO 00 HPS" with the 1 and 4 buttons.
2. Raise/lower the data with the 3 and 6 buttons.
3. Select the optimum state. (The standard is 1F for PAL reception.)
4. Write with the MUTING button. (The display changes to WRITE.)
5. Execute the writing with the 0 button. (The WRITE display will be changed to red color while excuting, and back to SERVICE.)

Example on screen display :-


GEO 00 HPS 1F 50
602S 1.0C 59 7F 0 000A
GREEN
Adjusted with 3 and 6 buttons.
GEO 00 HPS 1F WRITE 50
602S 1.0C 59 7F 0 000A
GREEN
Write with MUTING
GEO 00 HPS 1F 50
602S 1.0C 59 7F 0 000A
RED
The WRITE display then the display returns to green SERVICE.
Write executed with 0

Use the same method for all Items. Use 1 and 4 to select the adjustment item, use 3 and 6 to adjust, write with MUTING, then execute the write with 0.

Note : 1. In WRITE, the data for all items are written into memory together.
2. For adjustment items that have different standard data between 50Hz or 60Hz, be sure to use the respective input signal after adjustment.

Adjustment Item Table

TVG	Functionality		No Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name (Slave Address)	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
GEO	00	HPS	0	1E	3F	H Position	NRO: Others{Normal(50/60)/Wide(50/60)}	14 (7-2)	CXA2159S(88H)	9E (7-2)	A6	(6B/6D)/(6F/71)	7-2	1E (for 60Hz)
	01	HSZ	1	25	3F	H Size	Normal(50/60)/Wide(50/60)	13 (7-2)		9D (7-2)	A0/A4	(A0/AD)/(43/4E)	7-2	typical
	02	PAP	2	1F	3F	Pin Amp	Normal(50/60)/Wide(50/60)	15 (7-2)		9F (7-2)	A0/A4	(A2/AF)/(45/50)	7-2	typical
	03	TLT	3	7	0F	Trapezium	Normal(50/60)/Wide(50/60)	17 (7-4)		A1 (7-4)	A0/A4	(A4/B1)/(47/52)	7-4	typical
	04	VPS	4	1F	3F	V Position	Normal(50/60)/Wide(50/60)	11 (7-2)		9B (7-2)	A0/A4	(9E/AB)/(41/4C)	7-2	typical
	05	VSZ	5	1F	3F	V size	Normal(50/60)/Wide(50/60)	10 (7-2)		9A (7-2)	A0/A4	(9D/AA)/(40/4B)	7-2	typical
	06	SCO	6	7	0F	S Correction	Normal(50/60)/Wide(50/60)	12 (7-4)		9C (7-4)	A0/A4	(9F/AC)/(42/4D)	7-4	typical
	07	VLN	7	7	0F	V Linearity	Normal(50/60)/Wide(50/60)	12 (3-0)		9C (3-0)	A0/A4	(9F/AC)/(42/4D)	3-0	typical
	08	BOW	8	7	0F	AFC Bow	Normal(50/60)/Wide(50/60)	18 (7-4)		A2 (7-4)	A0/A4	(A5/B2)/(48/53)	7-4	typical
	09	AGL	9	7	0F	AFC Angle	Normal(50/60)/Wide(50/60)	18 (3-0)		A2 (3-0)	A0/A4	(A5/B2)/(48/53)	3-0	typical
	0A	UPN	10	1F	3F	Upper Pin	Normal(50/60)/Wide(50/60)	16 (7-2)		A0 (7-2)	A0/A4	(A3/B0)/(46/51)	7-2	typical
	0B	LPN	11	1F	3F	Lower Pin	Normal(50/60)/Wide(50/60)	1A (7-2)		A4 (7-2)	A0/A4	(A7/B4)/(4A/55)	7-2	typical
	0C	HBL	12	1	1	H Blanking on/off	NRO:Others	1A (1)		74 (1)	A6	73	1	typical
	0D	LBL	13	0B	0F	Left H Blanking	NRO:Others{Normal(50/60)/Wide(50/60)}	19 (7-4)		A3 (7-4)	A6	(6C/6E)/(70/72)	7-4	0F (for 60Hz)
	0E	RBL	14	2	0F	Right H Blanking	NRO:Others{Normal(50/60)/Wide(50/60)}	19 (3-0)		A3 (3-0)	A6	(6C/6E)/(70/72).	3-0	typical
WHB	00	RDR	0	25	3F	R Drive	DYNAMIC/others	0B (7-2)	CXA2159S(88H)	37E (7-2)	A0	C0/BA	7-2	2A (for non-DYNAMIC)
	01	GDR	1	25	3F	G Drive	DYNAMIC/others	0C (7-2)		37F (7-2)	A0	C1/BB	7-2	typical
	02	BDR	2	25	3F	B Drive	DYNAMIC/others	0D (7-2)		380 (7-2)	A0	C2/BC	7-2	typical
	03	RCT	3	7	0F	R Cutoff	SECAM/others	09 (3-0)		382 (3-0)	A0	C3/BD	3-0	typical
	04	GCT	4	7	0F	G Cutoff	SECAM/others	0A (7-4)		383 (7-2)	A0	C4/BE	7-4	typical
	05	BCT	5	7	0F	B Cutoff	SECAM/others	0A (3-0)		383 (3-0)	A0	C4/BE	3-0	typical
	06	BMN	6	15	1F	Brightness Minimum Data		08 (7-2)		106 (6-2)	A0	22	6-2	-
	07	SBR	7	25	3F	Sub Brightness Control		08 (7-2)		107 (7-2)	A0	23	7-2	-
	08	APB	8	0	3	Sub Bright Control Switch for Intelligent Picture #3		08 (7-2)		107 (1-0)	A0	23	1-0	-
SAJ	00	PMX	0	38	3F	Picture Maximum Data	non-Wide/Wide	05 (7-2)	CXA2159S(88H)	105 (7-2)	A0	21/20	7-2	typical
	01	SHU	1	7	0F	Sub Hue Control	TV/Video	07 (7-2)		108 (5-2)	A0	24/38	5-2	typical
	02	SSH	2	5	0F	Sub Sharpness Control	TV/Video	09 (7-4)		109 (7-2)	A0	25/36	7-4	09 (for VIDEO)
	03	SCL	3	1F	3F	Sub Color Control	(NTSC/others)/WIDE(NTSC/others)	06 (7-2)		10A (7-2)	A0	(37/26)/(3C/3B)	7-2	typical

TVG	Functionality		No. Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name Slave Address	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
VP	00	EHT	0	5	0F	EHT Comp	50/60Hz	17 (3-0)	CXA2159S(88H)	A1 (3-0)	A0[/A4]	A4/B1[/(47/52)]	3-0	typical
	01	GMA	1	2	3	Gamma Correction (sepatated in STANDARD mode)	NON-STD(NTSC/others)/STD(NTSC/others)	0D (1-0)		367 (1-0)	A4	68/67/6A/69	1-0	typical
	02	APG	2	0	1	Gamma Control Switch for Intelligent Picture #3	NON-STD(NTSC/others)/STD(NTSC/others)	0D (1-0)		367 (2)	A4	68/67/6A/69	2	-
	03	YDL	3	6	0F	Y Delay	PAL/SECAM/NTSC/DVD	0E (3-0)		36C (3-0)	A4	3C/3E/3D/3F	3-0	(09/08/08 for SECAM/NTSC/DVD)
	04	SST	4	1	3	SECAM ID Start Position	SECAM&ATUTO/FORCED-PAL&NTSC	03 (5-4)		369 (5-4)	A4	6B/6D	5-4	(00 for forced PAL/NTSC)
	05	SSP	5	1	3	SECAM ID Stop Position	SECAM&ATUTO/FORCED-PAL&NTSC	03 (7-6)		369 (7-6)	A4	6B/6D	7-6	(03 for forced PAL/NTSC)
	06	RLM	6	0	3	RGB Limit		03 (1-0)		5D (1-0)	A0	83	1-0	typical
	07	SLV	7	2	O3	SECAM ID Level	SECAM&ATUTO/FORCED-PAL&NTSC	04 (1-0)		36A (1-0)	A4	6C/6E	1-0	(02 for forced PAL/NTSC)
	08	SBF	8	22	3F	SECAM BELL fO	SECAM&ATUTO/FORCED-PAL&NTSC	04 (7-2)		36A (7-2)	A4	6C/6E	7-2	(22 for forced PAL/NTSC)
	09	DYC	9	1	1	Dynamic Color on/off		0C (1)		66 (1)	A0	8C	1	-
	0A	ABL	10	1	1	ABL Mode Switching (except STANDARD mode)	except STANDARD	0B (1)		65 (1)	A0	8B	1	(00 for STANDARD)
	0B	VTH	11	1	1	ABL Detection Vth Switching		0B (0)		65 (0)	A0	8B	0	-
	0C	SF0	12	1	1	FO Switching for Sharpness	NTSC/others	07 (1)		35A (1)	A4	5C/59	1	typical
	0D	DCX	13	1	1	DC Trans. Ratio Switching		08 (1)		62 (1)	A0	88	1	-
	0E	SHT	14	1	1	Pre-/Overshoot ratio Switch	NTSC/others	08 (0)		35B (0)	A4	5D/5A	0	typical
	0F	HDW	15	0	1	H Drive Pulse Width Switch		00 (6)		5A (6)	A0	80	6	-
	10	AFC	16	1	O3	AFC Gain Control	TV/Video/Text	11 (1-0)		A7 (1-0)	A0	28/29/2A	1-0	(00/01 dor VIDEO/TEXT)
	11	HOS	17	7	0F	H Oscillation		0E (7-4)		68 (7-4)	A0	8E	7-4	-
	12	HSS	18	0	1	Slice Level of H Sync Sep.		0F (1)		69 (1)	A0	8F	1	-
	13	VSS	19	0	1	Slice Level of V Sync Sep.		0F (0)		69 (0)	A0	8F	0	-
	14	HMS	20	1	1	Macro Vision C/m off/on	50/60Hz	10 (0)		9A (0)	A0[/A4]	9D/AA[/(40/4B)]	0	typical
	15	YUV	21	0	1	Y SEL		00 (2)		5A (2)	A0	80	2	-
	16	CDV	22	1	3	CD mode for video and RF under no signal	video only	0F (5-4)		365 (5-4)	A0	2B	5-4	-
	17	RON	23	1	1	R ON	not memorized	01 (2)		5B (2)	A0	81	2	not memorised
	18	GON	24	1	1	G ON	not memorized	01 (1)		5B (1)	A0	81	1	not memorised
	19	BON	25	1	1	B ON	not memorized	01 (0)		5B (0)	A0	81	0	not memorised
	1A	PON	26	1	1	P ON	not memorized	00 (7)		5A (7)	A0	80	7	not memorised
	1B	AXN	27	1	1	AXIS SW	NTSC/ others(only for DYNAMIC)	07 (0)		10A (0)	A0	37/26[/(3C/3B)]	0	-
	1C	RSL	28	0	1	RGB SEL		0C (0)		66 (0)	A0	8C	0	-
	1D	VBW	29	0	3	VBLKW		16 (1-0)		70 (1-0)	A0	96	1-0	-
	1E	RFP	30	0	1	REFP		14 (0)		6E (0)	A0	94	0	-
	1F	VMC	31	0	3	VM Level		03 (3-2)		6D (3-2)	A0	83	3-2	-
	20	CBF	32	0	1	Chroma Bandpass Filter								
	21	CTO	33	0	1	Chroma Trap Off								

TVG	Functionality		No. Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name Slave Address	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
AP2	00	BBS	0	3	0F	Bass Boost Level Setting					A0	44	7-4	
	01	BCB	1	0	1	Boost cut select for Sub Bass Control					A0	45	2	
	02	SBS	2	0	3	Sub Bass Level Setting					A0	45	1-0	
	03	BCT	3	0	1	Boost cut select for Sub Treble Control					A0	46	2	
	04	STS	4	0	3	Sub Treble Level Setting					A0	46	1-0	
	05	AGL	5	0	3	AGC Level Setting					A0	48	3-2	
	06	BSW	6	0	1	Bass Boost ON/OFF Switch					A0	44	3	
	07	BAS	7	0	1F	Bass sound mode control	dyna/drama/soft				A6	{7E/81/84}{75/78/7B}	4-0	
	08	TRE	8	0	1F	Treble sound mode control	dyna/drama/soft				A6	{7F/82/85}{76/79/7C}	4-0	
	09	BBE	9	0	FF	BBE Sound mode Control	dyna/ drama/soft				A6	{80/83/86}{77/7A/7D}	7-0	
MSP	00	WST	0	15	FF	W/G Stereo Threshold			MSP3415D(84H)	165	A0	60	7-0	-
	01	WBT	1	EC	FF	W/G Bilingual Threshold				166	A0	61	7-0	-
	02	WLL	2	5	FF	W/G Monaural Threshold				167	A0	62	7-0	-
	03	WAC	3	1	0F	W/G Agreement Count				168(3-0)	A0	63	3-0	-
	04	WDL	4	30	FF	W/G Search Delay				169	A0	64	7-0	-
	05	NDL	5	20	FF	NICAM Search Delay				16A	A0	65	7-0	-
	06	SDL	6	10	FF	Stereo status Read Delay				16B	A0	66	7-0	-
	07	AGC	7	1	1	AGC Switch Auto/Constant		00BB(7)		116(7)	A0	68	7	-
	08	REL	8	28	3F	AGC Gain at Constant Mode		00BB(6-1)		116(6-1)	A0	68	6-1	-
	09	CRM	9	0	1	Carrier muting on/off		00BB(9)		115(9)	A0	67	1	-
	0A	ACO	10	1	1	Audio Clock out on/off		0083(5)		11A(5)	A0	69	5	-
	0B	FP	11	1B	7F	FM Prescale for non-M system		000E(14-8)		32F	A0	6A	6-0	-
	0C	FPM	12	32	7F	FM Prescale for M system		000E(14-8)		330	A0	6B	6-0	-
	0D	FH	13	36	7F	FM Prescale for HDEV		000E(14-8)		331	A0	6C	6-0	-
	0E	FHM	14	65	7F	FM Prescale for HDEV and M		000E(14-8)		332	A0	6D	6-0	-
	0F	WGP	15	1C	7F	W/G Prescale		000E(14-8)		333	A0	6E	6-0	-
	10	NIP	16	7F	7F	NICAM Prescale		0010(14-8)		147	A0	6F	6-0	-
	11	ERR	17	50	FF	Auto FM switch Threshold		0021(10-3)		174	A0	70	7-0	-
	12	VOL	18	6D	FF	Loud Speaker gain 700h to 7ff0h		0000(15-4)		360	A4	62	7-0	-

TVG	Functionality		No. Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name Slave Address	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
PIP	00	PRO	0	0	1	Progreeive Scan Mode Enable			SDA9288X(D6H)	192 (6-3)	A4	1C	6-3	
	01	RED	1	0	1	Read Double Mode								
	02	FEI	2	0	3	Field Select								
	03	HPS	3	35	FF	Horizontal Picture Position								
	04	VPS	4	1B	FF	Vertical Picture Position								
	05	HFP	5	0	0F	Horizontal Fine Positioning								
	06	VFP	6	0	0F	Vertical Fine Positioning								
	07	DIS	7	0	3	Display standard								
	08	HOS	8	0	3	Horizontal Size								
	09	VES	9	0	3	Vertical Size								
	0A	FPS	10	0	3	Force Parent Standard								
	0B	HZM	11	0	7	Horizontal Zoom								
	0C	VSP	12	0	1	Vertical Sync Pule Noise Reduction								
	0D	VDL	13	0	1F	Vertical Sync Pulse Delay								
	0E	FRH	14	5	7	Frame Width Horizontal								
	0F	FWV	15	2	3	Frame Width Vertical								
	10	VRD	16	0	1	Reduction								
	11	VBK	17	0	1	Vertical Blanking								
	12	DLY	18	0	F	Select Delay								
	13	PCR	19	0	1	Position Correction								
	14	AGM	20	3	3	AGC Mode								
	15	AGC	21	6	F	Automatic Gain Control Value								
	16	CVB	22	0	3	CVBS Select								
	17	CPD	23	1	3	CLAMPING Duration								
	18	CPT	24	1	3	CLAMPING Pulse start								
	19	LUM	25	0	3	Luminance offset								
	1A	PLL	26	0	3	Insert PLL Time Constant								
	1B	YCD	27	2	F	Y/C Delay								
	1C	NSR	28	0	3	Noise Reduction for insert Pll								
	1D	LSP	29	0	1	Standard Identification Speed								
	1E	KIL	30	0	3	Color Killer Treshold								
	1F	BGP	31	0	1	Burst Gate Position								
	20	SEC	32	0	1	SECAM Identification level								
	21	DEM	33	1	3	Deemphasw selection								
	22	CMA	34	0	3	Chroma Bandwith								
	23	IFC	35	2	3	IF Compensation Filter								
	24	HUE	36	0	1F	Hue								
	25	SCA	37	7	1F	Color Subcarrier Adjustment								
	26	CON	38	0	F	Contrast Adjustment								
	27	BLR	39	0	F	Blanking Level Red Channel								
	28	BRT	40	0	F	Brightness Adjustment								
	29	BLG	41	0	F	Blanking Level Green Channel								
	2A	BIR	42	0	1	Blanking Inversion Red Channel								
	2B	BIB	43	0	1	Blanking Inversion Blue Channel								
	2C	BLB	44	0	F	Blanking level blue channel								
	2D	INT	45	0	1	Refresh Interval								
	2E	PKR	46	4F	FF	Peak Level Red Channel								
	2F	PKG	47	4F	FF	Peak Level Green Channel								
	30	PKB	48	4F	FF	Peak Level Blue Channel								
	31	FRY	49	A	F	Frame Color Y								
	32	OUT	50	1	1	Output Format								
	33	FRU	51	0	F	Frame Color U								
	34	FRV	52	0	F	Frame Color V								
	35	SAT	53	7	F	Color Separation Adjustment								
	36	YPK	54	7	7	Y Peak Adjustment								
	37	YCO	55	0	F	Y Coring Enable								
	38	PAL	56	3	3	PAL ID level								
	39	POV	57	0	7	Position Offset Vertical								
	3A	POH	58	0	1F	Position Offset Horizontal								
	3B	VSH	59	0	1F	Vertical Shrink				1A1	A4	29	7-0	-
	3C	HSH	60	0	1F	H Shrink				1A2	A4	2A	7-0	-
	3D	CPL	61	1	3	CLAMPING Pulse Length				195 (2-0)	A4	1F	2-0	-

TVG	Functionality		No. Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name Slave Address	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
YCT	00	SHU	0	0F	1F	Sub Hue Adjustment	TV/Video		CXA2163AQ(8AH)					
	01	PNG	1	1	1	PAL/NTSC Gate Width								
	02	PNI	2	0	1	PAL/NTSC Sensitivity SW								
	03	SCL	3	7	0F	Sub Color Control	50/60*TV/Video							
	04	SCT	4	8	0F	Sub Contrast Control	50/60*TV/Video							
	05	SF0	5	2	3	Sharpness Center Frequency Changing								
	06	SEQ	6	3	3	Sharpness Equalizer Characteristic								
	07	SHG	7	5	0F	Sharpness Gain Control	50/60*TV/Video/DVD							
	08	YOL	8	1F	3F	Y-Output Level Control								
	09	BSP	9	0	3	Black Stretch Start Point Changing								
	0A	COL	10	1F	3F	Cb/Cr Output Level Control								
	0B	DCR	11	0	3	DC Restoration Ratio Adjustment								
	0C	BF0	12	1	3	BPF/TQF F0 Adjustment								
	0D	BFQ	13	2	3	BPF/TQF Q Adjustment								
	0E	FSW	14	1	1	BPF/TQF Switch								
	0F	SDT	15	1	1	SECAM Double Trap Switch								
	10	LPF	16	1	1	Y/Cb/Cr LPF Switch								
	11	YDL	17	6	0F	Y-DL Time Adjustment	TV/Video/S-input/DVD							
	12	CMT	18	0	1	Cb/Cr Output Mute Switch								
	13	B01	19	7	0F	Cb Offset Adjustment (main route)								
	14	RO1	20	7	0F	Cr Offset Adjustment								
	15	CDF	21	0	7	V Count Down Frequency Switch	forced 50Hz for no signal							
	16	CDM	22	0	3	V Count Down Judge Switch								
	17	AFC	23	0	3	AFC Sensitivity Switch	(TV/)Video/DVD							
	18	MVM	24	1	1	Macrovision Mask + AFC Mask								
	19	SRY	25	7	0F	SECAM R-Y Black Adjustment								
	1A	SBY	26	1	0F	SECAM B-Y Black Adjustment								
	1B	BEL	27	2	3	SECAM BELL/HPF Switching								
	1C	BLF	28	0	1	BELL f0 Adjustment								
	1D	SVI	29	0	1	SECAM V-ID Switch								
	1E	SGP	30	0	3	SECAM Gate Position Adjustment								
	1F	SID	31	1	1	SECAM Sensitivity Switch	except SECAM							
	20	SIH	32	0	1	SECAM Inhibition Switch								
	21	STP	33	0	1	Y Black Level Setup for PAL plus								
	22	ASW	34	1	1	Auto Video select mode SW								
	23	WSH	35	0	3	Sharpness Gain Step for noise reduction								
	24	WCO	36	0	3	Cb/Cr Output Level Step for noise reduction								
	25	CB2	37	7	0F	Cb2 offset adjustment (YCbCr2 input)								
	26	CR2	38	7	0F	Cr2 offset adjustment (YCbCr2 input)								
	27	HPH	39	0	1	HS Output phase switch								
	28	VPH	40	0	1	Switch for VP output phase								
	29	NCM	41	0	1	NTSC COMB								

TVG	Functionality		No. Dec	Initial	Range	Function	Table & Note	Register No. (Bit Range)	Device Name Slave Address	RAM Address (Bit Range)	NVM Address			Remarks:
Category	No.	Name									Slave	Sub	Bit	Initial data for tables
TE	00	NR0	0	01	07	NR	NTSC/Others		CXA2163AQ(8AH)					
	01	TC0	1	04	0F	TE Coring	NTSC/Others							
	02	TG0	2	05	07	TE Gain	NTSC/Others							
	03	STH	3	00	01	Forced TE bypass 1:TE bypass								
	04	COF	4	00	01	Color Component OFF 1:OFF(512)								
	05	YOF	5	00	01	Luminance Component OFF 1:OFF								
	06	VJR	6	00	03	V jitter control 0:ON 1:SP1 2:SP2 3:SP2								
	07	TOF	7	00	01	TE OFF 1: TE OFF								
	08	DOF	8	00	01	Dot NR OFF 1:Dot NR OFF								
	09	FOF	9	01	01	TE LPF OFF 1:LPF OFF								
	0A	CTH	10	00	01	Color TE OFF 1:OFF								
	0B	PSL	11	02	03	TE Parameter Selection								
	0C	CLP	12	08	0F	Input Clamp Level								
	0D	CL2	13	08	0F	Output Clamp Level								
	0E	LA1	14	00	0F	Level depend Gain (+, White)								
	0F	LA2	15	01	0F	Level depend Gain (+, Black)								
	10	LA3	16	0F	0F	Level depend Gain (-, White)								
	11	LA4	17	01	0F	Level depend Gain (-, Black)								
	12	CRW	18	04	07	TE Y/C Compensation ratio								
	13	YCD	19	03	07	TE Y/C output delay adjustment								
NR	00	DMO	0	00	01	NR Demo Mode ON/OFF (1=Demo Mode)								
	02	THH	2	0F	1F	Offset of Noise Threshold level for horizontal direction								
	03	BLL	3	07	0F	Offset of Level detection for Black Level								
	04	CST	4	07	0F	Offset of Level detection for Color Level								
	05	THC	5	07	0F	Offset of Edge Detection Threshold								
	06	NRF	6	00	01	NR0 always Rank = 0								
	07	DIG	7	00	01	A/D in or Digital In (1=Digital In)								
TXT	00	TXH	0	0	3	Teletext Horizontal Position		10 (1-0)	SAA5261(58H)	96 (1-0)	A4	58	1-0	-
	01	TXV	1	0	3	Teletext Vertical Position		10 (5-4)		96 (5-4)	A4	58	5-4	-
PJE	00	PJE	0	0	1	(PJ-Engine Service Control)			CXPxxxx(6AH)					
OPM	00	OSH	0	0D	3F	OSD H Position	Option - Misc	1F1	CXP750097(60H)	17B (7-2)	A0	27	7-2	-
	01	COM	1	2	3	Comb Selection (0: None, 1: NTSC, 2: Digital, 3: 3D)				34D (7-6)	A0	50	7-6	-
	02	APC	2	1	1	APC Switch				34C (5)	A0	4F	5	-
	03	TSY	3	0	3	TV Sys at Auto TV Sys				34C (4-3)	A0	4F	4-3	-
	04	MUT	4	0	1	No signal Mute				34C (0)	A0	4F	0	-
	05	AFM	5	1	1	Auto FM switch				34C (1)	A0	4F	1	-
	06	RFB	6	0	3	C-BPF Control				34D (5-4)	A0	50	5-4	-
	07	TVO	7	2	7	Tilt to V-Angle offset				34D (2-0)	A0	50	2-0	-
	08	DBL	8	0	1	Disable Blueback Function				34C (2)	A0	4F	2	-
	09	SSO	9	1	3	Speed Search Option (0: Off, 1: 4x, 2: 6x, 3: 8x)				34C (7-6)	A0	4F	7-6	-
	0A	SCH	10	1	7F	CH Selection for Shipping Condition	NTSC models only			387 (0-6)	A0	3D	6-0	-
	0B	SCA	11	1	1	Cable/Air selection for shipping condition	NTSC models only			387 (7)	A0	3D	7	-
	0C	POR	12	0	1	Power on Reset Detection From YCT				34D(3)	A0	50	3	-
	0D	NRC	13	3	FF	N-Det Counter for DTE								
OPB	00	OP1	0	FF	FF	Optional Bits 1 (see below)	Option - Bits		CXP750097(60H)	4E	A0	2D	7-0	-
	01	OP2	1	67	FF	Optional Bits 2 (see below)				4F	A0	2E	7-0	-
	02	OP3	2	31	FF	Optional Bits 3 (see below)				50	A0	2F	7-0	-
	03	OP4	3	97	FF	Optional Bits 4 (see below)				51	A0	30	7-0	-

NOTE

- shaded items are fixed data.
- Standard data listed on the Adjustment Item Table are reference values, therefore it may be different for each model and for each mode.
- Note for Different Data Those are the standard data values written on the microprocessor. Therefore, the data values of the modes and stored respectively in the memory. In case of a device replacement, adjustment by rewriting the data value is necessary for some items.

ITEM INFORMATION

No. OPB0 OP1

Item	XTAL 4.43	XTAL 3.58	SECAM	2nd. Lang	B/G	I	D/K	M
KV-AR29M90	1	1	1	1	1	1	1	1

(APPLICABLE FOR XF-L(21" & 14") MODELS ONLY.

No. OPB1 OP2

Item	TOP	NICAM	HDEV	Thai Bil	PIP 4	DVD Input	AV Input	
KV-AR29M90	1	1	1	0	1	1	1	1

AV Input 00 = no AV Input 01 = 1 AV Input
10 = 2 AV Input 11 = 3 AV Input

DVD Input Effective only when "AV Input" is set to 3 AV Input

PIP 4 PIP 4 0 = disabled, 1 = enabled

No. OPB2 OP3

Item	Initial menu	AP2	Auto PIC	A-TVsys	US ST	DTE	Forced 50/60	Colour SW*2
KV-AR29M90	1	1	1	1	0	0	0	1

Initial Menu Initial Menu Setup 0 = disabled, 1 = enabled

AP2 Auto Processor Selection 0 = AP, 1 = AP2.

Auto PIC*3 Auto Picture Improvement 0 = off PNC1/PNC2
1 = activate PNC1/PNC2

A-TVsys Auto TV System in Auto Program 0 = disabled, 1 = enabled

US ST* USA Stereo 0 = disabled, 1 = enabled

DTE DTE Model Selection 0 = Non DTE, 1 = DTE

Forced 50/60 Forced to 50/60 Hz during no signal condition 0=60Hz, 1=50Hz

Color SW*2 Color Data Selection in Dynamic Mode 0 = 65 (No PIP), 1 = 57 (PIP)

Note: *1 - For XA21/XH29 Models Only
*2 - For XA34/29/25 Models Only
*3 - For PNC3, the enables are from service item APG and APB.

No. OPB3 *OP4

Item	PNC2	Korean ST	Vid NTSC3.58	Wide	Video3	Chinese(multi mdl)	Arabic/C.Chinese	Thai/Korean
KV-AR29M90	0	0	0	0	0	1	1	1

APPLICABLE TO XS ONLY - Sub Language Selection (Bit 0 - Bit 2)

Korean Stereo* Korean Stereo 0 = disabled, 1 = enabled

PNC2*2 Enable switch of PNC2 0 = disable, 1 = enable

Video NTSC3.58* Video Color System 0 = Multi System, 1 = Single System (NTSC3.58)

Wide Enable wide mode 0 = disable, 1 = enable

Note : *APPLICABLE FOR NTSC MODELS ONLY

4-3. ADJUSTMENT FOR NON DIGITAL TEXTURE ENHANCER (DTE) MODEL (not used for this model)

SUB COLOR ADJUSTMENT

1. Select Video.
2. Input PAL Color Bar
3. Set to following condition PICTURE 100%, BRIGHTNESS 50%, Color 50%.
4. Connect an oscilloscope to pin ① (BOUT) of CN305, A Board.
5. Set the service mode and select SAJ 3 'SCL' with [1] and [4] of the commander then adjust the VB2=VB3=VB4 [3] and [6].
6. Press [MUTING] → [0] of the commander to write the data.
7. Input NTSC Color Bar to set and repeat items (3 to 7).
8. Select "WIDE" mode, write the "SAME DATA- 3 STEPS" for both PAL and NTSC Color Bar input.



VB2 = VB3 = VB4 (Difference is within 70mV)

SUB COLOR ADJUSTMENT

1. Select Video.
2. Input PAL Color Bar
3. Set to following condition PICTURE 100%, BRIGHTNESS 50%, Color 50%.
4. Connect an oscilloscope to pin ① (BOUT) of CN305, A Board.
5. Set the service mode and select SAJ 3 'SCL' with [1] and [4] of the commander then adjust the VB2=VB3=VB4 [3] and [6].
6. Press [MUTING] → [0] of the commander to write the data.
7. Add 6 steps and save the data.
8. Input NTSC Color Bar to TV set and repeat items 3 to 7.
9. Select "WIDE" mode, write the "SAME DATA- 3 STEPS" for both PAL and NTSC Color Bar input.

SUB HUE ADJUSTMENT

1. Select Video 1.
2. Input a NTSC 3.58 color-bar, video into Video 1.
3. Set the following condition:
   PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
4. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
5. Select SAJ 1 "SHU" with [1] and [4] of the commander by setting to Service Mode and adjust to VB1=VB2=VB3=VB4 with [3] and [6].



The highest level of VB1,VB2,VB3,VB4 must be aligned at the same line. Ideal difference level between VB2 and VB3 should be within ± 110mV.

6. Press [MUTING] → [0] of the commander to write the data.
7. Adjust SAJ 1 "SHU" as step 3 to 6 when receiving TV mode.

4-4. ADJUSTMENT FOR DIGITAL TEXTURE ENHANCER (DTE) MODEL

Y LEVEL ADJUSTMENT

1. Select Video.
2. Input PAL Color Bar to TV set (white reference 100%).
3. Set the following condition:
   DTE : ON
   Picture Mode : Dynamic
4. Connect an oscilloscope to pin ① (CV/Y in) of CN106, A Board.
5. Set to Service Mode and YCT 08 'YOL' with [1] and [4] of the commander then adjust to VY within spec with [3] and [6].
6. Then press [MUTING] → [0] to write the data.
7. Select RF.
8. Repeat item [2] to [4].
9. Set to Service Mode and YCT 04 'SCT' with 1 and 4 of the commander then adjust to VY within spec with [3] to [6].
10. Copy SCT data to NTSC (RF).

SCT Setting (Video Mode) : 07h (NTSC & PAL)



SPEC: VY : 1.2 Vpp ± 0.05m Vpp

SUB COLOR (YCT) ADJUSTMENT

1. Select Video.
2. Input NTSC Color Bar.
3. Set the following condition:
   DTE : ON
   Picture Mode : Dynamic
   NTSC 75% Color Bar
4. Connect an oscilloscope to pin ② (B-Y in) of CN303, A Board.
5. Set to Service Mode and YCT 0A 'COL' with [1] and [4] of the commander then adjust to VB within spec with [3] and [6].
6. Then press [MUTING] → [0] to write the data.
7. Select RF.
8. Repeat item no [2] to [4].
9. Set to Service Mode and YCT 03 'COL' with [1] and [4] of the commander then adjust the waveform within spec with [3] and [6].
10. Then press [MUTING] → [0] to write the data.
11. Input PAL Color Bar (75%) and repeat item no 8 to 10.



SPEC :
VIDEO : VB = 0.931 Vpp ± 50 mVpp
RF : VB = 0.931 Vpp ± 50 mVpp

SUB COLOR (YCJ) ADJUSTMENT

1. Select Video.
2. Input PAL Color Bar to TV set.
3. Set the following condition:
   Pic: 100%, Col: 50%, Brightness: 50%, DTE: OFF
4. Connect an oscilloscope to pin ② (B output) of CN305, A Board.
5. Set to Service Mode and SAJ 03 'SCL' with [1] and [4] of the commander then adjust to VB2 = VB3 = VB4 = with [3] and [6].
6. Then press [MUTING] → [0] to write the data.
7. Add offset steps and save the data.
   Offset: 25... 0
   29... 0
   34... 0
8. Input NTSC color bar to TV set and repeat item no 3 to 7.
10. Select "WIDE" mode, write the "SAME DATA - 3 STEPS" for both PAL and NTSC input.



VB2 = VB3 = VB4 (Difference is within 70mV)

SUB HUE ADJUSTMENT

1. Select Video.
2. Input NTSC 3.58 Color Bar to TV Set.
3. Set the following condition:
   Pic: 100%, Col: 50%, Brightness: 50%, DTE: OFF
4. Connect an oscilloscope to pin ① (B output) of CN305, A Board.
5. Set to Service Mode and YCT 00 'SHU' with [1] and [4] of the commander then adjust to VB1 = VB2 = VB3 = VB4 = with [3] and [6].
6. Then press [MUTING] → [0] to write the data.
7. Select RF.
8. Input NTSC 3.58 and repeat item no 3 and 6.



The highest level of VB1, VB2, VB3, VB4 must be aligned at the same time.
Ideal difference level between VB2 and VB3 should be within ± 110 mVpp.

PMX ADJUSTMENT

1. Select Video (Wide mode: OFF).
2. Input PAL Color Bar to TV set.
3. Set the following condition:
   Pic: 100%, Col: 50%, Brightness: 50%, DTE: OFF
4. Connect an oscilloscope to pin ③ (R output) of CN305, A Board.
5. Set to Service Mode and SAJ 00 'PMX' with [1] and [4] of the commander then adjust to VR within spec with [3] and [6].
6. Then press [MUTING] → [0] to write the data.
7. Select "Wide" mode, write the "SAME DATA- 5 STEPS".



VR = 2.35 Vpp
(Difference is within 50 mVpp)

VP 06 RLM : 03H
17 R ON : 01H
18 G ON : 00H
19 B ON : 00H
After adjustment, these adjustment parameters must be recovered to the original condition.

4-5. DISPLAY POSITION ADJUSTMENT (not used for this model)

PIP POSITION

1. Input a PAL color-bar.
2. Press PIP button of the remote commander to set the PIP picture.
3. Set to Service Mode.
4. Use [1] and [4] of the remote commander to select PIP 03 "HPS" and use [3] and [6] to set data "15".
5. Select PIP 04 "VPS" to set data "2E".
6. Press [MUTING] → [0] of the remote commander to write the data.
7. Use the screen display menu changing the PIP position to check the PIP position.

4-6. DEFLECTION ADJUSTMENT

NORMAL MODE (50Hz)

1. Set Video Mode.
2. Using the [1] and [4] button, select category GEO (Service Mode).
3. Raise/lower the data using the [3] and [6] buttons. Select and adjust the following items to obtain optimum image.

Service Item

GEO :	00	HPS	H POSITION
	01	HSZ	H SIZE
	02	PAP	PIN AMP
	03	TLT	TILT
	04	VPS	V POSITION
	05	VSZ	V SIZE
	06	SCO	S CORRECTION
	07	VLN	V LINEARITY
	08	BOW	AFC BOW
	09	AGL	AFC ANGLE
	0A	UPN	UPPER CORNER PIN
	0B	LPN	LOWER CORNER PIN

4-7. PICTURE DISTORTION ADJUSTMENT (1)

Item Number 00 – 0B

GEO 0 HPS (H POSITION)



GEO 1 HSZ (H SIZE)



GEO 2 PAP (PIN AMP)



GEO 3 TLT (TRAPEZIUM)



GEO 4 VPS (V POSITION)



GEO 5 VSZ (V SIZE)



GEO 6 SCO (VERTICAL S-Correction)



GEO 7 VLN (V LINEARITY)



GEO 8 BOW (AFC. BOW)



GEO 9 AGL (AFC. ANGLE)



GEO 0A UPN (UPPER CORNER PIN)
GEO 0B LPN (LOWER CORNER PIN)



PICTURE DISTORTION ADJUSTMENT (2)

H-TRAPEZOID (DAC 4 HTR)



SECTION 5
DIAGRAMS

5-1. BLOCK DIAGRAM



5-2. CIRCUIT BOARDS LOCATION



5-3. SCHEMATIC DIAGRAM

Note:

- All capacitors are in µF unless otherwise noted.
- All electrolytic capacitors are rated at 50V unless otherwise noted.
- All resistors are in ohms.
  kΩ = 1000Ω, MΩ = 1000kΩ
- Indication of resistance which does not have rating electrical power is as follows.

  Pitch: 5 mm
  Rating electrical power 1/4W (CHIP: 1/10W)

- : nonflammable resistor.
- △ : internal component.
- : panel designation or adjustment for rrepair.
- All variable and adjustable resistors have characteristic curve B unless otherwise noted.
- **Redings are taken with a color-bar signal input.**
  no mark : Common
  ( ) : PAL
  [ ] : NTSC 3.58
- **Readings are taken with a 10 Ω digital multimeter.**
- **Voltage are dc with respect to ground unless otherwise noted.**
- **Voltage variations may be noted due to normal production tolerances.**
- **All voltage are in V.**
- **✻ : Cannot be measured.**
- **Circled numbers are waveform references.**
- **: B +bus.**
- **: B –bus.**
- **: signal path.**

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: ✻	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

Note: The component identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

(1) C6 Board Schematic Diagram



KV-AR29M90
RM-993

(2) A Board Schematic Diagrams


A 1/2
(SYSTEM CONTROLLER, Y/C JUNGLE, DEFLECTION, TUVIF, FRONT AMP, POWER SUPPLY)
CN302 8P :BTOB
CN303 10P :BTOB
TO B10 BOARD CN1406
CN101 10P :BTOB
TO B10 BOARD CN1405
CN102 8P :BTOB
TO B10 BOARD CN1407
CN106 3P WHT :S-MICRO
CN204
CN203
TU101 BTF-WG441
CN104 1P :TAB
TO F BOARD CN4603
CN205 TAB
CN105
CN103 TO TUVIF
9V
ATT.SW
GND
30V
IC001 CXP750097-602S
IC301 CXA2159S
IC100 S-80743AL
IC201
IC203
IC302 M24C08-BN6
IC303 MAX823REE
IC901
Q001 2SA1162-YG
Q002 2SC2712-YG-TE85L
Q005
Q101 2SC2712-YG-TE85L
Q201
Q202
Q205
Q206
Q207
Q303
Q305
Q307 2SC2712-YG-TE85L
Q308 2SA1162-YG
Q310 2SA1162
Q311 2SC2712-YG-TE85L
Q313 2SC2712-YG-TE85L
Q314
Q315 UN2213
Q316 2SA1162-YG
Q401
D100 MMDL914T1
D101 MMDL914T1
D300 :CHIP
D301 MMDL914T1
D303
D304
D305 JR504
D306 JR505
D307 MMDL914T1
D308 MMDL914T1
D309 RD5.1SB-T2
D310 RD7.5SE1
D311 MMDL914T1
D312 MMDL914T1
D313 MMDL914T1
D314
D315 MMDL914T1
D316 RD7.5SE1
D401
D402
D403
D404
D405
D406
D407
D408
D409
CN901 NS ROT
CN902
CN904 6P WHT :S-MICRO
TO H1 BOARD CN3905
CN905
CN906
CN907
CN908
CN909
CN910
CN911
CN912
CN913
CN914
CN915
CN916
CN917
CN918
CN919
CN920
CN921
CN922
CN923
CN924
CN925
CN926
CN927
CN928
CN929
CN930
CN931
CN932
CN933
CN934
CN935
CN936
CN937
CN938
CN939
CN940
CN941
CN942
CN943
CN944

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

A B C D E F G H I J

A 2/2

(SYSTEM CONTROLLER, Y/C JUNGLE, DEFLECTION, TUVIF, FRONT AMP, POWER SUPPLY)

NS ROT
NS MUTE
EW
VD+
VD-
ABL
HD
HP

PFC 1
PFC 2
CN600 #

TO H2 BOARD CN3602
TO DGC
TO B10 BOARD CN6205
TO DH BOARD CN3802

CN507 6P YEL :S-MICRO
TO C6 BOARD CN1801
1 VD+
2 GND
3 VD-
4 15V
5 NS ROT
6 NS MUTE

CN002 #
CN511 #
DY1 6P
1 H+
2 H+
3 H-
4 H-
5 V-
6 V+

CN506 #
TO C6 BOARD CN700/CN712
CN505 5P :S-MICRO
1 200V
2 NC
3 GND
4 H1
5 GND
CN508 # TO COATING EARTH
CN509 #
TO HV BLOCK CN504 1P :TAB
TO D3 BOARD CN2803
1 GND
CN609 #
7 VD+
6 15V
5 FBP
4 GND
3 GND
2 NC
1 135V
CN503 7P
TO D3 BOARD CN2800

B-SSS11222-HK.-A..(PG2/2)

KV-AR29M90
RM-993

(3) B10 Board Schematic Diagram



KV-AR29M90
RM-993

(4) B1 and D3 Boards Schematic Diagrams





(5) VM1 and F Boards Schematic Diagrams



(6) H1 Board Schematic Diagram



(7) J Board Schematic Diagram



(8) H2 Board Schematic Diagram



5-4. VOLTAGE LIST AND WAVEFORM

A BOARD

Ref	Pin No.	Voltage[v]
IC001	1	0
	2	0
	3	0.3
	4	0.3
	5	4.9
	6	4.9
	7	3.8
	8	4.7
	9	0
	①  5.120Vp-p	
	10	4.7
	②  4.880Vp-p	
	11	(0)[4.9]
	12	0
	13	(0)[2.1]
	14	2.1
	③ PAL 3.760Vp-p	
	③ NTSC 3.520Vp-p	
	15	4.9
	16	4.9
	17	0
	18	4.4
	19	(1.9)[2.5]
	20	1.6
	21	4.9
	22	0
	23	4.9
	24	0.3
	25	4.8
	26	4.9
	27	4.8
	28	4.9
	29	4.8
	30	0
	31	0
	32	0
	33	4.9
	34	0
	35	0
	36	(2.3)[2.5]
	37	2.5
	38	4.8
	39	4.9
	40	0
	41	0
	42	0.3
	43	0
	44	4.9
	45	4.9
	46	(4.3)[4.6]
	47	4.9
	48	4.4
	49	0
	50	(1.6)[2.2]
	51	0
	52	(4.7)[0]
IC002	1	0
	2	4.9
	3	4.9
	4	7.2
	5	4.9
	6	0
	7	0
IC003	1	0
	2	0
	3	0
	4	0
	5	4.9
	6	4.9
	7	0
	8	4.9
IC100	1	4.8
	2	4.8
	3	0
IC301	1	3.3
	2	5.0
	3	(0)[1.2]
	4	5.0
	5	4.8
	6	4.3
	7	0
	8	3.8
	9	5.0
	10	3.7
	11	5.0
	12	0
	13	3.6
	14	2.4
	15	3.5
	16	3.4
	⑬ 1.3Vp-p	
	17	5.4
	18	7.6
	19	0.7
	20	3.5
	21	*
	22	3.8
	23	3.5
	24	1.9
	⑩ PAL 4.000Vp-p	
	⑩ NTSC  4.160Vp-p	
	25	1.9
	⑪ 3.760Vp-p	
	26	1.9
	⑫  4.080Vp-p	
	27	0
	28	4.4
	29	4.4
	30	4.4
	31	8.7
	32	4.1
	⑥ 0.2Vp-p	
	33	4.1
	⑤  1.1Vp-p	
	34	3.5
	④ 880.0mVp-p	
	35	8.7
	36	4.4
	37	(4.6)[4.4]
	38	4.6
	39	4.6
	⑨ 920.0mVp-p	
	40	5.1
	⑧ 1.160Vp-p	
	41	5.1
	⑦ PAL 1.520Vp-p	
	⑦ NTSC 1.400Vp-p	

A BOARD

Ref	Pin No.	Voltage[v]
	42	0
	43	5.0
	44	4.7
	45	6.6
	46	5.0
	47	8.8
	48	0
	49	4.3
	50	0
	51	(0)[2.7]
	52	(3.1)[0]
IC302	1	(0.3)[0.6]
	2	0
	3	0.5
	4	0
	5	0.1
	6	0
	7	2.9
	8	0
	9	0
	10	(0)[2.2]
	11	2.1
	12	(0)[2.2]
	13	0
	14	0.2
	15	0
	16	0
IC502	1	0.9
	2	3.5
	3	(0)[1.8]
	4	0
	5	2.9
	6	2.4
	7	6.9
	8	8.9
IC503	1	1.5
	2	13.1
	3	13.3
	4	14.7
	5	0.5
	6	13.2
	7	1.5
IC601	1	1.9
	2	0
	3	187.7
	4	16.9
	5	0
IC602	1	76.3
	2	68.5
	3	(*)[0]
IC603	I	12.0
	G	0
	O	8.9
IC604	I	7.8
	G	0
	O	0
PH600	1	72.5
	2	71.6
	3	3.3
	4	16.9
Q001	B	4.9
	C	0
	E	(0.8)[1.1]
Q002	B	0
	C	4.9
	E	0
Q101	B	2.5
	C	8.8
	E	1.9

Ref	Pin No.	Voltage[v]
Q301	B	12.0
	C	0
	E	11.8
Q302	B	0.5
	C	8.7
	E	0
Q303	B	8.7
	C	0
	E	8.8
Q304	B	3.5
	C	0
	E	4.2
Q305	B	8.7
	C	0
	E	8.8
Q306	B	0.5
	C	8.6
	E	0
Q308	B	3.6
	C	0.3
	E	0.8
Q309	B	2.9
	C	0
	E	0
Q310	B	0.4
	C	2.2
	E	0
Q311	B	0
	C	8.9
	E	0
Q312	B	5.1
	C	0
	E	6.6
Q313	B	0
	C	11.8
	E	0
Q314	B	0.17
	C	0
	E	2.2
Q315	B	0
	C	3.5
	E	0
Q316	B	4.1
	C	0
	E	4.7
Q317	B	4.1
	C	0
	E	4.7
Q501	B	3.4
	C	0
	E	4.0
Q502	B	4.2
	C	2.3
	E	4.0
Q503	B	0
	C	3.6
	E	0
Q505	S	0
	G	*
	D	*
Q506	B	0.5
	C	*
	E	0
Q507	B	12.5
	C	0.3
	E	13.1
Q509	B	0.6
	C	0
	E	0

Ref	Pin No.	Voltage[v]
Q511	B	0.8
	C	0
	E	0
Q600	B	0
	C	12.2
	E	0
Q601	B	0.7
	C	0.3
	E	0.3
Q602	B	0.1
	C	16.8
	E	0.1
Q603	B	16.8
	C	3.3
	E	16.9
Q604	B	133.8
	C	0
	E	134.0
Q605	S	0.6
	G	0.2
	D	(266.3)[257]
Q606	B	0.1
	C	0.2
	E	0.6
Q607	B	1.4
	C	(0.8)[1.1]
	E	1.1
Q608	B	0
	C	0.8
	E	0











B10 BOARD

Ref	Pin No.	Voltage[v]
IC1401	1	3.8
	2	3.9
	3	3.8
	4	3.9
	5	3.8
	6	8.2
	7	3.8
	8	3.9
	9	3.8
	10	3.9
	11	3.8
	12	8.2
	13	3.9
	14	3.9
	15	3.8
	16	3.9
	17	3.8
	18	8.1
	19	4.3
	20	4.4
	21	0
	22	3.9
	23	3.8
	24	3.9
	25	3.8
	26	3.9
	27	3.8
	28	3.9
	29	3.8
	30	3.8
	31	3.9
	32	3.9
	33	3.8
	34	0
	35	3.8
	36	0
	37	3.8
	38	3.9
	39	3.9
	40	3.8
	41	3.8
	42	3.9
	43	3.7
	44	8.8
	45	3.8
	46	3.9
	47	3.9
	48	3.8
IC1402	1	4.9
	2	2.5
	3	2.5
	4	0
	5	8.8
	6	5.0
	7	2.5
	8	2.5
IC1404	I	12.1
	G	0
	O	8.8
IC3200	1	4.4
	2	4.4
	3	4.4
	4	0
	5	4.4
	6	4.4
	7	4.4
	8	8.9
IC3202	1	4.4
	2	4.4
	3	4.4
	4	0
	5	4.4
	6	4.4
	7	4.4
	8	8.9

Ref	Pin No.	Voltage[v]
IC3204	1	4.5
	2	4.5
	3	4.4
	4	0
	5	4.4
	6	4.5
	7	4.5
	8	8.8
IC3205	1	8.8
	2	0.1
	3	0.4
	4	0.4
	5	0.4
	6	0.4
	7	0.3
	8	0
	9	0.1
	10	2.4
	11	0
	12	0
	13	8.7
	14	4.4
	15	4.4
	16	8.8
IC3301	1	2.7
	2	2.6
	3	3.0
	4	3.0
	5	0.4
	6	0
	7	0
	8	0
	9	4.5
	10	4.5
	11	4.5
	12	0
	13	0.4
	14	8.8
IC3302	1	4.4
	2	4.5
	3	4.5
	4	4.5
	5	4.5
	6	4.5
	7	4.5
	8	4.5
	9	4.5
	10	4.4
	11	4.4
	12	4.5
	13	4.5
	14	1.5
	15	1.7
	16	2.7
	17	2.7
	18	4.4
	19	*
	20	0
	21	8.9
	22	4.5
	23	2.5
	24	2.1
	25	2.1
	26	2.1
	27	2.0
	28	4.5
	29	4.4
	30	4.3
	31	4.4
	32	4.5
	33	4.4
	34	4.5
	35	4.5
	36	4.4
	37	4.4
	38	4.5

Ref	Pin No.	Voltage[v]
	39	4.4
	40	4.4
IC6200	1	1.5
	2	0
	3	0
	4	0
	5	1.6
	6	8.7
	7	12.3
	8	5.0
	9	25.8
	10	0
	11	4.2
	12	12.0
Q1316	B	8.8
	C	4.6
	E	8.2
Q1317	B	3.9
	C	8.7
	E	4.6
Q1318	B	3.5
	C	6.1
	E	4.2
Q1323	B	2.0
	C	8.2
	E	2.7
Q1324	B	5.4
	C	8.8
	E	6.1
Q1365	B	3.5
	C	5.3
	E	4.2
Q1372	B	2.8
	C	8.8
	E	3.5
Q1401	B	0
	C	8.8
	E	0
Q1402	B	4.5
	C	0
	E	3.8
Q1403	B	3.1
	C	8.8
	E	3.7
Q1404	B	3.2
	C	8.8
	E	3.8
Q1408	B	5.2
	C	8.8
	E	5.8
Q1409	B	1.8
	C	5.8
	E	2.5
Q3201	S	4.4
	G	4.2
	D	4.3
Q3202	B	3.6
	C	8.6
	E	4.1
Q3203	B	3.6
	C	8.6
	E	4.1
Q3204	S	3.6
	G	4.0
	D	4.4
Q6201	B	0
	C	4.2
	E	0
Q6206	B	0
	C	8.8
	E	0
Q6208	B	0
	C	8.6
	E	0

C6 BOARD

Ref	Pin No.	Voltage[v]
IC1800	1	6.4
	2	6.4
	3	6.4
	4	6.4
	5	0
	6	6.4
	7	6.4
	8	6.3
	9	6.3
	10	12.7
J701	KR	(135)[132]
	①  164.0Vp-p	
	KG	(135)[*]
	②  160.0Vp-p	

Ref	Pin No.	Voltage[v]
	KB	(136)[*]
	③  170.0Vp-p	
	H2	(*)[0.2]
	④ 24.80Vp-p	
	G2	(266)[263]
Q701	B	*
	C	204
	E	*
Q702	B	136
	C	204
	E	*
Q703	B	(*)[131]
	C	204
	E	*
Q704	B	8.9
	C	(*)[129]
	E	8.3

Ref	Pin No.	Voltage[v]
Q705	B	8.9
	C	*
	E	8.3
Q706	B	8.9
	C	*
	E	8.4
Q707	B	*
	C	5.6
	E	*
Q708	B	*
	C	(5.7)[6.1]
	E	*
Q709	B	*
	C	(5.1)[5.6]
	E	(*)[132]
Q710	B	(1.9)[2.0
	C	8.3
	E	1.5
Q711	B	1.9
	C	8.3
	E	1.5
Q712	B	1.9
	C	8.3
	E	1.5
Q714	B	0.6
	C	0.2
	E	0.01

VM1 BOARD

Ref	Pin No.	Voltage[v]
Q5901	B	2.6
	C	8.8
	E	(0)[2.0]
Q5902	B	135
	C	135
	E	(70)[64]
Q5903	B	2.6
	C	4.5
	E	1.9

Ref	Pin No.	Voltage[v]
Q5904	B	4.5
	C	0
	E	5.0
Q5905	B	5.5
	C	8.8
	E	5.0
Q5906	B	(0.27)[0.22]
	C	(0)[64.7]
	E	0

Ref	Pin No.	Voltage[v]
Q5907	B	0
	C	0
	E	0
Q5908	B	3.3
	C	0
	E	0
Q5909	B	0
	C	8.8
	E	3.3

D3 BOARD

Ref	Pin No.	Voltage[v]	Ref	Pin No.	Voltage[v]
IC2800	I	13.2	Q2801	B	(*)[0.3
	G	0		C	(3.1)[*]
	O	9.0		E	0
IC2801	1	4.4	Q2802	B	2.4
	2	4.5		C	12.7
	3	4.4		E	1.7
	4	0	Q2803	B	12.1
	5	(1.2)[1.4]		C	2.3
	6	1.2		E	12.7
	7	7.9	Q2804	B	2.0
	8	8.9		C	12.1
Q2800	B	(0.41)[*]		E	1.5
	C	*			
	E	0			

H1 AND H2 BOARD

Ref	Pin No.	Voltage[v]
IC3901	1	(4.9)[4.8]
	2	(0)[4.9]
	3	(4.8)[0]
Q3901	B	0.1
	C	4.9
	E	0.2
Q3902	B	(4.7)[0]
	C	(2.4)[4.9]
	E	(2.0)[0.1]

B1 BOARD

Ref	Pin No.	Voltage[v]	Ref	Pin No.	Voltage[v]	Ref	Pin No.	Voltage[v]
IC1502	1	3.1	Q1502	B	2.3	Q1514	B	0.6
	2	3.0		C	2.3		C	0.6
	3	3.2		E	2.5		E	0.6
	4	4.6	Q1503	B	0.6	Q1515	B	0.6
	5	4.6		C	0.6		C	0.6
	6	0		E	0.6		E	0.6
	7	0	Q1505	B	0.6	Q1516	B	0.5
	8	0		C	0.8		C	0.5
	9	8.1		E	0		E	0.5
	10	7.9	Q1507	B	0.7	Q1520	B	0.5
	11	7.9		C	0.8		C	0.4
	12	7.6		E	0.7		E	0
	13	7.6	Q1509	B	0.8	Q1522	B	0.4
	14	7.3		C	0.8		C	0
	15	7.6		E	0		E	0.5
	16	7.6	Q1510	B	0.7	Q1523	B	0.4
Q1501	B	2.5		C	0.7		C	0
	C	2.4		E	0		E	0.5
	E	2.4	Q1511	B	0.7			
				C	0.7			
				E	0			

5-5. PRINTED WIRING BOARDS AND PARTS LOCATION

PRINTED WIRING BOARDS

C6 [VIDEO AMP, ROTATION CIRCUIT] **F** [CISPR]

– C6 Board –



– F Board –



KV-AR29M90
RM-993

PRINTED WIRING BOARDS

A [SYSTEM CONTROLLER, Y/C JUNGLE, DEFLECTION, TUVIF, FRONT AMP, POWER SUPPLY]

NOTE:
The circuit indicated at left contains high voltage of over 1220 Vp-p. Please pay attention when inspecting or repairing it to prevent an electric shock.

– A Board –



A BOARD

IC

IC001	B-10
IC002	D-10
IC003	A-9
IC100	B-4
IC201	B-12
IC203	B-4
IC301	B-6
IC302	D-7
IC502	E-6
IC503	J-5
IC601	J-8
IC602	H-6
IC603	E-8
IC604	D-10
IC901	I-13

TRANSISTOR

Q001	B-8
Q002	B-8
Q005	B-9
Q101	B-4
Q201	A-11
Q202	A-11
Q203	C-11
Q204	C-12
Q205	A-12
Q206	A-11
Q207	A-12
Q301	B-8
Q302	C-6
Q303	D-6
Q304	B-6
Q305	C-6
Q306	D-6
Q307	D-6
Q308	C-5
Q309	D-6
Q310	D-8
Q311	D-9
Q312	B-7
Q313	B-8
Q314	D-8
Q315	B-4
Q316	B-5
Q317	B-5
Q401	D-2
Q402	D-1
Q403	C-3
Q404	D-2
Q501	D-6
Q502	E-7
Q503	F-6
Q505	D-6
Q506	E-2
Q507	H-6
Q509	F-6
Q511	F-1
Q600	D-12
Q601	F-11
Q602	J-7
Q603	J-7
Q604	H-6
Q605	E-12
Q606	F-11
Q607	H-13
Q901	H-13
Q902	H-13

DIODE

D001	B-8
D002	B-9
D003	C-9
D004	D-8
D005	B-8
D006	A-3
D007	B-8
D008	B-8
D009	B-8
D010	D-10
D203	C-11
D300	A-9
D301	B-9
D303	B-5
D304	B-5
D305	B-5
D306	C-5
D307	C-5
D308	B-5
D309	D-5
D311	C-5
D312	C-5
D313	A-8
D314	A-9
D315	B-7
D316	B-7
D317	B-9
D319	B-6
D320	C-5
D321	B-6
D401	C-2
D402	C-2
D403	C-2
D404	C-2
D405	B-1
D406	B-1
D407	C-2
D408	B-1
D409	A-1
D504	D-5
D505	H-6
D506	F-6
D507	F-6
D508	I-6
D509	F-6
D510	F-5
D511	F-5
D512	G-5
D513	I-5
D517	F-2
D518	F-2
D519	F-2
D520	E-5
D521	I-4
D522	J-4
D523	H-4
D525	F-5
D526	F-6
D527	F-3
D528	F-3
D529	F-5
D531	E-6
D533	D-2
D534	E-6
D500	G-13
D601	I-8
D602	G-13
D603	F-11
D604	J-7
D605	G-10
D606	E-11
D607	F-10
D608	F-11
D609	H-8
D610	J-8
D611	I-7
D612	F-8
D613	I-7
D615	E-7
D616	E-9
D617	F-8
D618	F-9
D620	E-8
D621	F-9
D622	F-8
D623	F-12
D624	E-12
D625	D-12
D627	F-8
D628	G-5
D629	E-9
D630	E-10
D631	G-12
D632	E-12
D633	E-12
D634	F11
D635	E-12
D636	D-12
D637	F-11
D638	E-11
D639	D-12
D901	C-13
D902	C-13
D903	C-13
D904	D-13
D905	F-13
D906	H-13

KV-AR29M90
RM-993

PRINTED WIRING BOARDS

B10 [AUDIO PROCESSOR, AUDIO AMP, SUB TUNER, AV IN/OUT, VM DRIVER]

– B10 Board –



KV-AR29M90
RM-993

PRINTED WIRING BOARDS

D3 [DYNAMIC FOCUS, DQP]

H1 [FRONT AV IN, KEY SW]

H2 [RECEIVER, POWER SW, LED]

VM1 [VELOCITY MODULATIONM]

– D3 Board –



– H2 Board –



– VM1 Board –



– H1 Board –



PRINTED WIRING BOARDS

J [DVD TERMINAL]

B1 [DVD, SWITCH]

– J Board –



– B1 Board –



5-7. SEMICONDUCTORS

TRANSISTOR

					
2SK2845-LB102	DTC144ESA 2SA1175-HFE 2SC2785-HFE	DTC144EKA MSD601-RT1 UN2111 UN2213 2SA1162-G 2SC2712-YG 2SD2114K	2SK246-GR	2SC2458-YGR 2SC3576	2SC2611 2SC2688-LK

DIODE

					
2SC2958	IRF614	2SD2578-CA	2SA1606-E 2SC4793 2SC4159-E	2SA1091-0 2SC2551-0	D1N20R D1NS4 RD39ES-B RD6.8ES-B1 RD20ES-B2 RD30ES-B2 1SS119-25

				
DTZ10B MA111-TX RD5.1SB-T2 RD7.5SB1-T1 RD9.1S-B UDZS-TE17-9.1B 1SS355TE-17	RU-1P		D5S6M	5P-6M	SPB-25MVWF

					
D3SB60	ERC04-06SE RS3FS 1SS133T-77 FR-104-AS	ON3171-R	DA204K	AK04V0 AU-01Z-V1 DTZ-TT11-15B D2L20U ERA22-08 FR104-A5 GP08D	NNCD9.1A-T1 RD33EB3T RGP02-17EL-6433 RU4AM-T3 RU4AM-T4

DIODE

IC

				 Single In -line Package Pin 8~98	
30DF2N-FCS	MMDL914T1	S-80743-AL-A7-S	NJM78M09FA	CXA1315M MM1319AFBE NJM2903M NJU4066BM LM358D UPC4558G2	

DIP  Dual In-line Package Pin 6~98					
CXA1855S CXA2159S CXP750097-602S M24C08-BN6		SE-135N	TDA8172	SBX3081-21	TA8200AH

MARKING SIDE VIEW



Zig-zag In -line Package
Pin 6~99

STR-F6456S

SECTION 6
EXPLODED VIEWS

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

6-1. SPEAKER BRACKET

■ : 7-685-663-79 SCREW +BVTP 4 × 16



REF. NO.		PART NO.	DESCRIPTION	REMARK
1		4-302-404-03	SCREW (WASHER HEAD)(+P4 x 16)	
2		4-087-606-01	COVER REAR	
3		1-825-099-11	SPEAKER (13 x 5.5 CM)	
4	*	4-087-798-11	BRACKET,SPEAKER	

6-2. CHASSIS

● : 7-685-648-79 SCREW +BVTP 3 × 12
■ : 7-685-663-79 SCREW +BVTP 4 × 16



REF. NO.	PART NO.	DESCRIPTION	REMARK
51	* A-1400-888-A	H1 BOARD MOUNTED	
52	* A-1300-556-A	B10 BOARD COMPLETE	
53	* A-1400-886-A	J BOARD, MOUNTED	
54	⚠ 4-022-115-00	HOLDER, AC CORD	
55	⚠ 1-757-030-11	CORD, POWER (WITH CONNECTOR)	
56	* 4-067-072-71	BRACKET, TERMINAL	
57	* A-1300-557-A	A BOARD COMPLETE	
58	⚠ 1-453-284-11	TRANSFORMER ASSY, FLYBACK (NX-4009//M314)	
59	* A-1401-077-A	B1 BOARD MOUNTED	
60	* 4-088-486-01	HOLDER PWB	

REF. NO.	PART NO.	DESCRIPTION	REMARK
61	* A-1241-445-A	F BOARD MOUNTED	
62	* 4-067-074-01	BRACKET F PWB	
63	* A-1401-079-A	D3 BOARD MOUNTED	
64	8-598-451-30	TUNER,FSS BTF-WG441	
65	4-046-797-01	SCREW (3 x 12) (+) BVTAP	
66	* 4-087-492-01	BRACKET MAIN (7 SCREWS (3 x 12) (+)BVTAP	
67	* A-1400-889-A	H2 BOARD MOUNTED	

6-3. PICTURE TUBE

● : 7-685-648-79 SCREW +BVTP 3 × 12
■ : 7-685-663-79 SCREW +BVTP 4 × 16



REF. NO.		PART NO.	DESCRIPTION	REMARK
151		X-4040-413-1	BEZNET ASSY	152-154, 172,173
152		4-036-405-11	SPRING, COMPRESSION	
153		4-086-448-01	BUTTON, POWER	
154		4-086-707-01	GUIDE, LIGHT	
155	⚠	8-735-058-01	PICTURE TUBE (M68LNH070X)	
156	*	3-704-372-61	HOLDER, HV CABLE	
157		3-703-961-01	SPACER, DY	
158		X-4387-214-3	PERMALOY ASSY, CORRECTION	
159	⚠	8-451-494-31	DEFLECTION YOKE (Y29RSA-S)	
160	*	A-1401-078-A	C6 BOARD MOUNTED	
161	⚠	1-419-323-11	COIL, DEGAUSSING	
162	*	4-063-935-21	CUSHION (50 X 550) DGC	
163		4-064-883-03	HOLDER, DGC	
164		1-452-896-11	COIL, NA ROTATION (RT200)	
165	*	A-1400-080-A	VM1 BOARD MOUNTED	

REF. NO.		PART NO.	DESCRIPTION	REMARK
166		4-369-318-61	SPRING, TENSION	
167		1-452-032-00	MAGNET, DISC	
168		1-452-094-00	CIRCULAR DISC MAGNET B	
169		4-077-228-02	PIECE, TLH CONVERGENCE	
170		4-079-376-01	BAND, DGC	
171		8-453-011-41	NA299-C	
172		4-088-697-01	DOOR	
173		4-087-491-11	SPRING (DOOR)	
174		4-046-765-12	SCREW TAPPING 7+ CROWN WASHER	
175	*	4-062-970-22	CLIP (29RSN), DGC	

SECTION 7
ELECTRICAL PARTS LIST

A

NOTE:

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- All resistors are in ohms
- F : nonflammable

CAPACITORS
- MF : µF, PF : µµF

COILS
- MMH : mH, UH : µH

REF NO.	PART NO.	DESCRIPTION			REMARK
*	A-1300-557-A	A BOARD COMPLETE **********			
*	4-040-983-31	TERMINAL BOARD (D)			
	4-382-854-11	SCREW (M3X10), P, SW (+)			
	4-382-854-21	SCREW (M3X14), P, SW (+)			
		<CAPACITOR>			
C004	1-163-001-11	CERAMIC CHIP	220PF	10.00%	50V
C005	1-163-001-11	CERAMIC CHIP	220PF	10.00%	50V
C006	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C007	1-126-947-11	ELECT	47UF	20.00%	16V
C013	1-162-970-11	CERAMIC CHIP	0.01UF	10.00%	25V
C014	1-126-947-11	ELECT	47UF	20.00%	25V
C015	1-163-009-91	CERAMIC CHIP	0.001UF	10.00%	50V
C016	1-163-243-11	CERAMIC CHIP	47PF	5.00%	50V
C017	1-163-247-91	CERAMIC CHIP	68PF	5.00%	50V
C019	1-126-947-11	ELECT	47UF	20.00%	25V
C020	1-163-259-91	CERAMIC CHIP	220PF	5.00%	50V
C022	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V
C023	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V
C024	1-163-227-11	CERAMIC CHIP	10PF	0.50PF	50V
C026	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C027	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C028	1-163-037-11	CERAMIC CHIP	0.022UF	10.00%	50V
C030	1-126-965-91	ELECT	22UF	20.00%	50V
C031	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C032	1-107-823-11	CERAMIC CHIP	0.47UF	10.00%	16V
C041	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C042	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C043	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C044	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C047	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C048	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C050	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C051	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C053	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C056	1-163-263-11	CERAMIC CHIP	330PF	5.00%	50V
C103	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C104	1-126-935-11	ELECT	470UF	20.00%	16V
C107	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C108	1-126-947-11	ELECT	47UF	20.00%	16V
C109	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C110	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C111	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C112	1-126-947-11	ELECT	47UF	20.00%	16V
C113	1-126-935-11	ELECT	470UF	20.00%	16V
C114	1-126-967-11	ELECT	47UF	20.00%	50V
C118	1-110-501-11	CERAMIC CHIP	0.33UF	10.00%	16V
C300	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C301	1-126-935-11	ELECT	470UF	20.00%	16V
C302	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C303	1-126-959-11	ELECT	0.47UF	20.00%	50V
C304	1-126-967-11	ELECT	47UF	20.00%	50V
C305	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C306	1-163-233-91	CERAMIC CHIP	18PF	5.00%	50V
C307	1-163-233-91	CERAMIC CHIP	18PF	5.00%	50V
C308	1-163-259-91	CERAMIC CHIP	220PF	5.00%	50V
C309	1-137-378-11	MYLAR	0.22UF	5.00%	50V
C311	1-126-964-11	ELECT	10UF	20.00%	50V
C312	1-164-346-11	CERAMIC CHIP	1UF		16V
C313	1-164-346-11	CERAMIC CHIP	1UF		16V
C314	1-164-346-11	CERAMIC CHIP	1UF		16V
C315	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C316	1-126-934-11	ELECT	220UF	20.00%	16V
C317	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C318	1-163-031-91	CERAMIC CHIP	0.01UF		50V
C319	1-163-031-91	CERAMIC CHIP	0.01UF		50V
C320	1-163-031-91	CERAMIC CHIP	0.01UF		50V
C321	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C322	1-163-005-91	CERAMIC CHIP	470PF	10.00%	50V
C324	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V
C325	1-126-960-11	ELECT	1UF	20.00%	50V
C327	1-126-965-91	ELECT	22UF	20.00%	50V
C328	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C329	1-126-963-11	ELECT	4.7UF	20.00%	50V
C330	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C331	1-126-963-11	ELECT	4.7UF	20.00%	50V
C332	1-126-963-11	ELECT	4.7UF	20.00%	50V
C335	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C336	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C337	1-126-961-11	ELECT	2.2UF	20.00%	50V
C341	1-115-340-11	CERAMIC CHIP	0.22UF	10.00%	25V
C342	1-163-259-91	CERAMIC CHIP	220PF	5.00%	50V
C347	1-126-933-11	ELECT	100UF	20.00%	16V
C348	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C349	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C350	1-163-031-91	CERAMIC CHIP	0.01UF		50V
C351	1-126-964-11	ELECT	10UF	20.00%	50V
C352	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C353	1-126-960-11	ELECT	1UF	20.00%	50V
C356	1-126-947-11	ELECT	47UF	20.00%	16V
C357	1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C502	1-163-145-00	CERAMIC CHIP	0.0015UF	5.00%	50V
C503	1-126-964-11	ELECT	10UF	20.00%	50V
C506	1-107-638-11	ELECT	33UF	20.00%	160V
C507	1-161-830-00	CERAMIC	0.0047UF		500V
C510	1-102-112-00	CERAMIC	330PF	10.00%	50V
C512	1-163-989-11	CERAMIC CHIP	0.033UF	10.00%	25V
C513	1-163-263-11	CERAMIC CHIP	330PF	5.00%	50V
C514	1-106-383-00	MYLAR	0.047UF	10.00%	200V
C517	1-164-182-11	CERAMIC CHIP	0.0033UF	10.00%	50V
C518	1-104-665-11	ELECT	100UF	20.00%	10V

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

A

REF NO.		PART NO.	DESCRIPTION		REMARK	
C519		1-102-212-00	CERAMIC	820PF	10.00%	500V
C521		1-126-934-11	ELECT	220UF	20.00%	16V
C522		1-126-933-11	ELECT	100UF	20.00%	16V
C523		1-102-002-00	CERAMIC	680PF	10.00%	500V
C524		1-126-967-11	ELECT	47UF	20.00%	50V
C526		1-130-495-00	MYLAR	0.1UF	5.00%	50V
C527		1-102-820-00	CERAMIC	330PF	5.00%	50V
C528		1-162-116-00	CERAMIC	680PF	10.00%	2KV
C530		1-137-372-11	MYLAR	0.022UF	5.00%	50V
C531		1-107-903-11	ELECT	2.2UF	20.00%	50V
C532		1-126-941-11	ELECT	470UF	20.00%	25V
C533		1-126-941-11	ELECT	470UF	20.00%	25V
C534		1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C536		1-130-495-00	MYLAR	0.1UF	5.00%	50V
C537		1-126-969-11	ELECT	220UF	20.00%	50V
C538		1-127-717-11	FILM	19000PF	3%	1.2KV
C539	⚠	1-110-541-91	FILM	0.056UF	5.00%	630V
C540		1-136-171-00	FILM	0.33UF	5.00%	50V
C546		1-165-319-11	CERAMIC CHIP	0.1UF		50V
C549		1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V
C550		1-106-220-00	MYLAR	0.1UF	10.00%	100V
C551		1-126-960-11	ELECT	1UF	20.00%	50V
C552		1-162-116-00	CERAMIC	680PF	10.00%	2KV
C553		1-162-116-00	CERAMIC	680PF	10.00%	2KV
C554		1-137-417-11	MYLAR	0.0047UF	10.00%	200V
C556		1-126-941-11	ELECT	470UF	20.00%	25V
C557		1-126-941-11	ELECT	470UF	20.00%	25V
C558		1-123-024-21	ELECT	33UF		160V
C560		1-102-228-00	CERAMIC	470PF	10.00%	500V
C561		1-129-898-00	FILM	0.0022UF	5.00%	630V
C562		1-102-228-00	CERAMIC	470PF	10.00%	500V
C564		1-163-038-91	CERAMIC CHIP	0.1UF		25V
C565		1-107-655-11	ELECT	47UF	20.00%	250V
C566		1-102-244-00	CERAMIC	220PF	10.00%	500V
C567	⚠	1-115-520-21	FILM	0.68UF	5.00%	250V
C568		1-102-228-00	CERAMIC	470PF	10.00%	500V
C570		1-115-522-11	FILM	1UF	5.00%	250V
C572		1-117-661-21	FILM	0.15UF	5.00%	250V
C573		1-106-387-00	MYLAR	0.068UF	10.00%	200V
C574		1-104-709-11	ELECT	4.7UF		160V
C576		1-130-495-00	MYLAR	0.1UF	5.00%	50V
C577		1-106-395-00	MYLAR	0.15UF	10.00%	200V
C582		1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C584		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C586		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C600	⚠	1-115-165-11	MYLAR	0.1UF	20.00%	250V
C602	⚠	1-115-165-11	MYLAR	0.1UF	20.00%	250V
C603		1-126-947-11	ELECT	47UF	20.00%	25V
C604		1-163-009-91	CERAMIC CHIP	0.001UF	10.00%	50V
C605	⚠	1-119-886-51	CERAMIC	470PF	10.00%	250V
C606	⚠	1-119-886-51	CERAMIC	470PF	10.00%	250V
C607		1-161-830-00	CERAMIC	0.0047UF	99%	500V
C608		1-161-830-00	CERAMIC	0.0047UF	99%	500V
C609		1-126-968-11	ELECT	100UF	20.00%	50V
C610		1-126-964-11	ELECT	10UF	20.00%	50V
C611		1-161-830-00	CERAMIC	0.0047UF	99%	500V
C612		1-161-830-00	CERAMIC	0.0047UF	99%	500V
C613		1-125-906-11	ELECT	560UF	20.00%	450V
C614		1-126-964-11	ELECT	10UF	20.00%	50V
C615	⚠	1-119-886-51	CERAMIC	470PF	10.00%	250V

REF NO.		PART NO.	DESCRIPTION		REMARK	
C616		1-130-202-00	FILM	0.022UF	5.00%	400V
C617		1-107-792-11	CERAMIC	100PF	5.00%	1KV
C618		1-125-893-11	FILM	680PF	3.00%	1.5KV
C619	⚠	1-119-886-51	CERAMIC	470PF	10.00%	250V
C620		1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C621		1-102-114-00	CERAMIC	470PF	10.00%	50V
C622		1-102-074-00	CERAMIC	0.001UF	10.00%	50V
C623		1-104-665-11	ELECT	100UF	20.00%	25V
C624		1-104-331-11	CERAMIC	0.0022UF	10.00%	1KV
C626		1-102-002-00	CERAMIC	680PF	10.00%	500V
C629		1-126-964-11	ELECT	10UF	20.00%	50V
C630		1-125-494-11	ELECT(BLOCK)	560UF	20.00%	160V
C631		1-128-550-11	ELECT	2200UF	20.00%	50V
C632		1-126-936-11	ELECT	3300UF	20.00%	16V
C633		1-104-999-11	MYLAR	0.1UF	10.00%	200V
C634		1-126-933-11	ELECT	100UF	20.00%	16V
C635		1-126-934-11	ELECT	220UF	20.00%	16V
C636		1-104-760-11	CERAMIC CHIP	0.047UF	10.00%	50V
C638		1-161-830-00	CERAMIC	0.0047UF		500V
C641		1-102-002-00	CERAMIC	680PF	10.00%	500V
C642		1-126-943-11	ELECT	2200UF	20.00%	25V
C643		1-104-665-11	ELECT	100UF	20.00%	10V
C644		1-104-331-11	CERAMIC	0.0022UF	10.00%	1KV
C645		1-137-605-11	MYLAR	0.01UF	10.00%	250V
C646		1-107-679-91	ELECT	10UF	20.00%	450V
C647		1-163-275-11	CERAMIC CHIP	0.001UF	5.00%	50V
C649		1-126-940-11	ELECT	330UF	20.00%	25V
C650		1-163-275-11	CERAMIC CHIP	0.001UF	5.00%	50V
C651		1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C652		1-126-965-91	ELECT	22UF	20.00%	50V
C653		1-126-947-11	ELECT	47UF	20.00%	25V
C655	⚠	1-119-886-51	CERAMIC	470PF	10.00%	250V
C657		1-101-821-00	CERAMIC	0.0022UF		500V
C659		1-162-116-00	CERAMIC	680PF	10.00%	2KV
C912		1-107-826-11	CERAMIC CHIP	0.1UF	10.00%	16V
C913		1-104-665-11	ELECT	100UF	20.00%	10V
C915		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C916		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C917		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C918		1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V

<CONNECTOR>

CN101	*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P
CN102	*	1-779-889-11	CONNECTOR, BOARD TO BOARD 8P
CN104		1-695-915-11	TAB (CONTACT)
CN105		1-695-915-11	TAB (CONTACT)
CN106		1-564-506-11	PLUG, CONNECTOR 3P
CN201	*	1-564-508-11	PLUG, CONNECTOR 5P
CN202	*	1-508-847-00	PIN, CONNECTOR 4P
CN302	*	1-779-889-11	CONNECTOR, BOARD TO BOARD 8P
CN303	*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P
CN305		1-564-509-11	PLUG, CONNECTOR 6P
CN501	*	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P
CN502	*	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P
CN503	*	1-564-510-11	PLUG, CONNECTOR 7P
CN504		1-695-915-11	TAB (CONTACT)
CN505	*	1-564-508-11	PLUG, CONNECTOR 5P
CN507	*	1-564-509-11	PLUG, CONNECTOR 6P
CN601		1-580-843-11	PIN, CONNECTOR (POWER)
CN602	*	1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P
CN603	*	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P
CN604	*	1-691-134-11	PIN, CONNECTOR (PC BOARD) 2P

A

REF NO.		PART NO.	DESCRIPTION			REMARK
CN608		1-564-507-41	PLUG, CONNECTOR 4P			
CN904	*	1-564-512-11	PLUG, CONNECTOR 9P			
			<DIODE>			
D001		8-719-081-97	MMDL914T1			
D002		8-719-081-97	MMDL914T1			
D004		1-216-295-91	SHORT CHIP	0		
D005		8-719-081-97	MMDL914T1			
D006		1-216-295-91	SHORT CHIP	0		
D007		8-719-081-97	MMDL914T1			
D008		8-719-081-97	MMDL914T1			
D009		8-719-081-97	MMDL914T1			
D010		8-719-158-35	RD9.1S-B			
D100		8-719-081-97	MMDL914T1			
D300		1-216-295-91	SHORT CHIP	0		
D301		8-719-081-97	MMDL914T1			
D306		8-719-081-97	MMDL914T1			
D307		8-719-081-97	MMDL914T1			
D308		8-719-081-97	MMDL914T1			
D309		8-719-159-10	RD5.1SB-T2			
D311		8-719-081-97	MMDL914T1			
D312		8-719-081-97	MMDL914T1			
D313		8-719-081-97	MMDL914T1			
D315		8-719-081-97	MMDL914T1			
D316		8-719-037-06	RD7.5SB1-T1			
D319		8-719-158-35	RD9.1S-B			
D320		8-719-158-35	RD9.1S-B			
D321		8-719-158-35	RD9.1S-B			
D322		8-719-158-35	RD9.1S-B			
D504		8-719-075-05	DIODE FR104-A5			
D505		8-719-081-97	MMDL914T1			
D506		8-719-991-33	1SS133T-77			
D507		8-719-081-97	MMDL914T1			
D508		8-719-081-97	MMDL914T1			
D509		1-216-073-91	RES-CHIP	10K	5%	1/10W
D510		8-719-081-97	MMDL914T1			
D511		8-719-081-97	MMDL914T1			
D512		8-719-081-97	MMDL914T1			
D513		8-719-908-03	GP08D			
D517		8-719-312-71	RS3FS			
D518		8-719-074-35	RU4AM-T4			
D519		8-719-312-71	RS3FS			
D521		8-719-075-05	DIODE FR104-A5			
D522		8-719-028-45	D2L20U			
D523		8-719-075-05	DIODE FR104-A5			
D527		8-719-908-03	GP08D			
D528		8-719-908-03	GP08D			
D532		8-719-081-97	MMDL914T1			
D534		8-719-081-97	MMDL914T1			
D600		8-719-991-33	1SS133T-77			
D602		8-719-991-33	1SS133T-77			
D603		8-719-150-92	RD33EB3T			
D604		8-719-028-72	RGP02-17EL-6433			
D605		8-719-510-22	D3SB60			
D606		8-719-108-18	5P-6M			
D607		8-719-081-97	MMDL914T1			
D608		8-719-110-53	RD20ES-B2			
D609		8-719-311-31	RU-1P			
D610		8-719-043-76	AK04V0			
D611		8-719-046-74	AU-01Z-V1			
D612		8-719-043-52	F5KQ60			
D613		8-719-046-74	AU-01Z-V1			
D614		8-719-046-74	AU-01Z-V1			
D620		8-719-110-72	RD30ESB2			
D621		8-719-071-38	D5S6M			
D622		8-719-029-04	D5L60			
D623		8-719-978-65	DTZ-TT11-15B			
D624		8-719-081-97	MMDL914T1			
D625		8-719-977-28	DTZ10B			
D628		8-719-991-33	1SS133T-77			
D630		8-719-052-74	FMX-12S			
D631		8-719-068-00	ERC04-06SE			
D632		8-719-068-00	ERC04-06SE			
D633		8-719-948-45	ERA22-08			
D634		8-719-081-97	MMDL914T1			
D635		8-719-081-97	MMDL914T1			
D636		8-719-510-02	D1NS4			
D637		8-719-109-96	RD6.8ES-B1			
D638		8-719-510-48	D1N20R			
			<CONNECTOR>			
DY1	*	1-580-798-11	CONNECTOR PIN (DY) 6P			
			<FERRITE BEAD>			
FB300		1-412-911-31	FERRITE	0UH		
FB501		1-410-397-21	FERRITE	1.1UH		
FB502		1-410-397-21	FERRITE	1.1UH		
FB600		1-410-397-21	FERRITE	1.1UH		
FB601		1-410-397-21	FERRITE	1.1UH		
FB602		1-410-397-21	FERRITE	1.1UH		
FB603		1-410-397-21	FERRITE	1.1UH		
FB604		1-412-911-31	FERRITE	0UH		
FB605		1-412-911-31	FERRITE	0UH		
FB606		1-412-911-31	FERRITE	0UH		
FB608		1-412-911-31	FERRITE	0UH		
FB611		1-410-397-21	FERRITE	1.1UH		
FB612		1-410-397-21	FERRITE	1.1UH		
FB613		1-410-397-21	FERRITE	1.1UH		
FB615		1-410-397-21	FERRITE	1.1UH		
			<IC>			
IC001		8-752-931-45	IC CXP750097-602S			
IC002		8-759-371-21	MM1319AFBE			
IC003		8-759-672-78	M24C08-BN6(A)			
IC100		8-759-042-02	S-80743AL-A7-S			
IC301		8-752-095-72	CXA2159S			
IC302		8-759-666-90	IC TDA9181T			
IC502		8-759-700-07	NJM2903M			
IC503		8-759-980-58	TDA8172			
IC601		8-749-019-09	IC STR-F6456S			
IC602		8-749-920-61	SE-135N			
IC603		8-759-701-59	NJM78M09FA			
IC604		8-759-231-53	TA7805S			
			<CHIP CONDUCTOR>			
JR001		1-216-295-91	SHORT CHIP	0		
JR002		1-216-295-91	SHORT CHIP	0		
JR003		1-216-295-91	SHORT CHIP	0		
JR004		1-216-295-91	SHORT CHIP	0		
JR006		1-216-295-91	SHORT CHIP	0		

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

A

REF NO.	PART NO.	DESCRIPTION			REMARK
JR007	1-216-295-91	SHORT CHIP	0		
JR008	1-216-295-91	SHORT CHIP	0		
JR010	1-216-295-91	SHORT CHIP	0		
JR012	1-216-295-91	SHORT CHIP	0		
JR014	1-216-295-91	SHORT CHIP	0		
JR015	1-216-295-91	SHORT CHIP	0		
JR016	1-216-295-91	SHORT CHIP	0		
JR020	1-216-295-91	SHORT CHIP	0		
JR022	1-216-295-91	SHORT CHIP	0		
JR023	1-216-295-91	SHORT CHIP	0		
JR024	1-216-295-91	SHORT CHIP	0		
JR025	1-216-295-91	SHORT CHIP	0		
JR028	1-216-295-91	SHORT CHIP	0		
JR030	1-216-295-91	SHORT CHIP	0		
JR031	1-216-295-91	SHORT CHIP	0		
JR102	1-216-295-91	SHORT CHIP	0		
JR107	1-216-295-91	SHORT CHIP	0		
JR214	1-216-295-91	SHORT CHIP	0		
JR304	1-216-295-91	SHORT CHIP	0		
JR308	1-216-295-91	SHORT CHIP	0		
JR309	1-216-295-91	SHORT CHIP	0		
JR310	1-216-295-91	SHORT CHIP	0		
JR311	1-216-295-91	SHORT CHIP	0		
JR500	1-216-295-91	SHORT CHIP	0		
JR501	1-216-295-91	SHORT CHIP	0		
JR502	1-216-295-91	SHORT CHIP	0		
JR503	1-216-295-91	SHORT CHIP	0		
JR600	1-216-295-91	SHORT CHIP	0		
		<COIL>			
L002	1-414-856-11	INDUCTOR	10UH		
L003	1-414-180-11	INDUCTOR	3.3UH		
L004	1-249-395-11	CARBON	15	5%	1/4W
L005	1-414-233-22	FERRITE	0UH		
L101	1-414-856-11	INDUCTOR	10UH		
L102	1-414-189-31	INDUCTOR	100UH		
L103	1-414-856-11	INDUCTOR	10UH		
L104	1-414-856-11	INDUCTOR	10UH		
L105	1-414-185-41	INDUCTOR	22UH		
L301	1-414-189-31	INDUCTOR	100UH		
L302	1-414-185-41	INDUCTOR	22UH		
L303	1-414-189-31	INDUCTOR	100UH		
L304	1-414-189-31	INDUCTOR	100UH		
L501	1-412-525-31	INDUCTOR	10UH		
L502	1-416-947-11	COIL, AIR-CORE			
L503	1-412-525-31	INDUCTOR	10UH		
L504	1-412-525-31	INDUCTOR	10UH		
L507	1-459-111-00	INDUCTOR	10MH		
L511	1-406-977-71	INDUCTOR	0UH		
L513	1-412-551-31	INDUCTOR	1.5MH		
L515	1-459-104-00	COIL, WITH CORE			
L518	1-414-187-11	INDUCTOR	47UH		
L601	1-412-533-21	INDUCTOR	47UH		
L905	1-414-856-11	INDUCTOR	10UH		
		<PHOTO COUPLER>			
PH600	⚠ 8-749-924-35	ON3171-R			

REF NO.	PART NO.	DESCRIPTION			REMARK
		<IC LINK>			
PS600	1-533-597-41	LINK, IC			
PS601	1-533-597-41	LINK, IC			
		<TRANSISTOR>			
Q001	8-729-216-22	2SA1162-G			
Q002	8-729-230-49	2SC2712-YG			
Q101	8-729-230-49	2SC2712-YG			
Q301	8-729-216-22	2SA1162-G			
Q302	8-729-230-49	2SC2712-YG			
Q304	8-729-216-22	2SA1162-G			
Q306	8-729-230-49	2SC2712-YG			
Q307	8-729-230-49	2SC2712-YG			
Q308	8-729-216-22	2SA1162-G			
Q309	8-729-421-19	UN2213			
Q310	8-729-230-49	2SC2712-YG			
Q311	8-729-230-49	2SC2712-YG			
Q312	8-729-216-22	2SA1162-G			
Q313	8-729-230-49	2SC2712-YG			
Q315	8-729-421-19	UN2213			
Q316	8-729-216-22	2SA1162-G			
Q317	8-729-216-22	2SA1162-G			
Q501	8-729-216-22	2SA1162-G			
Q502	8-729-216-22	2SA1162-G			
Q503	8-729-230-49	2SC2712-YG			
Q505	8-729-931-45	IRF614			
Q506	8-729-119-80	2SC2688-LK			
Q507	8-729-216-22	2SA1162-G			
Q509	8-729-230-49	2SC2712-YG			
Q511	8-729-048-07	2SD2578-CA			
Q600	8-729-119-78	2SC2785-HFE			
Q601	8-729-023-22	2SD2114K			
Q602	8-729-230-49	2SC2712-YG			
Q603	8-729-424-08	UN2111			
Q604	8-729-200-17	2SA1091-O			
Q605	8-729-044-30	2SK2845-LB102			
Q606	8-729-230-49	2SC2712-YG			
Q607	8-729-823-22	2SC3576			
Q608	8-729-230-49	2SC2712-YG			
		<RESISTOR>			
R001	1-414-233-22	FERRITE	0UH		
R002	1-216-025-11	RES-CHIP	100	5%	1/10W
R003	1-216-073-91	RES-CHIP	10K	5%	1/10W
R004	1-216-025-11	RES-CHIP	100	5%	1/10W
R005	1-216-025-11	RES-CHIP	100	5%	1/10W
R008	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R010	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R011	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R012	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R013	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R014	1-216-025-11	RES-CHIP	100	5%	1/10W
R015	1-216-025-11	RES-CHIP	100	5%	1/10W
R018	1-216-033-00	RES-CHIP	220	5%	1/10W
R019	1-216-073-91	RES-CHIP	10K	5%	1/10W
R020	1-216-045-00	RES-CHIP	680	5%	1/10W
R021	1-216-073-91	RES-CHIP	10K	5%	1/10W
R022	1-216-295-91	SHORT CHIP	0		
R023	1-216-049-11	RES-CHIP	1K	5%	1/10W

A

REF NO.	PART NO.	DESCRIPTION		REMARK	
R024	1-216-063-91	RES-CHIP	3.9K	5%	1/10W
R025	1-216-063-91	RES-CHIP	3.9K	5%	1/10W
R026	1-216-063-91	RES-CHIP	3.9K	5%	1/10W
R027	1-216-049-11	RES-CHIP	1K	5%	1/10W
R028	1-216-073-91	RES-CHIP	10K	5%	1/10W
R029	1-216-049-11	RES-CHIP	1K	5%	1/10W
R031	1-216-049-11	RES-CHIP	1K	5%	1/10W
R032	1-216-025-11	RES-CHIP	100	5%	1/10W
R034	1-216-049-11	RES-CHIP	1K	5%	1/10W
R035	1-216-025-11	RES-CHIP	100	5%	1/10W
R036	1-216-025-11	RES-CHIP	100	5%	1/10W
R037	1-216-025-11	RES-CHIP	100	5%	1/10W
R038	1-216-049-11	RES-CHIP	1K	5%	1/10W
R040	1-216-025-11	RES-CHIP	100	5%	1/10W
R041	1-216-025-11	RES-CHIP	100	5%	1/10W
R042	1-216-295-91	SHORT CHIP	0		
R043	1-216-049-11	RES-CHIP	1K	5%	1/10W
R044	1-216-025-11	RES-CHIP	100	5%	1/10W
R045	1-414-233-22	FERRITE	0UH		
R046	1-216-049-11	RES-CHIP	1K	5%	1/10W
R047	1-414-233-22	FERRITE	0UH		
R048	1-216-073-91	RES-CHIP	10K	5%	1/10W
R050	1-216-073-91	RES-CHIP	10K	5%	1/10W
R053	1-216-049-11	RES-CHIP	1K	5%	1/10W
R058	1-216-295-91	SHORT CHIP	0		
R059	1-216-295-91	SHORT CHIP	0		
R060	1-216-295-91	SHORT CHIP	0		
R061	1-216-295-91	SHORT CHIP	0		
R062	1-216-041-00	RES-CHIP	470	5%	1/10W
R063	1-216-041-00	RES-CHIP	470	5%	1/10W
R064	1-216-041-00	RES-CHIP	470	5%	1/10W
R065	1-216-041-00	RES-CHIP	470	5%	1/10W
R066	1-216-049-11	RES-CHIP	1K	5%	1/10W
R067	1-216-049-11	RES-CHIP	1K	5%	1/10W
R068	1-216-041-00	RES-CHIP	470	5%	1/10W
R101	1-216-025-11	RES-CHIP	100	5%	1/10W
R102	1-216-025-11	RES-CHIP	100	5%	1/10W
R105	1-216-295-91	SHORT CHIP	0		
R109	1-216-041-00	RES-CHIP	470	5%	1/10W
R111	1-216-025-11	RES-CHIP	100	5%	1/10W
R112	1-216-025-11	RES-CHIP	100	5%	1/10W
R113	1-216-025-11	RES-CHIP	100	5%	1/10W
R225	1-216-033-00	RES-CHIP	220	5%	1/10W
R226	1-216-033-00	RES-CHIP	220	5%	1/10W
R227	1-216-033-00	RES-CHIP	220	5%	1/10W
R237	1-216-295-91	SHORT CHIP	0		
R301	1-216-113-00	RES-CHIP	470K	5%	1/10W
R302	1-216-295-91	SHORT CHIP	0		
R303	1-216-049-11	RES-CHIP	1K	5%	1/10W
R304	1-216-073-91	RES-CHIP	10K	5%	1/10W
R308	1-216-025-11	RES-CHIP	100	5%	1/10W
R309	1-216-025-11	RES-CHIP	100	5%	1/10W
R310	1-216-025-11	RES-CHIP	100	5%	1/10W
R311	1-216-041-00	RES-CHIP	470	5%	1/10W
R312	1-216-039-00	RES-CHIP	390	5%	1/10W
R313	1-216-037-00	RES-CHIP	330	5%	1/10W
R314	1-216-083-00	RES-CHIP	27K	5%	1/10W
R315	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R316	1-216-037-00	RES-CHIP	330	5%	1/10W
R317	1-216-091-00	RES-CHIP	56K	5%	1/10W
R318	1-216-039-00	RES-CHIP	390	5%	1/10W
R319	1-216-025-11	RES-CHIP	100	5%	1/10W

REF NO.	PART NO.	DESCRIPTION		REMARK	
R320	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R321	1-216-073-91	RES-CHIP	10K	5%	1/10W
R322	1-216-033-00	RES-CHIP	220	5%	1/10W
R323	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R324	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R326	1-216-029-00	RES-CHIP	150	5%	1/10W
R327	1-216-033-00	RES-CHIP	220	5%	1/10W
R328	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R329	1-216-041-00	RES-CHIP	470	5%	1/10W
R331	1-216-295-91	SHORT CHIP	0		
R332	1-216-033-00	RES-CHIP	220	5%	1/10W
R335	1-216-045-00	RES-CHIP	680	5%	1/10W
R338	1-216-037-00	RES-CHIP	330	5%	1/10W
R339	1-216-033-00	RES-CHIP	220	5%	1/10W
R340	1-216-025-11	RES-CHIP	100	5%	1/10W
R345	1-216-081-00	RES-CHIP	22K	5%	1/10W
R348	1-208-806-11	METAL CHIP	10K	0.5%	1/10W
R349	1-216-073-91	RES-CHIP	10K	5%	1/10W
R350	1-216-061-91	RES-CHIP	3.3K	5%	1/10W
R351	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R354	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R355	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R356	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R357	1-216-079-00	RES-CHIP	18K	5%	1/10W
R358	1-216-049-11	RES-CHIP	1K	5%	1/10W
R359	1-216-033-00	RES-CHIP	220	5%	1/10W
R360	1-216-033-00	RES-CHIP	220	5%	1/10W
R361	1-216-073-91	RES-CHIP	10K	5%	1/10W
R362	1-216-075-00	RES-CHIP	12K	5%	1/10W
R363	1-216-079-00	RES-CHIP	18K	5%	1/10W
R364	1-216-295-91	SHORT CHIP	0		
R365	1-216-033-00	RES-CHIP	220	5%	1/10W
R366	1-216-073-91	RES-CHIP	10K	5%	1/10W
R367	1-216-073-91	RES-CHIP	10K	5%	1/10W
R368	1-216-073-91	RES-CHIP	10K	5%	1/10W
R370	1-216-033-00	RES-CHIP	220	5%	1/10W
R371	1-216-083-00	RES-CHIP	27K	5%	1/10W
R372	1-216-091-00	RES-CHIP	56K	5%	1/10W
R376	1-216-081-00	RES-CHIP	22K	5%	1/10W
R377	1-216-121-11	RES-CHIP	1M	5%	1/10W
R378	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R379	1-218-179-11	RES-CHIP	10M	5%	1/10W
R381	1-216-295-91	SHORT CHIP	0		
R382	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R383	1-216-049-11	RES-CHIP	1K	5%	1/10W
R384	1-216-041-00	RES-CHIP	470	5%	1/10W
R385	1-216-029-00	RES-CHIP	150	5%	1/10W
R391	1-216-295-91	SHORT CHIP	0		
R500	1-249-417-11	CARBON	1K	5%	1/4W
R501	1-216-049-11	RES-CHIP	1K	5%	1/10W
R505	1-208-830-11	METAL CHIP	100K	0.5%	1/10W
R506	1-216-081-00	RES-CHIP	22K	5%	1/10W
R507	1-249-389-11	CARBON	4.7	5%	1/4W
R508	1-216-471-11	METAL OXIDE	27	5%	3W
R509	1-216-473-11	METAL OXIDE	56	5%	3W
R510	1-216-449-11	METAL OXIDE	56	5%	2W
R511	1-215-908-00	METAL OXIDE	33	5%	3W
R515	1-215-911-11	METAL OXIDE	100	5%	3W
R517	1-208-798-11	METAL CHIP	4.7K	0.5%	1/10W
R518	1-247-807-31	CARBON	100	5%	1/4W
R519	1-215-913-11	METAL OXIDE	220	5%	3W
R520	1-215-445-00	METAL	10K	1%	1/4W

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

A

REF NO.	PART NO.	DESCRIPTION		REMARK	
R522	1-208-806-11	METAL CHIP	10K	0.5%	1/10W
R523	1-249-411-11	CARBON	330	5%	1/4W
R525	1-208-846-11	METAL CHIP	470K	0.5%	1/10W
R526	1-208-804-11	METAL CHIP	8.2K	0.5%	1/10W
R527	1-216-001-00	RES-CHIP	10	5%	1/10W
R528	1-208-814-91	METAL CHIP	22K	0.5%	1/10W
R529	1-216-635-11	METAL CHIP	220	0.5%	1/10W
R531	1-247-843-11	CARBON	3.3K	5%	1/4W
R533	1-249-417-11	CARBON	1K	5%	1/4W
R534	1-216-364-21	METAL OXIDE	0.39	5%	2W
R535	1-216-067-00	RES-CHIP	5.6K	5%	1/10W
R536	1-216-067-00	RES-CHIP	5.6K	5%	1/10W
R537	1-208-804-11	METAL CHIP	8.2K	0.5%	1/10W
R539	1-216-049-11	RES-CHIP	1K	5%	1/10W
R540	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R541	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R542	1-216-073-91	RES-CHIP	10K	5%	1/10W
R543	1-216-437-00	METAL OXIDE	5.6K	5%	1W
R544	1-215-917-11	METAL OXIDE	1K	5%	3W
R545	1-216-077-91	RES-CHIP	15K	5%	1/10W
R546	1-216-077-91	RES-CHIP	15K	5%	1/10W
R547	1-216-085-91	RES-CHIP	33K	5%	1/10W
R548	1-216-665-11	METAL CHIP	3.9K	0.5%	1/10W
R549	1-215-452-00	METAL	20K	1%	1/4W
R550	1-216-097-11	RES-CHIP	100K	5%	1/10W
R551	1-249-441-11	CARBON	100K	5%	1/4W
R552	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R553	1-215-453-00	METAL	22K	1%	1/4W
R554	1-215-453-00	METAL	22K	1%	1/4W
R556	1-215-437-00	METAL	4.7K	1%	1/4W
R558	1-247-843-11	CARBON	3.3K	5%	1/4W
R559	1-249-429-11	CARBON	10K	5%	1/4W
R560	1-216-073-91	RES-CHIP	10K	5%	1/10W
R561	1-216-049-11	RES-CHIP	1K	5%	1/10W
R562	1-249-401-11	CARBON	47	5%	1/4W
R564	1-208-820-11	METAL CHIP	39K	0.5%	1/10W
R565	1-216-073-91	RES-CHIP	10K	5%	1/10W
R567	1-216-105-91	RES-CHIP	220K	5%	1/10W
R568	1-249-383-11	CARBON	1.5	5%	1/4W
R570	1-216-069-00	RES-CHIP	6.8K	5%	1/10W
R571	1-215-443-00	METAL	8.2K	1%	1/4W
R573	1-216-083-00	RES-CHIP	27K	5%	1/10W
R575	1-216-665-11	METAL CHIP	3.9K	0.5%	1/10W
R577	1-215-913-11	METAL OXIDE	220	5%	3W
R578	1-216-369-00	METAL OXIDE	1	5%	2W
R579	1-216-295-91	SHORT CHIP	0		
R580	1-208-830-11	METAL CHIP	100K	0.5%	1/10W
R581	1-208-790-11	METAL CHIP	2.2K	0.5%	1/10W
R582	1-208-842-11	METAL CHIP	330K	0.5%	1/10W
R584	1-218-760-11	METAL CHIP	220K	0.5%	1/10W
R585	1-249-385-11	CARBON	2.2	5%	1/4W
R587	1-208-822-11	METAL CHIP	47K	0.5%	1/10W
R588	1-215-888-00	METAL OXIDE	220	5%	2W
R589	1-215-888-00	METAL OXIDE	220	5%	2W
R590	1-215-465-00	METAL	68K	1%	1/4W
R591	1-260-288-11	CARBON	0.47	5%	1/2W
R592	1-208-820-11	METAL CHIP	39K	0.5%	1/10W
R593	1-260-288-11	CARBON	0.47	5%	1/2W
R594	1-260-288-11	CARBON	0.47	5%	1/2W
R595	1-216-073-91	RES-CHIP	10K	5%	1/10W
R596	1-215-916-00	METAL OXIDE	680	5%	3W

REF NO.		PART NO.	DESCRIPTION		REMARK	
R597		1-247-750-11	CARBON	680	5%	1/2W
R598		1-249-438-11	CARBON	56K	5%	1/4W
R599		1-249-389-11	CARBON	4.7	5%	1/4W
R600		1-249-438-11	CARBON	56K	5%	1/4W
R601		1-249-420-11	CARBON	1.8K	5%	1/4W
R602		1-249-389-11	CARBON	4.7	5%	1/4W
R603		1-215-485-00	METAL	470K	1%	1/4W
R604		1-216-097-11	RES-CHIP	100K	5%	1/10W
R607		1-249-425-11	CARBON	4.7K	5%	1/4W
R608		1-240-205-91	CARBON	22M	5%	1/2W
R609		1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R610		1-216-073-91	RES-CHIP	10K	5%	1/10W
R611		1-216-089-91	RES-CHIP	47K	5%	1/10W
R612		1-216-045-00	RES-CHIP	680	5%	1/10W
R614		1-216-041-00	RES-CHIP	470	5%	1/10W
R615		1-216-369-00	METAL OXIDE	1	5%	2W
R616		1-260-302-51	CARBON	6.8	5%	1/2W
R617		1-247-791-91	CARBON	22	5%	1/4W
R619		1-260-128-11	CARBON	270K	5%	1/2W
R620	⚠	1-129-720-91	FILM	0.033UF	5.00%	630V
R621		1-215-864-00	METAL OXIDE	150	5%	1W
R623		1-216-095-00	RES-CHIP	82K	5%	1/10W
R624		1-216-089-91	RES-CHIP	47K	5%	1/10W
R626		1-216-049-11	RES-CHIP	1K	5%	1/10W
R627		1-240-251-11	CEMENTED	6.8	5%	10W
R629		1-247-747-11	CARBON	470	5%	1/2W
R630		1-249-429-11	CARBON	10K	5%	1/4W
R631		1-216-089-91	RES-CHIP	47K	5%	1/10W
R632		1-220-886-11	FUSIBLE	0.1	10%	1W
R634	⚠	1-240-917-91	METAL	8.2M	5%	1W
R635		1-216-492-21	METAL OXIDE	82K	5%	3W
R636		1-215-924-00	METAL OXIDE	15K	5%	3W
R637		1-216-492-21	METAL OXIDE	82K	5%	3W
R639		1-216-361-21	METAL OXIDE	0.22	5%	2W
R640		1-249-415-11	CARBON	680	5%	1/4W
R641		1-216-361-21	METAL OXIDE	0.22	5%	2W
R642		1-249-419-11	CARBON	1.5K	5%	1/4W
R643		1-247-843-11	CARBON	3.3K	5%	1/4W
R644		1-249-419-11	CARBON	1.5K	5%	1/4W
R646		1-215-924-00	METAL OXIDE	15K	5%	3W
R647		1-249-387-11	CARBON	3.3	5%	1/4W
R648		1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R649		1-249-417-11	CARBON	1K	5%	1/4W
R650		1-215-882-00	METAL OXIDE	22	5%	2W
R652		1-215-900-11	METAL OXIDE	22K	5%	2W
R653		1-215-873-00	METAL OXIDE	4.7K	5%	1W
R656		1-249-417-11	CARBON	1K	5%	1/4W
R657		1-260-127-11	CARBON	220K	5%	1/2W
R659		1-216-049-11	RES-CHIP	1K	5%	1/10W
R660		1-216-073-91	RES-CHIP	10K	5%	1/10W
R661		1-215-873-00	METAL OXIDE	4.7K	5%	1W
R682		1-533-597-41	LINK, IC			
R909		1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R910		1-216-065-91	RES-CHIP	4.7K	5%	1/10W

<RELAY>

RY600	⚠	1-755-299-11	RELAY, AC POWER			
RY601	⚠	1-755-299-11	RELAY, AC POWER			

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

A B1

REF NO.		PART NO.	DESCRIPTION			REMARK
			<SWITCH>			
S501		1-572-707-11	SWITCH, LEVER			
S502		1-572-707-11	SWITCH, LEVER			
			<TRANSFORMER>			
T501		1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE			
T503	⚠	1-453-284-11	TRANSFORMER ASSY FLY BACK (NX-4009//M314)			
T504		1-431-693-11	TRANSFORMER, HORIZONTAL LINEAR			
T505		1-426-981-11	TRANSFORMER, FERRITE (PMT)			
T601	⚠	1-433-743-11	TRANSFORMER, LINE FILTER			
T603	⚠	1-431-976-11	TRANSFORMER, CONVERTER (SRT)			
T604	⚠	1-431-852-11	TRANSFORMER, CONVERTER (SRT)			
			<THERMISTOR>			
TH600		1-803-586-11	THERMISTOR, NTC			
			<THERMISTOR>			
THP600	⚠	1-803-541-11	THERMISTOR			
			<TUNER>			
TU101		8-598-451-30	TUNER, FSS BTF-WG441			
			<VARISTOR>			
VDR600		1-803-830-11	VARISTOR (ERZV14D621)			
			<CRYSTAL>			
X001		1-781-174-21	VIBRATOR, CERAMIC			
X301		1-781-134-21	OSCILLATOR, CRYSTAL			
X302		1-781-132-21	VIBRATOR, CRYSTAL			

****

	*	A-1401-077-A	B1 BOARD MOUNTED			
			**********			
			<CAPACITOR>			
C1513		1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1514		1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1515		1-163-243-11	CERAMIC CHIP	47PF	5.00%	50V
C1517		1-164-005-11	CERAMIC CHIP	0.47UF		25V
C1518		1-126-967-11	ELECT	47UF	20.00%	50V
C1519		1-163-249-11	CERAMIC CHIP	82PF	5.00%	50V
C1520		1-163-249-11	CERAMIC CHIP	82PF	5.00%	50V
C1522		1-164-005-11	CERAMIC CHIP	0.47UF		25V
C1523		1-163-255-11	CERAMIC CHIP	150PF	5.00%	50V
C1524		1-163-247-91	CERAMIC CHIP	68PF	5.00%	50V
C1525		1-163-249-11	CERAMIC CHIP	82PF	5.00%	50V
C1526		1-163-249-11	CERAMIC CHIP	82PF	5.00%	50V
C1528		1-164-005-11	CERAMIC CHIP	0.47UF		25V
C1529		1-163-255-11	CERAMIC CHIP	150PF	5.00%	50V
C1530		1-163-247-91	CERAMIC CHIP	68PF	5.00%	50V

REF NO.		PART NO.	DESCRIPTION			REMARK
C1543		1-126-933-11	ELECT	100UF	20.00%	16V
C1544		1-165-319-11	CERAMIC CHIP	0.1UF		50V
C1554		1-165-319-11	CERAMIC CHIP	0.1UF		50V
C1555		1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1556		1-163-038-91	CERAMIC CHIP	0.1UF		25V
			<CONNECTOR>			
CN1501	*	1-564-511-11	PLUG, CONNECTOR 8P			
CN1502	*	1-564-508-11	PLUG, CONNECTOR 5P			
CN1503		1-764-811-11	CONNECTOR, BOARD TO BOARD 10P			
			<DIODE>			
D1501		8-719-158-35	RD9.1S-B			
			<IC>			
IC1502		8-759-439-64	HEF4053BT			
			<COIL>			
L1501		1-414-856-11	INDUCTOR	10UH		
L1506		1-414-857-11	INDUCTOR	100UH		
L1507		1-414-187-11	INDUCTOR	47UH		
L1508		1-414-187-11	INDUCTOR	47UH		
L1509		1-414-857-11	INDUCTOR	100UH		
L1510		1-414-187-11	INDUCTOR	47UH		
L1511		1-414-187-11	INDUCTOR	47UH		
			<TRANSISTOR>			
Q1501		8-729-010-25	MSD601-RT1			
Q1502		8-729-216-22	2SA1162-G			
Q1503		8-729-010-25	MSD601-RT1			
Q1504		8-729-010-25	MSD601-RT1			
Q1505		8-729-010-25	MSD601-RT1			
Q1506		8-729-010-25	MSD601-RT1			
Q1507		8-729-216-22	2SA1162-G			
Q1509		8-729-010-25	MSD601-RT1			
Q1510		8-729-010-25	MSD601-RT1			
Q1511		8-729-216-22	2SA1162-G			
Q1514		8-729-010-25	MSD601-RT1			
Q1515		8-729-010-25	MSD601-RT1			
Q1516		8-729-216-22	2SA1162-G			
Q1520		8-729-010-25	MSD601-RT1			
Q1522		8-729-010-25	MSD601-RT1			
Q1523		8-729-216-22	2SA1162-G			
			<RESISTOR>			
R1501		1-216-049-11	RES-CHIP	1K	5%	1/10W
R1502		1-216-049-11	RES-CHIP	1K	5%	1/10W
R1503		1-216-025-11	RES-CHIP	100	5%	1/10W
R1504		1-216-025-11	RES-CHIP	100	5%	1/10W
R1506		1-216-025-11	RES-CHIP	100	5%	1/10W
R1507		1-216-081-00	RES-CHIP	22K	5%	1/10W
R1508		1-216-073-91	RES-CHIP	10K	5%	1/10W
R1511		1-216-033-00	RES-CHIP	220	5%	1/10W
R1512		1-216-005-00	RES-CHIP	15	5%	1/10W
R1515		1-216-041-00	RES-CHIP	470	5%	1/10W

B10 B1

REF NO.	PART NO.	DESCRIPTION		REMARK	
R1516	1-216-025-11	RES-CHIP	100	5%	1/10W
R1517	1-216-075-00	RES-CHIP	12K	5%	1/10W
R1520	1-216-079-00	RES-CHIP	18K	5%	1/10W
R1522	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1523	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1528	1-216-033-00	RES-CHIP	220	5%	1/10W
R1529	1-216-053-00	RES-CHIP	1.5K	5%	1/10W
R1531	1-216-045-00	RES-CHIP	680	5%	1/10W
R1537	1-216-041-00	RES-CHIP	470	5%	1/10W
R1538	1-216-041-00	RES-CHIP	470	5%	1/10W
R1540	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1541	1-216-041-00	RES-CHIP	470	5%	1/10W
R1542	1-216-041-00	RES-CHIP	470	5%	1/10W
R1543	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1545	1-216-041-00	RES-CHIP	470	5%	1/10W
R1547	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1548	1-216-025-11	RES-CHIP	100	5%	1/10W
R1549	1-216-075-00	RES-CHIP	12K	5%	1/10W
R1551	1-216-081-00	RES-CHIP	22K	5%	1/10W
R1552	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1553	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1554	1-216-033-00	RES-CHIP	220	5%	1/10W
R1556	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1559	1-216-041-00	RES-CHIP	470	5%	1/10W
R1560	1-216-041-00	RES-CHIP	470	5%	1/10W
R1561	1-216-041-00	RES-CHIP	470	5%	1/10W
R1562	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1563	1-216-041-00	RES-CHIP	470	5%	1/10W
R1566	1-216-041-00	RES-CHIP	470	5%	1/10W
R1567	1-216-049-11	RES-CHIP	1K	5%	1/10W
R1568	1-216-041-00	RES-CHIP	470	5%	1/10W
R1569	1-216-049-11	RES-CHIP	1K	5%	1/10W

****

*	A-1300-556-A	B10 BOARD COMPLETE			
		**********			
	4-382-854-11	SCREW (M3X10), P, SW (+)			
		<CAPACITOR>			
C1305	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1307	1-164-346-11	CERAMIC CHIP	1UF		16V
C1310	1-126-947-11	ELECT	47UF	20.00%	16V
C1312	1-126-947-11	ELECT	47UF	20.00%	16V
C1330	1-126-964-11	ELECT	10UF	20.00%	50V
C1333	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1395	1-163-249-11	CERAMIC CHIP	82PF	5.00%	50V
C1396	1-125-889-91	CERAMIC CHIP	2.2UF	10%	10V
C1401	1-104-661-91	ELECT	330UF	20.00%	16V
C1402	1-126-947-11	ELECT	47UF	20.00%	25V
C1403	1-126-947-11	ELECT	47UF	20.00%	25V
C1404	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C1405	1-126-947-11	ELECT	47UF	20.00%	25V
C1406	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C1408	1-126-964-11	ELECT	10UF	20.00%	50V
C1410	1-126-947-11	ELECT	47UF	20.00%	25V
C1411	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C1413	1-126-935-11	ELECT	470UF	20.00%	16V
C1414	1-164-346-11	CERAMIC CHIP	1UF		16V
C1415	1-126-947-11	ELECT	47UF	20.00%	25V

REF NO.	PART NO.	DESCRIPTION		REMARK	
C1416	1-164-346-11	CERAMIC CHIP	1UF		16V
C1418	1-163-031-91	CERAMIC CHIP	0.01UF		50V
C1419	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C1421	1-164-346-11	CERAMIC CHIP	1UF		16V
C1422	1-164-346-11	CERAMIC CHIP	1UF		16V
C1423	1-164-346-11	CERAMIC CHIP	1UF		16V
C1425	1-164-346-11	CERAMIC CHIP	1UF		16V
C1426	1-164-346-11	CERAMIC CHIP	1UF		16V
C1428	1-104-665-11	ELECT	100UF	20.00%	25V
C1429	1-104-663-11	ELECT	33UF	20.00%	25V
C1431	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1432	1-126-933-11	ELECT	100UF	20.00%	16V
C1433	1-126-947-11	ELECT	47UF	20.00%	16V
C1434	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1435	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1436	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C1439	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1440	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1441	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1442	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1443	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1444	1-164-005-11	CERAMIC CHIP	0.47UF		25V
C1445	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1446	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1447	1-126-964-11	ELECT	10UF	20.00%	50V
C1448	1-164-005-11	CERAMIC CHIP	0.47UF		25V
C1449	1-126-933-11	ELECT	100UF	20.00%	16V
C1457	1-164-346-11	CERAMIC CHIP	1UF		16V
C1459	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1460	1-163-133-00	CERAMIC CHIP	470PF	5.00%	50V
C1461	1-164-346-11	CERAMIC CHIP	1UF		16V
C1462	1-164-346-11	CERAMIC CHIP	1UF		16V
C1464	1-126-933-11	ELECT	100UF	20.00%	16V
C3201	1-126-964-11	ELECT	10UF	20.00%	50V
C3202	1-136-171-00	FILM	0.33UF	5.00%	50V
C3203	1-115-339-11	CERAMIC CHIP	0.1UF	10.00%	50V
C3220	1-163-037-11	CERAMIC CHIP	0.022UF	10.00%	50V
C3221	1-163-037-11	CERAMIC CHIP	0.022UF	10.00%	50V
C3222	1-163-037-11	CERAMIC CHIP	0.022UF	10.00%	50V
C3223	1-163-037-11	CERAMIC CHIP	0.022UF	10.00%	50V
C3224	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C3225	1-163-038-91	CERAMIC CHIP	0.1UF		25V
C3226	1-126-964-11	ELECT	10UF	20.00%	50V
C3227	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C3228	1-107-698-11	ELECT	10UF	20.00%	25V
C3229	1-107-698-11	ELECT	10UF	20.00%	25V
C3238	1-164-005-11	CERAMIC CHIP	0.47UF		25V
C3239	1-136-171-00	FILM	0.33UF	5.00%	50V
C3243	1-163-989-11	CERAMIC CHIP	0.033UF	10.00%	25V
C3244	1-164-346-11	CERAMIC CHIP	1UF		16V
C3245	1-164-005-11	CERAMIC CHIP	0.47UF		25V
C3246	1-163-243-11	CERAMIC CHIP	47PF	5.00%	50V
C3247	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3248	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C3249	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C3250	1-164-346-11	CERAMIC CHIP	1UF		16V
C3251	1-126-964-11	ELECT	10UF	20.00%	50V
C3252	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C3253	1-126-933-11	ELECT	100UF	20.00%	16V
C3254	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C3255	1-163-243-11	CERAMIC CHIP	47PF	5.00%	50V
C3256	1-126-963-11	ELECT	4.7UF	20.00%	50V

B10

REF NO.	PART NO.	DESCRIPTION		REMARK	
C3257	1-164-346-11	CERAMIC CHIP	1UF		16V
C3258	1-163-989-11	CERAMIC CHIP	0.033UF	10.00%	25V
C3259	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3260	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C3262	1-126-947-11	ELECT	47UF	20.00%	16V
C3264	1-163-251-11	CERAMIC CHIP	100PF	5.00%	50V
C3301	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3302	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3303	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3304	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3305	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3306	1-117-720-11	CERAMIC CHIP	4.7UF		10V
C3307	1-104-665-11	ELECT	100UF	20.00%	25V
C3308	1-115-339-11	CERAMIC CHIP	0.1UF	10.00%	50V
C3309	1-104-760-11	CERAMIC CHIP	0.047UF	10.00%	50V
C3310	1-104-760-11	CERAMIC CHIP	0.047UF	10.00%	50V
C3311	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C3312	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C3313	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V
C3314	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C3315	1-164-182-11	CERAMIC CHIP	0.0033UF	10.00%	50V
C3316	1-115-185-11	CERAMIC CHIP	0.033UF	10.00%	50V
C3317	1-163-009-91	CERAMIC CHIP	0.001UF	10.00%	50V
C3318	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C3319	1-110-501-11	CERAMIC CHIP	0.33UF	10.00%	16V
C3320	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3321	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3322	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3323	1-115-339-11	CERAMIC CHIP	0.1UF	10.00%	50V
C3324	1-126-964-11	ELECT	10UF	20.00%	50V
C3325	1-104-665-11	ELECT	100UF	20.00%	25V
C3326	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3327	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3328	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3329	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3330	1-126-963-11	ELECT	4.7UF	20.00%	50V
C3331	1-164-489-11	CERAMIC CHIP	0.22UF	10.00%	16V
C3332	1-163-009-91	CERAMIC CHIP	0.001UF	10.00%	50V
C3333	1-115-185-11	CERAMIC CHIP	0.033UF	10.00%	50V
C3334	1-164-182-11	CERAMIC CHIP	0.0033UF	10.00%	50V
C3335	1-163-019-00	CERAMIC CHIP	0.0068UF	10.00%	50V
C3336	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V
C3337	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V
C3338	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C6200	1-216-295-91	SHORT CHIP	0		
C6202	1-128-550-11	ELECT	2200UF	20.00%	50V
C6203	1-163-021-91	CERAMIC CHIP	0.01UF	10.00%	50V
C6204	1-128-550-11	ELECT	2200UF	20.00%	50V
C6205	1-130-495-00	MYLAR	0.1UF	5.00%	50V
C6206	1-128-550-11	ELECT	2200UF	20.00%	50V
C6209	1-130-495-00	MYLAR	0.1UF	5.00%	50V
C6210	1-126-924-11	ELECT	330UF	20.00%	10V
C6211	1-126-924-11	ELECT	330UF	20.00%	10V
C6212	1-126-947-11	ELECT	47UF	20.00%	25V
C6213	1-126-964-11	ELECT	10UF	20.00%	50V
C6217	1-164-004-11	CERAMIC CHIP	0.1UF	10.00%	25V
C6220	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C6222	1-164-505-11	CERAMIC CHIP	2.2UF		16V
C6223	1-126-960-11	ELECT	1UF	20.00%	50V
C6241	1-126-964-11	ELECT	10UF	20.00%	50V
C6244	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00%	50V

REF NO.		PART NO.	DESCRIPTION	REMARK
C6245		1-163-017-00	CERAMIC CHIP	0.0047UF 10.00% 50V
C6249		1-216-295-91	SHORT CHIP	0
			<CONNECTOR>	
CN1300	*	1-564-506-11	PLUG, CONNECTOR 3P	
CN1400	*	1-564-512-11	PLUG, CONNECTOR 9P	
CN1401	*	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P	
CN1403	*	1-564-506-11	PLUG, CONNECTOR 3P	
CN1405	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P	
CN1406	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P	
CN1407	*	1-779-891-11	CONNECTOR, BOARD TO BOARD 8P	
CN1409		1-764-818-11	CONNECTOR, BOARD TO BOARD 10P	
CN6200	*	1-564-507-11	PLUG, CONNECTOR 4P	
CN6204	*	1-564-509-11	PLUG, CONNECTOR 6P	
CN6206	*	1-564-508-11	PLUG, CONNECTOR 5P	
			<DIODE>	
D1401		8-719-069-60	UDZSTE-179.1B	
D1402		8-719-069-60	UDZSTE-179.1B	
D1403		8-719-069-60	UDZSTE-179.1B	
D1404		8-719-069-60	UDZSTE-179.1B	
D1405		8-719-069-60	UDZSTE-179.1B	
D1406		8-719-069-60	UDZSTE-179.1B	
D1407		8-719-069-60	UDZSTE-179.1B	
D1408		8-719-069-60	UDZSTE-179.1B	
D1409		8-719-069-60	UDZSTE-179.1B	
D1410		8-719-069-60	UDZSTE-179.1B	
D1411		8-719-069-60	UDZSTE-179.1B	
D1412		8-719-069-60	UDZSTE-179.1B	
D1415		8-719-069-60	UDZSTE-179.1B	
D1416		8-719-069-60	UDZSTE-179.1B	
D1418		8-719-069-60	UDZSTE-179.1B	
D3201		8-719-988-61	1SS355TE-17	
D3203		8-719-988-61	1SS355TE-17	
D3301		8-719-404-50	MA111-TX	
D3302		8-719-404-50	MA111-TX	
D6210		8-719-914-42	DA204K	
D6211		8-719-404-50	MA111-TX	
D6212		8-719-404-50	MA111-TX	
			<IC>	
IC1401		8-752-068-46	CXA1855S	
IC1402		8-759-100-96	UPC4558G2	
IC1404		8-759-701-59	NJM78M09FA	
IC3200		8-759-100-96	UPC4558G2	
IC3202		8-759-100-96	UPC4558G2	
IC3204		8-759-100-96	UPC4558G2	
IC3205		8-752-058-68	CXA1315M	
IC3301		8-759-711-10	NJU4066BM	
IC3302		6-702-145-01	IC NJW1139GK1-TE2	
IC6200		8-759-168-24	TA8200AH	
			<JACK>	
J1401		1-784-646-11	TERMINAL, S	
J1402		1-778-387-11	JACK BLOCK, PIN 12P	

B10

REF NO.	PART NO.	DESCRIPTION		REMARK
		<CHIP CONDUCTOR>		
JR1301	1-216-295-91	SHORT CHIP	0	
JR1405	1-216-295-91	SHORT CHIP	0	
JR1406	1-216-295-91	SHORT CHIP	0	
JR1407	1-216-295-91	SHORT CHIP	0	
JR1409	1-216-295-91	SHORT CHIP	0	
JR1410	1-216-295-91	SHORT CHIP	0	
JR1411	1-216-295-91	SHORT CHIP	0	
JR3204	1-216-295-91	SHORT CHIP	0	
JR3209	1-216-295-91	SHORT CHIP	0	
JR6200	1-216-295-91	SHORT CHIP	0	
JR6202	1-216-295-91	SHORT CHIP	0	
JR6203	1-216-295-91	SHORT CHIP	0	
JR6204	1-216-295-91	SHORT CHIP	0	
JR6206	1-216-295-91	SHORT CHIP	0	
		<COIL>		
L1313	1-414-187-11	INDUCTOR	47UH	
L1314	1-414-856-11	INDUCTOR	10UH	
L1315	1-414-856-11	INDUCTOR	10UH	
L1317	1-414-856-11	INDUCTOR	10UH	
L1404	1-406-665-11	INDUCTOR	100UH	
L3202	1-414-856-11	INDUCTOR	10UH	
		<TRANSISTOR>		
Q1316	8-729-216-22	2SA1162-G		
Q1317	8-729-230-49	2SC2712-YG		
Q1318	8-729-230-49	2SC2712-YG		
Q1323	8-729-230-49	2SC2712-YG		
Q1324	8-729-230-49	2SC2712-YG		
Q1365	8-729-230-49	2SC2712-YG		
Q1372	8-729-230-49	2SC2712-YG		
Q1402	8-729-216-22	2SA1162-G		
Q1403	8-729-230-49	2SC2712-YG		
Q1404	8-729-230-49	2SC2712-YG		
Q1408	8-729-230-49	2SC2712-YG		
Q1409	8-729-230-49	2SC2712-YG		
Q3201	8-729-224-62	2SK246-GR		
Q3202	8-729-230-49	2SC2712-YG		
Q3203	8-729-230-49	2SC2712-YG		
Q3204	8-729-224-62	2SK246-GR		
Q6201	8-729-421-19	UN2213		
Q6203	8-729-421-19	UN2213		
Q6204	8-729-421-19	UN2213		
Q6208	8-729-421-19	UN2213		
		<RESISTOR>		
R1301	1-216-041-00	RES-CHIP	470	5% 1/10W
R1318	1-216-033-00	RES-CHIP	220	5% 1/10W
R1320	1-216-081-00	RES-CHIP	22K	5% 1/10W
R1343	1-216-049-11	RES-CHIP	1K	5% 1/10W
R1344	1-216-025-11	RES-CHIP	100	5% 1/10W
R1345	1-216-041-00	RES-CHIP	470	5% 1/10W
R1346	1-216-041-00	RES-CHIP	470	5% 1/10W
R1347	1-216-025-11	RES-CHIP	100	5% 1/10W
R1350	1-216-085-91	RES-CHIP	33K	5% 1/10W
R1359	1-216-025-11	RES-CHIP	100	5% 1/10W
R1360	1-216-041-00	RES-CHIP	470	5% 1/10W
R1361	1-216-041-00	RES-CHIP	470	5% 1/10W
R1362	1-216-055-00	RES-CHIP	1.8K	5% 1/10W
R1363	1-216-033-00	RES-CHIP	220	5% 1/10W
R1364	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1365	1-216-081-00	RES-CHIP	22K	5% 1/10W
R1366	1-216-295-91	SHORT CHIP	0	
R1368	1-216-049-11	RES-CHIP	1K	5% 1/10W
R1369	1-216-025-11	RES-CHIP	100	5% 1/10W
R1370	1-216-041-00	RES-CHIP	470	5% 1/10W
R1371	1-216-039-00	RES-CHIP	390	5% 1/10W
R1372	1-216-041-00	RES-CHIP	470	5% 1/10W
R1397	1-216-045-00	RES-CHIP	680	5% 1/10W
R1400	1-216-105-91	RES-CHIP	220K	5% 1/10W
R1403	1-216-033-00	RES-CHIP	220	5% 1/10W
R1404	1-216-295-91	SHORT CHIP	0	
R1406	1-216-013-00	RES-CHIP	33	5% 1/10W
R1407	1-216-033-00	RES-CHIP	220	5% 1/10W
R1408	1-216-031-00	RES-CHIP	180	5% 1/10W
R1409	1-216-105-91	RES-CHIP	220K	5% 1/10W
R1410	1-216-105-91	RES-CHIP	220K	5% 1/10W
R1411	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1412	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1413	1-216-105-91	RES-CHIP	220K	5% 1/10W
R1414	1-216-025-11	RES-CHIP	100	5% 1/10W
R1417	1-216-025-11	RES-CHIP	100	5% 1/10W
R1418	1-216-025-11	RES-CHIP	100	5% 1/10W
R1421	1-216-057-00	RES-CHIP	2.2K	5% 1/10W
R1424	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1425	1-216-047-91	RES-CHIP	820	5% 1/10W
R1426	1-216-025-11	RES-CHIP	100	5% 1/10W
R1427	1-216-063-91	RES-CHIP	3.9K	5% 1/10W
R1428	1-216-025-11	RES-CHIP	100	5% 1/10W
R1429	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1430	1-216-025-11	RES-CHIP	100	5% 1/10W
R1431	1-216-025-11	RES-CHIP	100	5% 1/10W
R1432	1-216-041-00	RES-CHIP	470	5% 1/10W
R1433	1-216-025-11	RES-CHIP	100	5% 1/10W
R1435	1-216-022-00	RES-CHIP	75	5% 1/10W
R1436	1-216-025-11	RES-CHIP	100	5% 1/10W
R1437	1-216-022-00	RES-CHIP	75	5% 1/10W
R1438	1-216-025-11	RES-CHIP	100	5% 1/10W
R1439	1-216-017-91	RES-CHIP	47	5% 1/10W
R1441	1-216-025-11	RES-CHIP	100	5% 1/10W
R1442	1-216-049-11	RES-CHIP	1K	5% 1/10W
R1443	1-216-049-11	RES-CHIP	1K	5% 1/10W
R1444	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1445	1-216-025-11	RES-CHIP	100	5% 1/10W
R1446	1-216-105-91	RES-CHIP	220K	5% 1/10W
R1447	1-216-025-11	RES-CHIP	100	5% 1/10W
R1448	1-216-043-91	RES-CHIP	560	5% 1/10W
R1449	1-249-429-11	CARBON	10K	5% 1/4W
R1450	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1451	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1452	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1453	1-216-025-11	RES-CHIP	100	5% 1/10W
R1454	1-216-089-91	RES-CHIP	47K	5% 1/10W
R1455	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1456	1-216-113-00	RES-CHIP	470K	5% 1/10W
R1457	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1458	1-216-073-91	RES-CHIP	10K	5% 1/10W
R1459	1-216-025-11	RES-CHIP	100	5% 1/10W
R1460	1-216-033-00	RES-CHIP	220	5% 1/10W

B10

REF NO.	PART NO.	DESCRIPTION		REMARK	
R1461	1-216-025-11	RES-CHIP	100	5%	1/10W
R1463	1-249-429-11	CARBON	10K	5%	1/4W
R1464	1-216-113-00	RES-CHIP	470K	5%	1/10W
R1465	1-216-113-00	RES-CHIP	470K	5%	1/10W
R1466	1-216-033-00	RES-CHIP	220	5%	1/10W
R1467	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R1468	1-216-093-91	RES-CHIP	68K	5%	1/10W
R1469	1-216-105-91	RES-CHIP	220K	5%	1/10W
R1470	1-216-105-91	RES-CHIP	220K	5%	1/10W
R1471	1-216-022-00	RES-CHIP	75	5%	1/10W
R1472	1-216-033-00	RES-CHIP	220	5%	1/10W
R1473	1-216-033-00	RES-CHIP	220	5%	1/10W
R1475	1-216-089-91	RES-CHIP	47K	5%	1/10W
R1476	1-216-089-91	RES-CHIP	47K	5%	1/10W
R1477	1-216-047-91	RES-CHIP	820	5%	1/10W
R1478	1-216-051-00	RES-CHIP	1.2K	5%	1/10W
R1479	1-216-105-91	RES-CHIP	220K	5%	1/10W
R1480	1-216-105-91	RES-CHIP	220K	5%	1/10W
R1481	1-216-022-00	RES-CHIP	75	5%	1/10W
R1483	1-216-025-11	RES-CHIP	100	5%	1/10W
R1484	1-216-025-11	RES-CHIP	100	5%	1/10W
R1485	1-216-025-11	RES-CHIP	100	5%	1/10W
R1486	1-216-067-00	RES-CHIP	5.6K	5%	1/10W
R1487	1-216-073-91	RES-CHIP	10K	5%	1/10W
R1488	1-216-073-91	RES-CHIP	10K	5%	1/10W
R1489	1-216-022-00	RES-CHIP	75	5%	1/10W
R1490	1-216-025-11	RES-CHIP	100	5%	1/10W
R1491	1-216-025-11	RES-CHIP	100	5%	1/10W
R1492	1-216-021-00	RES-CHIP	68	5%	1/10W
R1493	1-216-067-00	RES-CHIP	5.6K	5%	1/10W
R1496	1-216-041-00	RES-CHIP	470	5%	1/10W
R1497	1-216-041-00	RES-CHIP	470	5%	1/10W
R1498	1-216-025-11	RES-CHIP	100	5%	1/10W
R1499	1-216-025-11	RES-CHIP	100	5%	1/10W
R1500	1-216-025-11	RES-CHIP	100	5%	1/10W
R1501	1-216-045-00	RES-CHIP	680	5%	1/10W
R1503	1-216-073-91	RES-CHIP	10K	5%	1/10W
R1504	1-216-073-91	RES-CHIP	10K	5%	1/10W
R1505	1-216-022-00	RES-CHIP	75	5%	1/10W
R1506	1-216-033-00	RES-CHIP	220	5%	1/10W
R1507	1-216-025-11	RES-CHIP	100	5%	1/10W
R3200	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3201	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3202	1-216-097-11	RES-CHIP	100K	5%	1/10W
R3203	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3204	1-216-061-91	RES-CHIP	3.3K	5%	1/10W
R3205	1-216-069-00	RES-CHIP	6.8K	5%	1/10W
R3206	1-216-039-00	RES-CHIP	390	5%	1/10W
R3207	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3219	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3220	1-216-097-11	RES-CHIP	100K	5%	1/10W
R3221	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3222	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3223	1-216-045-00	RES-CHIP	680	5%	1/10W
R3224	1-216-101-00	RES-CHIP	150K	5%	1/10W
R3229	1-216-025-11	RES-CHIP	100	5%	1/10W
R3230	1-216-025-11	RES-CHIP	100	5%	1/10W
R3231	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3232	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3233	1-216-069-00	RES-CHIP	6.8K	5%	1/10W
R3234	1-216-039-00	RES-CHIP	390	5%	1/10W
R3235	1-216-101-00	RES-CHIP	150K	5%	1/10W

REF NO.	PART NO.	DESCRIPTION		REMARK	
R3236	1-216-113-00	RES-CHIP	470K	5%	1/10W
R3237	1-216-045-00	RES-CHIP	680	5%	1/10W
R3238	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3239	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3240	1-216-081-00	RES-CHIP	22K	5%	1/10W
R3241	1-216-093-91	RES-CHIP	68K	5%	1/10W
R3242	1-216-081-00	RES-CHIP	22K	5%	1/10W
R3245	1-216-097-11	RES-CHIP	100K	5%	1/10W
R3246	1-216-045-00	RES-CHIP	680	5%	1/10W
R3251	1-216-101-00	RES-CHIP	150K	5%	1/10W
R3252	1-216-113-00	RES-CHIP	470K	5%	1/10W
R3253	1-216-045-00	RES-CHIP	680	5%	1/10W
R3254	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3255	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3256	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3257	1-216-097-11	RES-CHIP	100K	5%	1/10W
R3258	1-216-121-11	RES-CHIP	1M	5%	1/10W
R3259	1-216-061-91	RES-CHIP	3.3K	5%	1/10W
R3262	1-216-101-00	RES-CHIP	150K	5%	1/10W
R3263	1-216-093-91	RES-CHIP	68K	5%	1/10W
R3267	1-216-049-11	RES-CHIP	1K	5%	1/10W
R3268	1-216-049-11	RES-CHIP	1K	5%	1/10W
R3269	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R3271	1-216-063-91	RES-CHIP	3.9K	5%	1/10W
R3273	1-216-057-00	RES-CHIP	2.2K	5%	1/10W
R3274	1-216-063-91	RES-CHIP	3.9K	5%	1/10W
R3301	1-216-079-00	RES-CHIP	18K	5%	1/10W
R3302	1-216-081-00	RES-CHIP	22K	5%	1/10W
R3303	1-216-079-00	RES-CHIP	18K	5%	1/10W
R3304	1-216-077-91	RES-CHIP	15K	5%	1/10W
R3305	1-216-077-91	RES-CHIP	15K	5%	1/10W
R3306	1-216-081-00	RES-CHIP	22K	5%	1/10W
R3307	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3308	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3309	1-216-025-11	RES-CHIP	100	5%	1/10W
R3310	1-216-025-11	RES-CHIP	100	5%	1/10W
R3311	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3312	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3313	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3314	1-216-073-91	RES-CHIP	10K	5%	1/10W
R3315	1-216-295-91	SHORT CHIP	0		
R3318	1-216-295-91	SHORT CHIP	0		
R6201	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R6202	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R6203	1-216-295-91	SHORT CHIP	0		
R6209	1-216-049-11	RES-CHIP	1K	5%	1/10W
R6213	1-216-073-91	RES-CHIP	10K	5%	1/10W
R6214	1-216-073-91	RES-CHIP	10K	5%	1/10W
R6219	1-216-089-91	RES-CHIP	47K	5%	1/10W
R6245	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R6246	1-216-065-91	RES-CHIP	4.7K	5%	1/10W
R6254	1-216-021-00	RES-CHIP	68	5%	1/10W
R6255	1-216-308-00	RES-CHIP	4.7	5%	1/10W
R6258	1-216-021-00	RES-CHIP	68	5%	1/10W
R6259	1-216-308-00	RES-CHIP	4.7	5%	1/10W
R6278	1-216-295-91	SHORT CHIP	0		

****

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

C6

REF NO.		PART NO.	DESCRIPTION			REMARK
	*	A-1401-078-A	C6 BOARD MOUNTED **********			
		4-382-854-11	SCREW (M3X10), P, SW (+)			
			<CAPACITOR>			
C701		1-115-350-51	CERAMIC	0.0047UF	2KV	
C702		1-102-074-00	CERAMIC	0.001UF	10.00% 50V	
C708		1-102-114-00	CERAMIC	470PF	10.00% 50V	
C709		1-102-114-00	CERAMIC	470PF	10.00% 50V	
C710		1-102-114-00	CERAMIC	470PF	10.00% 50V	
C712		1-102-115-00	CERAMIC	560PF	10.00% 50V	
C713		1-102-112-00	CERAMIC	330PF	10.00% 50V	
C714		1-102-112-00	CERAMIC	330PF	10.00% 50V	
C716		1-126-933-11	ELECT	100UF	20.00% 16V	
C717		1-107-651-11	ELECT	4.7UF	20.00% 250V	
C718		1-102-106-00	CERAMIC	100PF	10.00% 50V	
C1800		1-126-964-11	ELECT	10UF	20.00% 50V	
C1803		1-126-964-11	ELECT	10UF	20.00% 50V	
C1804		1-126-964-11	ELECT	10UF	20.00% 50V	
C1809		1-126-942-61	ELECT	1000UF	20.00% 25V	
C1810		1-102-106-00	CERAMIC	100PF	10.00% 50V	
			<CONNECTOR>			
CN700		1-695-915-11	TAB (CONTACT)			
CN702		1-695-915-11	TAB (CONTACT)			
CN703		1-564-509-11	PLUG, CONNECTOR 6P			
CN704		1-695-915-11	TAB (CONTACT)			
CN712		1-564-507-11	PLUG, CONNECTOR 4P			
CN1801	*	1-564-509-11	PLUG, CONNECTOR 6P			
CN1802		1-564-506-11	PLUG, CONNECTOR 3P			
			<DIODE>			
D701		8-719-991-33	1SS133T-77			
D702		8-719-991-33	1SS133T-77			
D703		8-719-991-33	1SS133T-77			
D704		8-719-991-33	1SS133T-77			
D705		8-719-991-33	1SS133T-77			
D706		8-719-991-33	1SS133T-77			
D707		8-719-991-33	1SS133T-77			
D708		8-719-991-33	1SS133T-77			
D709		8-719-991-33	1SS133T-77			
D710		8-719-991-33	1SS133T-77			
D711		8-719-991-33	1SS133T-77			
D712		8-719-991-33	1SS133T-77			
D716		8-719-991-33	1SS133T-77			
D717		8-719-070-16	NNCD9.1A-T1			
D1803		8-719-991-33	1SS133T-77			
D1804		8-719-991-33	1SS133T-77			
D1808		8-719-908-03	GP08D			
			<IC>			
IC1800		8-759-822-38	LA6510			
			<JACK>			
J701	⚠	1-540-071-22	SOCKET, CRT			

REF NO.	PART NO.	DESCRIPTION				REMARK
		<COIL>				
L701	1-410-667-31	INDUCTOR	22UH			
L703	1-414-186-31	INDUCTOR	33UH			
L705	1-414-186-31	INDUCTOR	33UH			
L707	1-414-187-11	INDUCTOR	47UH			
		<TRANSISTOR>				
Q701	8-729-326-11	2SC2611				
Q702	8-729-326-11	2SC2611				
Q703	8-729-326-11	2SC2611				
Q704	8-729-326-11	2SC2611				
Q705	8-729-326-11	2SC2611				
Q706	8-729-326-11	2SC2611				
Q707	8-729-200-17	2SA1091-O				
Q708	8-729-200-17	2SA1091-O				
Q709	8-729-200-17	2SA1091-O				
Q710	8-729-230-45	2SC2458-YGR				
Q711	8-729-230-45	2SC2458-YGR				
Q712	8-729-230-45	2SC2458-YGR				
Q714	8-729-255-12	2SC2551-O				
Q1800	8-729-119-76	2SA1175-HFE				
Q1802	8-729-230-45	2SC2458-YGR				
		<RESISTOR>				
R701	1-219-752-11	CARBON	100K	5%	1/2W	
R705	1-216-392-11	METAL OXIDE	1.8	5%	3W	
R710	1-215-923-00	METAL OXIDE	10K	5%	3W	
R711	1-260-328-11	CARBON	1K	5%	1/2W	
R712	1-215-923-00	METAL OXIDE	10K	5%	3W	
R713	1-260-330-11	CARBON	1.5K	5%	1/2W	
R714	1-215-923-00	METAL OXIDE	10K	5%	3W	
R715	1-260-330-11	CARBON	1.5K	5%	1/2W	
R716	1-249-405-11	CARBON	100	5%	1/4W	
R717	1-249-405-11	CARBON	100	5%	1/4W	
R718	1-249-405-11	CARBON	100	5%	1/4W	
R719	1-215-469-00	METAL	100K	1%	1/4W	
R720	1-249-923-11	CARBON	1K	5%	1/4W	
R722	1-249-923-11	CARBON	1K	5%	1/4W	
R723	1-215-469-00	METAL	100K	1%	1/4W	
R724	1-249-923-11	CARBON	1K	5%	1/4W	
R725	1-249-424-11	CARBON	3.9K	5%	1/4W	
R726	1-249-424-11	CARBON	3.9K	5%	1/4W	
R727	1-249-424-11	CARBON	3.9K	5%	1/4W	
R728	1-249-408-11	CARBON	180	5%	1/4W	
R729	1-249-408-11	CARBON	180	5%	1/4W	
R730	1-249-408-11	CARBON	180	5%	1/4W	
R731	1-249-401-11	CARBON	47	5%	1/4W	
R732	1-249-401-11	CARBON	47	5%	1/4W	
R733	1-249-401-11	CARBON	47	5%	1/4W	
R734	1-219-743-11	CARBON	100	5%	1/2W	
R738	1-247-807-31	CARBON	100	5%	1/4W	
R739	1-247-807-31	CARBON	100	5%	1/4W	
R740	1-247-807-31	CARBON	100	5%	1/4W	
R747	1-215-926-00	METAL OXIDE	33K	5%	3W	
R749	1-215-927-00	METAL OXIDE	47K	5%	3W	
R751	1-215-926-00	METAL OXIDE	33K	5%	3W	
R753	1-249-429-11	CARBON	10K	5%	1/4W	
R755	1-249-427-11	CARBON	6.8K	5%	1/4W	
R756	1-249-427-11	CARBON	6.8K	5%	1/4W	

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

C6 D3 F

REF NO.	PART NO.	DESCRIPTION		REMARK	
R757	1-249-427-11	CARBON	6.8K	5%	1/4W
R758	1-249-419-11	CARBON	1.5K	5%	1/4W
R759	1-249-419-11	CARBON	1.5K	5%	1/4W
R760	1-249-419-11	CARBON	1.5K	5%	1/4W
R1800	1-249-417-11	CARBON	1K	5%	1/4W
R1801	1-249-426-11	CARBON	5.6K	5%	1/4W
R1802	1-249-382-11	CARBON	1.2	5%	1/4W
R1803	1-249-382-11	CARBON	1.2	5%	1/4W
R1805	1-249-429-11	CARBON	10K	5%	1/4W
R1806	1-249-425-11	CARBON	4.7K	5%	1/4W
R1808	1-249-425-11	CARBON	4.7K	5%	1/4W
R1809	1-249-435-11	CARBON	33K	5%	1/4W
R1810	1-249-435-11	CARBON	33K	5%	1/4W
R1811	1-249-433-11	CARBON	22K	5%	1/4W
R1812	1-249-435-11	CARBON	33K	5%	1/4W
R1821	1-249-433-11	CARBON	22K	5%	1/4W
R1822	1-249-435-11	CARBON	33K	5%	1/4W
R1823	1-249-426-11	CARBON	5.6K	5%	1/4W
R1824	1-249-435-11	CARBON	33K	5%	1/4W
R1825	1-247-843-11	CARBON	3.3K	5%	1/4W
		<VARIABLE RESISTOR>			
RV702	1-241-656-11	RES, ADJ, METAL FILM 110M			
RV1801	1-238-019-11	RES, ADJ, CARBON 47K			

****

* A-1401-079-A D3 BOARD MOUNTED
****

<CAPACITOR>

C2800	1-126-947-11	ELECT	47UF	20.00%	25V
C2801	1-106-220-00	MYLAR	0.1UF	10.00%	100V
C2802	1-137-350-11	MYLAR	0.015UF	5.00%	50V
C2803	1-129-723-00	FILM	0.056UF	5.00%	630V
C2805	1-126-947-11	ELECT	47UF	20.00%	25V
C2806	1-106-383-00	MYLAR	0.047UF	5.00%	100V
C2807	1-137-194-81	FILM	0.47UF	5.00%	50V
C2808	1-126-964-11	ELECT	10UF	20.00%	50V
C2809	1-137-194-81	FILM	0.47UF	5.00%	50V
C2810	1-106-375-12	MYLAR	0.022UF	10.00%	250V
C2811	1-126-964-11	ELECT	10UF	20.00%	50V
C2812	1-126-964-11	ELECT	10UF	20.00%	50V
C2813	1-129-708-91	FILM	0.0033UF	5.00%	630V

<CONNECTOR>

CN2800	* 1-564-510-11	PLUG, CONNECTOR 7P	
CN2802	1-564-506-11	PLUG, CONNECTOR 3P	
CN2803	1-695-915-11	TAB (CONTACT)	

<DIODE>

D2800	8-719-075-05	DIODE FR104-A5
D2801	8-719-911-19	1SS119-25
D2802	8-719-911-19	ISS119-25
D2803	8-719-911-19	ISS119-25

REF NO.	PART NO.	DESCRIPTION		REMARK	
		<IC>			
IC2800	8-759-701-59	NJM78M09FA			
IC2801	8-759-998-98	LM358D			
		<COIL>			
L2800	1-406-989-71	COIL, CHOKE	10MMH		
L2802	1-406-987-71	COIL, CHOKE	4.7MMH		
L2803	1-406-986-71	COIL, CHOKE	3.3MMH		
L2804	1-406-678-11	COIL, CHOKE	15MMH		
		<TRANSISTOR>			
Q2800	8-729-119-78	2SC2785-HFE			
Q2801	8-729-195-82	2SC2958			
Q2802	8-729-017-06	2SC4793			
Q2803	8-729-216-22	2SA1162-G			
Q2804	8-729-010-25	MSD601-RT1			
		<RESISTOR>			
R2800	1-249-405-11	CARBON	100	5%	1/4W
R2802	1-260-111-11	CARBON	10K	5%	1/2W
R2803	1-216-111-11	CARBON	10K	5%	1/2W
R2804	1-216-061-91	RES-CHIP	3.3K	5%	1/10W
R2805	1-216-097-11	RES-CHIP	100K	5%	1/10W
R2806	1-249-421-11	CARBON	2.2K	5%	1/4W
R2807	1-249-420-11	CARBON	1.8K	5%	1/4W
R2808	1-215-857-11	METAL OXIDE	10	5%	1W
R2809	1-216-059-00	RES-CHIP	2.7K	5%	1/10W
R2810	1-216-049-11	RES-CHIP	1K	5%	1/10W
R2811	1-216-069-00	RES-CHIP	6.8K	5%	1/10W
R2812	1-216-081-00	RES-CHIP	22K	5%	1/10W
R2813	1-216-059-00	RES-CHIP	2.7K	5%	1/10W
R2814	1-216-121-11	RES-CHIP	1M	5%	1/10W
R2815	1-216-085-91	RES-CHIP	33K	5%	1/10W
R2816	1-216-107-00	RES-CHIP	270K	5%	1/10W
R2817	1-216-107-00	RES-CHIP	270K	5%	1/10W
		<TRANSFORMER>			
T2800	1-413-059-00	TRANSFORMER, FERRITE (DFT)			

****

* A-1241-445-A F BOARD MOUNTED
****

1-533-223-11 CLIP, FUSE

<CAPACITOR>

C654	⚠	1-117-703-51	CERAMIC	0.0047UF	99%	250V
C4601	⚠	1-113-511-11	MYLAR	0.47UF	20.00%	250V
C4602	⚠	1-113-512-11	MYLAR	0.68UF	20.00%	250V

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

H1 **H2** **F**

REF NO.		PART NO.	DESCRIPTION			REMARK
			<CONNECTOR>			
CN4601		1-580-843-11	PIN, CONNECTOR (POWER)			
CN4602		1-580-843-11	PIN, CONNECTOR (POWER)			
CN4603		1-695-915-11	TAB (CONTACT)			
			<FUSE>			
F4601	⚠	1-533-223-41	FUSE, TIME-LAG 5A/250V			
			<RESISTOR>			
R4601	⚠	1-202-885-91	CARBON	1M	5%	1/2W
			<TRANSFORMER>			
T4601	⚠	1-433-743-11	TRANSFORMER, LINE FILTER			
T4602	⚠	1-431-182-11	TRANSFORMER, LINE FILTER			
**********						
	*	A-1400-888-A	H1 BOARD MOUNTED			
			**********			
			<CAPACITOR>			
C3900		1-136-153-00	FILM	0.01UF	5.00%	50V
C3902		1-136-153-00	FILM	0.01UF	5.00%	50V
C3904		1-126-947-11	ELECT	47UF	20.00%	25V
C3905		1-126-963-11	ELECT	4.7UF	20.00%	50V
C3906		1-126-963-11	ELECT	4.7UF	20.00%	50V
C3910		1-126-947-11	ELECT	47UF	20.00%	16V
C3911		1-126-947-11	ELECT	47UF	20.00%	16V
C3913		1-126-960-11	ELECT	1UF	20.00%	50V
			<CONNECTOR>			
CN3901		1-564-507-21	PLUG, CONNECTOR 4P			
CN3902		1-564-509-11	PLUG, CONNECTOR 6P			
CN3904	*	1-564-512-11	PLUG, CONNECTOR 9P			
CN3905	*	1-564-512-11	PLUG, CONNECTOR 9P			
CN3907	*	1-564-521-11	PLUG, CONNECTOR 6P			
			<DIODE>			
D3900		8-719-070-16	NNCD9.1A-T1			
D3901		8-719-070-16	NNCD9.1A-T1			
D3905		8-719-070-16	NNCD9.1A-T1			
D3907		8-719-070-16	NNCD9.1A-T1			
D3908		8-719-070-16	NNCD9.1A-T1			
			<JACK>			
J3901		1-750-264-11	JACK			
J3902		1-784-646-11	TERMINAL, S			
J3903		1-770-329-12	JACK, PIN 3P			
			<COIL>			
L3901		1-414-183-41	INDUCTOR	10UH		
L3902		1-414-183-41	INDUCTOR	10UH		

REF NO.		PART NO.	DESCRIPTION			REMARK
			<TRANSISTOR>			
Q3901		8-729-030-02	DTC144ESA			
Q3902		8-729-030-02	DTC144ESA			
			<RESISTOR>			
R3900		1-249-411-11	CARBON	330	5%	1/4W
R3901		1-249-411-11	CARBON	330	5%	1/4W
R3902		1-247-804-11	CARBON	75	5%	1/4W
R3904		1-249-429-11	CARBON	10K	5%	1/4W
R3905		1-249-429-11	CARBON	10K	5%	1/4W
R3907		1-249-426-11	CARBON	5.6K	5%	1/4W
R3908		1-249-413-11	CARBON	470	5%	1/4W
R3909		1-249-417-11	CARBON	1K	5%	1/4W
R3910		1-249-420-11	CARBON	1.8K	5%	1/4W
R3911		1-249-411-11	CARBON	330	5%	1/4W
R3912		1-247-843-11	CARBON	3.3K	5%	1/4W
R3913		1-249-429-11	CARBON	10K	5%	1/4W
R3914		1-249-411-11	CARBON	330	5%	1/4W
R3915		1-249-429-11	CARBON	10K	5%	1/4W
R3916		1-249-401-11	CARBON	47	5%	1/4W
R3917		1-247-804-11	CARBON	75	5%	1/4W
R3918		1-247-807-31	CARBON	100	5%	1/4W
R3919		1-249-409-11	CARBON	220	5%	1/4W
R3920		1-247-807-31	CARBON	100	5%	1/4W
R3921		1-247-807-31	CARBON	100	5%	1/4W
R3922		1-249-421-11	CARBON	2.2K	5%	1/4W
			<SWITCH>			
S3902		1-692-431-21	SWITCH, TACTILE			
S3903		1-692-431-21	SWITCH, TACTILE			
S3904		1-692-431-21	SWITCH, TACTILE			
S3905		1-692-431-21	SWITCH, TACTILE			
S3906		1-692-431-21	SWITCH, TACTILE			
S3907		1-692-431-21	SWITCH, TACTILE			
S3908		1-692-431-21	SWITCH, TACTILE			
**********						
	*	A-1400-889-A	H2 BOARD MOUNTED			
			**********			
	*	4-055-304-01	HOLDER, LED			
			<CAPACITOR>			
C3912		1-102-114-00	CERAMIC	470PF	10.00%	50V
			<CONNECTOR>			
CN3601	*	1-580-844-11	PIN, CONNECTOR (POWER)			
CN3602	*	1-580-844-11	PIN, CONNECTOR (POWER)			
CN3603	*	1-564-521-11	PLUG, CONNECTOR 6P			
			<DIODE>			
D3906		8-719-083-18	DIODE SPB-25MVWF			

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

H2 J VM1

REF NO.	PART NO.	DESCRIPTION			REMARK
		<IC>			
IC3901	6-600-129-01	IC RPM7140-H5			
		<SWITCH>			
S3601	⚠ 1-571-433-31	SWITCH, PUSH (AC POWER)			

****

*	A-1400-886-A	J BOARD MOUNTED **********			
		<CAPACITOR>			
C2410	1-126-967-11	ELECT	47UF	20.00%	50V
C2411	1-126-967-11	ELECT	47UF	20.00%	50V
C2412	1-126-967-11	ELECT	47UF	20.00%	50V
C2413	1-102-112-00	CERAMIC	330PF	10.00%	50V
C2414	1-102-112-00	CERAMIC	330PF	10.00%	50V
C2418	1-126-960-11	ELECT	1UF	20.00%	50V
C2419	1-126-960-11	ELECT	1UF	20.00%	50V
		<CONNECTOR>			
CN2410	* 1-564-523-11	PLUG, CONNECTOR 8P			
		<DIODE>			
D2410	8-719-070-16	NNCD9.1A-T1			
D2411	8-719-070-16	NNCD9.1A-T1			
D2412	8-719-070-16	NNCD9.1A-T1			
D2414	8-719-070-16	NNCD9.1A-T1			
D2415	8-719-070-16	NNCD9.1A-T1			
		<JACK>			
J2410	1-784-623-11	BLOCK, PIN JACK 5P			
		<RESISTOR>			
R2410	1-247-804-11	CARBON	75	5%	1/4W
R2411	1-247-804-11	CARBON	75	5%	1/4W
R2412	1-247-804-11	CARBON	75	5%	1/4W
R2414	1-247-887-00	CARBON	220K	5%	1/4W
R2415	1-247-807-31	CARBON	100	5%	1/4W
R2417	1-247-887-00	CARBON	220K	5%	1/4W
R2418	1-247-807-31	CARBON	100	5%	1/4W
R2419	1-249-409-11	CARBON	220	5%	1/4W
R2420	1-249-409-11	CARBON	220	5%	1/4W
R2421	1-249-409-11	CARBON	220	5%	1/4W

****

REF NO.	PART NO.	DESCRIPTION			REMARK
*	A-1401-080-A	VM1 BOARD MOUNTED **********			
	4-382-854-11	SCREW (M3X10), P, SW (+)			
		<CAPACITOR>			
C5900	1-102-115-00	CERAMIC	560PF	10.00%	50V
C5902	1-104-661-91	ELECT	330UF	20.00%	16V
C5903	1-161-830-00	CERAMIC	0.0047UF		500V
C5905	1-126-935-11	ELECT	470UF	20.00%	10V
C5906	1-130-491-00	MYLAR	0.047UF	5.00%	50V
C5907	1-107-638-11	ELECT	33UF	20.00%	160V
C5908	1-106-383-00	MYLAR	0.047UF	10.00%	200V
C5909	1-126-933-11	ELECT	100UF	20.00%	16V
C5910	1-130-471-00	MYLAR	0.001UF	5.00%	50V
C5911	1-107-949-11	ELECT	2.2UF	20.00%	160V
C5912	1-104-999-11	MYLAR	0.1UF	10.00%	200V
C5913	1-130-471-00	MYLAR	0.001UF	5.00%	50V
C5914	1-126-933-11	ELECT	100UF	20.00%	16V
C5916	1-130-491-00	MYLAR	0.047UF	5.00%	50V
C5917	1-126-935-11	ELECT	470UF	20.00%	10V
C5918	1-102-244-00	CERAMIC	220PF	10.00%	500V
C5919	1-136-165-00	FILM	0.1UF	5.00%	50V
		<CONNECTOR>			
CN2801	1-564-506-11	PLUG, CONNECTOR 3P			
CN5901	* 1-564-510-11	PLUG, CONNECTOR 7P			
CN5904	* 1-770-723-11	CONNECTOR, BOARD TO BOARD 8P			
		<DIODE>			
D5901	8-719-991-33	1SS133T-77			
D5902	8-719-110-86	RD39ES-B			
D5903	8-719-991-33	1SS133T-77			
D5904	8-719-110-86	RD39ES-B			
D5905	8-719-991-33	1SS133T-77			
D5906	1-249-406-11	CARBON	120	5%	1/4W
D5907	1-249-406-11	CARBON	120	5%	1/4W
		<COIL>			
L5901	1-414-187-11	INDUCTOR	47UH		
		<TRANSISTOR>			
Q5901	8-729-230-45	2SC2458-YGR			
Q5902	8-729-809-26	2SA1606-E			
Q5903	8-729-230-45	2SC2458-YGR			
Q5904	8-729-119-76	2SA1175-HFE			
Q5905	8-729-230-45	2SC2458-YGR			
Q5906	8-729-809-29	2SC4159-E			
Q5907	8-729-230-45	2SC2458-YGR			
		<RESISTOR>			
R5901	1-249-401-11	CARBON	47	5%	1/4W
R5902	1-249-414-11	CARBON	560	5%	1/4W
R5903	1-247-734-11	CARBON	39	5%	1/2W
R5904	1-249-411-11	CARBON	330	5%	1/4W
R5905	1-249-417-11	CARBON	1K	5%	1/4W

VM1

REF NO.	PART NO.	DESCRIPTION		REMARK	
R5906	1-249-417-11	CARBON	1K	5%	1/4W
R5907	1-249-417-11	CARBON	1K	5%	1/4W
R5908	1-249-383-11	CARBON	1.5	5%	1/4W
R5909	1-249-409-11	CARBON	220	5%	1/4W
R5910	1-249-403-11	CARBON	68	5%	1/4W
R5911	1-249-439-11	CARBON	68K	5%	1/4W
R5912	1-249-437-11	CARBON	47K	5%	1/4W
R5914	1-249-403-11	CARBON	68	5%	1/4W
R5915	1-249-429-11	CARBON	10K	5%	1/4W
R5916	1-249-419-11	CARBON	1.5K	5%	1/4W
R5917	1-249-416-11	CARBON	820	5%	1/4W
R5918	1-249-429-11	CARBON	10K	5%	1/4W
R5919	1-249-417-11	CARBON	1K	5%	1/4W
R5920	1-249-439-11	CARBON	68K	5%	1/4W
R5921	1-216-476-11	METAL OXIDE	180	5%	3W
R5922	1-249-414-11	CARBON	560	5%	1/4W
R5923	1-249-383-11	CARBON	1.5	5%	1/4W
R5925	1-249-400-11	CARBON	39	5%	1/4W
R5927	1-249-416-11	CARBON	820	5%	1/4W
R5929	1-215-880-00	METAL OXIDE	10	5%	2W

****

REF NO.	PART NO.	DESCRIPTION	REMARK
		ACCESSORIES AND PACKING MATERIALS	
		**********	
	3-701-910-00	SCREW, SPECIAL (DIA. 3.8X20)	
*	4-029-168-01	BAG, PROTECTION	
	4-074-287-01	JOINT	
*	4-088-913-01	TRAY	
*	4-088-914-01	CUSHION (UPPER)	
*	4-088-915-01	CUSHION (LOWER)	
*	4-089-303-01	INDIVIDUAL CARTON	
	4-088-211-11	INSTRUCTION MANUAL	
	4-392-003-11	BAND, HOLD	
	4-392-004-11	CLIP	

****

		REMOTE COMMANDER	
		**********	
	1-477-407-11	REMOTE COMMANDER (RM-993)	

Sony Corporation
Sony Technology Malaysia Sdn. Bhd.
Visual Products

9-872-312-01

English
© 2002.5

SONY

4-088-211-**11** (2)

Trinitron Color TV

Operating Instructions — GB

- Before operating the unit, please read this manual thoroughly and retain it for future reference.

使用說明書 — CT

- 使用本電視機之前請先詳細閱讀此手冊，並妥善保存以備日後用作參考。

使用说明书 — CS

- 使用本电视机之前请详细阅读此手册，并妥善保存以备日后用作参考。

FD Trinitron WEGA

KV-AR29

© 2002 Sony Corporation

M90

WARNING

- Dangerously high voltages are present inside the TV.
- TV operating voltage: 220-240 V AC.
- Do not plug in the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.
- To avoid battery leakage and damage to the remote, remove the batteries from the remote if you are not going to use it for several days. If any liquid leaks from the batteries and touches your skin, immediately wash it away with water.



For your own safety, do not touch any part of the TV, the power cord and the antenna cable during lightning storms.



For children's safety, do not leave children alone with the TV. Do not allow children to climb onto it.



To prevent fire or shock hazard, do not expose the TV to rain or moisture.



Do not operate the TV if any liquid or solid object falls into it. Have it checked immediately by qualified personnel only.



Do not block the ventilation openings of the TV.
Do not install the TV in a confined space, such as a bookcase or built-in cabinet.



Clean the TV with a dry and soft cloth.
Do not use benzine, thinner, or any other chemicals to clean the TV. Do not attach anything (e. g., adhesive tape, cellophane tape, glue) on the painted cabinet of the TV. Do not scratch the picture tube.



Do not open the cabinet and the rear cover of the TV as high voltages and other hazards are present inside the TV. Refer servicing and disposal of the TV to qualified personnel.



Your TV is recommended for home use only.
Do not use the TV in any vehicle or where it may be subject to excessive dust, heat, moisture or vibrations.



Do not place any objects on the TV.



Do not plug in too many appliances to the same power socket. Do not damage the power cord.



Install the TV on a stable TV stand and floor which can support the TV set weight. Ensure that the TV stand surface is flat and its area is larger than the bottom area of the TV.



Pull the power cord out by the plug. Do not pull the power cord itself. Even if your TV is turned off, it is still connected to the AC power source (mains) as long as the power cord is plugged in. Unplug the TV before moving it or if you are not going to use it for several days.

■ Securing the TV

To prevent the TV from falling, use the supplied screws, clamps and band to secure the TV.



screws

clamps



band

1



(1) Screw the band and one clamp to the provided hole at the rear of your TV.
(2) Screw the band to the TV stand.
(3) Put a cord or chain through both clamps and screw the other clamp to a wall or pillar.

2



(1) Attach each end of a cord or chain to the provided holders at the rear of your TV.
(2) Securely fix the attached cord or chain to a wall or pillar using an attachment which can support the TV set weight.

Note

- Use only the supplied screws. Use of other screws may damage the TV.

Table of Contents

Installation

Getting Started **6**
Setting up your TV ("INITIAL SETUP") **7**

Overview of Controls

TV front and rear panels **8**
Remote control **9**

Advanced Operations

Selecting the picture and sound modes **11**
Viewing the picture in wide mode .. **12**
Listening with surround sound **12**
Enjoying stereo or bilingual programs **13**
Setting the timers **14**

Menu Adjustment

Introducing the menu system **15**
Changing the "PICTURE" setting ... **18**
Changing the "SOUND" setting **20**
Changing the "SETUP" setting **22**
Changing the Channel Preset ("CH PRESET") setting **24**

Additional Information

Connecting optional components ... **27**
Troubleshooting **29**
Specifications ..... **Back cover**

GB

■ Getting Started



Step 1

Insert the batteries (supplied) into the remote.

Note

- Do not use old or different types of batteries together.



Step 2

Connect the antenna cable (not supplied) to ⅂⊢ (antenna input) at the rear of the TV.

Tip

- You can also connect your TV to other optional components (see page 27).



Step 3

Plug in the power cord, then press ⏻ on the TV to turn it on.



Step 4

Set up the TV by following the instructions of the "INITIAL SETUP"menu (see page 7).

■ Setting up your TV ("INITIAL SETUP")

When you turn on your TV for the first time, the "INITIAL SETUP" menu will appear. This menu allows you to change the menu language, adjust the picture position and preset the TV channels automatically.



1 Press ↑ or ↓ to select the desired menu language (e.g.,"ENGLISH"), then press ENTER.

The selected menu language appears.



2 If the "PIC ROTATION" bar is slanted, press ↑ or ↓ to adjust it, then press ENTER.

If no adjustment is necessary, then press ENTER.

The ⊞ or ⊟ icon on the screen flashes while adjusting.



3 Press ↑ or ↓ to select "YES", then press ENTER to preset the channels automatically (see page 24).

The screen will indicate automatic presetting is in progress.

To skip automatic channel presetting, select "NO", then press ENTER.





4 Press ↑ or ↓ to select "NO", then press ENTER. The "INITIAL SETUP" menu will not appear again the next time you turn on the TV by pressing ⏻.

To allow this menu to appear again, select "YES", then press ENTER.



Tips

- You can immediately go to the end of the "INITIAL SETUP" menu by pressing MENU.
- You can also set up your TV using the menu system (see page 15).

■ TV front and rear panels



Button/Terminal	Function	Page
❶ ⏻	Turn off or turn on the TV.	6
❷ ⏻	Standby indicator.	–
❷ ⧉	Stereo/bilingual indicator.	13
❷ 🕘	Wake Up indicator.	14
❸	Remote control sensor.	–
❹ PROGR +/–	Select program number.	–
❺ +/–	Adjust volume.	–
❻	Select TV or video input.	–
❼ AUTO PROGR	Preset channels automatically.	–
Menu operations		
❺ SELECT ▼/▲	Select and adjust items.	17
❻ ENTER	Confirm selected items.	17
❽ MENU	Display or cancel the menu.	17
❾ 3	Video input terminal 3.	27
❿	Headphone jack.	–
⓫	Component video input terminal.	28
⓬	Antenna input terminal.	27
⓭	Monitor output terminal.	27
⓮ 1, 2, 3	Video input terminal 1, 2, 3.	27

■ Remote control



Button	Function	Page
❶ I/⏻	Turn off temporarily or turn on the TV.	–
❸ ▭	Display the TV input.	–
❹ 0 – 9, -/--	Input numbers.	–
❺ JUMP	Jump to previous program number.	–
❾ SURROUND	Select surround mode.	12
❿ WIDE MODE	Select wide-mode (16:9).	12
⓫ PROGR +/–	Select program number.	–
⓮ ⓘ+	Display on-screen information.	–
⓯ 🔇	Mute the sound.	–
⓰ DVD	Select DVD input.	28
⓱ ⏎	Select TV or video input.	27
㉑ SOUND MODE	Select sound mode.	11
㉒ PIC MODE	Select picture mode.	11
㉓ ◿ +/–	Adjust volume.	–
Timer operations		
⓬ ⏲	Set TV to turn off automatically.	14
⓭ ⏲	Set TV to turn on automatically.	14
PIP operations (yellow label)		
❻ ◳	Not function for your TV.	–
❼ ♪		
❽ PIP PROGR + / PIP PROGR –		
⓲ ◳		
⓳ SOUND		
⓴ ENTER		
Stereo/bilingual operations		
❷ A/B	Select stereo/bilingual mode.	13

continue

continued



Button	Function	Page
Menu operations		
26 MENU	Display or cancel the menu.	17
27 ENTER	Confirm selected items.	17
35 ↑, ↓, ←, →	Select and adjust items.	17
Teletext operations (green label)		
24 ⇕	Not function for your TV.	–
25 0 – 9		
28 PROGR +/–		
29 ⊠		
30		
31 ?		
32 ☰		
33 ⇕		
34 ▬ (red, green, yellow, blue)		
36 RESET	Set TV to factory setting.	29

■ Selecting the picture and sound modes

You can select picture and sound modes and adjust the setting to your preference in the “PERSONAL” option.



Selecting the picture mode

Press PIC MODE to select the desired picture mode.

Select	To
“DYNAMIC”	view high contrast pictures.
“STANDARD”	view normal pictures.
“SOFT”	view mild pictures.
“PERSONAL”	receive the last adjusted picture setting from the “ADJUST” option in the “PICTURE” menu (see page 19).

Selecting the sound mode

Press SOUND MODE to select the desired sound mode.

Select	To
“♪ DYNAMIC”	listen to dynamic and clear sound that emphasizes both the low and high tones.
“♪ DRAMA”	listen to sound that emphasizes voice and high tones.
“♪ SOFT”	listen to soft sound.
“♪ PERSONAL”	receive the last adjusted sound setting from the “ADJUST” option in the “SOUND” menu (see page 21).

■ Viewing the picture in wide mode

When receiving a wide-mode (16:9) signal, the picture will appear “squeezed” (compressed) on your screen. Use the WIDE MODE button to view the picture with the optimal effect.



Select	To
“ON”	view the picture in wide-mode (16:9).
“OFF”	cancel wide-mode (16:9).

■ Listening with surround sound

You can use the SURROUND button to listen to the sound effects of a concert hall or movie theater.



Select	To
“TruSurround”	listen to the surround sound that spreads out to the rear of a room.
“SIMULATED”	listen to monaural sound with a stereo-like effect.
“OFF”	cancel surround sound.

The surround of your TV is categorized as TruSurround.

TruSurround™ is a trademark of SRS Labs, Inc. SRS and the SRS symbol are registered trademarks of SRS Labs, Inc. in the United States and selected foreign countries. SRS and TruSurround are incorporated under license from SRS Labs, Inc. and are protected under United States Patent Nos. 4,748,669 and 4,841,572 with numerous additional issued and pending foreign patents.

■ Enjoying stereo or bilingual programs

You can enjoy stereo sound or bilingual programs of NICAM and A2 stereo systems by using the A/B button.



When receiving a NICAM program

Broadcasting	On-screen display (Selected sound)
NICAM stereo	NICAM (Stereo sound) → MONO (Regular sound)
NICAM bilingual	NICAM MAIN (Main sound) → NICAM SUB (Sub sound) → MONO (Regular sound)
NICAM monaural	NICAM MAIN (Main sound) → MONO (Regular sound)

When receiving an A2 program

Broadcasting	On-screen display (Selected sound)
A2 stereo	STEREO (Stereo sound) → MONO (Regular sound)
A2 bilingual	MAIN (Main sound) → SUB (Sub sound)

Notes

- If the stereo sound is noisy when receiving a stereo program, select “MONO”. The sound becomes monaural, but the noise is reduced.
- Before receiving a NICAM stereo program in China, please check the NICAM broadcast condition in your area. When receiving a NICAM stereo program, the receiving conditions might vary depending on area. In addition, different strength of the NICAM broadcast signal might affect the receiving quality.
- If the sound is distorted when receiving a monaural program through ⅂Γ (antenna input), press A/B repeatedly until “MONO” appears on the screen. To cancel the monaural sound setting, press A/B again until “AUTO” appears on the screen.

■ Setting the timers

You can set your TV to turn on and off automatically by using the WAKE UP and SLEEP timers respectively.



Setting the Wake Up timer

1 Press ⏲ until the desired period of time appears on the screen.



The Wake Up timer starts immediately after you have set it.

2 Select the program number or video input you want to wake up to.

3 Press I/⏻, or set the Sleep timer if you want the TV to turn off automatically.

The ⏲ indicator on the TV lights up orange when the TV goes into standby mode.

Setting the Sleep timer

Press ⏲ until the desired period of time appears on the screen.



The Sleep timer starts immediately after you have set it.

Notes

- You can also cancel the Wake Up and Sleep timers by turning off the TV's main power.
- If no buttons are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into standby mode.

■ Introducing the menu system

The MENU button lets you open a menu and change the settings of your TV. The following is an overview of the menu system.



Level 1	Level 2	Level 3/Function	Page
"PICTURE"	"PICTURE MODE"	Select the picture mode: "DYNAMIC" → "STANDARD" → "SOFT" → "PERSONAL" → "ADJUST"	18
	"ADJUST"	Adjust the "PERSONAL" option: "PICTURE" → "COLOR" → "BRIGHT" → "HUE" → "SHARP"	
	"WIDE MODE"	Change the picture size: "ON" → "OFF"	
	"INTELLIGENT PIC"	Optimize picture quality: "ON" → "OFF"	
"SOUND"	"SOUND MODE"	Select the sound mode: "DYNAMIC" → "DRAMA" → "SOFT" → "PERSONAL" → "ADJUST"	20
	"ADJUST"	Adjust the "PERSONAL" option: "BASS" → "TREBLE" → "BALANCE" → "BBE"*	
	"SURROUND"	Select the "SURROUND" mode: "TruSurround" → "SIMULATED" →"OFF"	
	"INTELLIGENT VOL"	Adjust volume automatically: "ON" → "OFF"	

continue

continued

Level 1	Level 2	Level 3/Function	Page
"SETUP"	"LANGUAGE"	Change the menu language: "ENGLISH" → "中文"(Chinese) → "عربي"(Arabic) → "ไทย"(Thai)	22
	"PIC ROTATION"	Adjust the picture position.	
	"PROGRAM SETUP"	Adjust each program number settings.	
	"COLOR SYS"	Select the color system: "AUTO" →" PAL" → "SECAM" → "NTSC3.58" → "NTSC4.43"	
"CH PRESET"	"AUTO PROGRAM"	Preset channels automatically.	24
	"MANUAL PROGRAM"	Preset channels manually.	
	"TV SYS"	Select the TV system: "B/G" → "I" → "D/K" → "M"	

* The BBE is manufactured by Sony Corporation under license from BBE Sound, Inc. It is covered by U.S. Patent No. 4,638,258 and No. 4,482,866. The word "BBE" and the BBE symbol are the trademarks of BBE Sound, Inc.

How to use the menu



Other menu operations

To	Press
Adjust the setting value	↑, ↓, ← or →.
Move to the next/previous menu level	← or →.
Cancel the menu	MENU.

Tips

- If you want to exit from Menu level 2 to Menu level 1, press ↑ or ↓ until the return icon (⮌) is highlighted, then press ENTER.
- Some of the menu items can be operated directly using the remote buttons.
- The MENU, ENTER, and SELECT ▼/▲ buttons on the TV can also be used for the operations above.

Front of TV



■ Changing the “PICTURE” setting

The “PICTURE” menu allows you to adjust the picture settings.

1 Press MENU.

2 Make sure the “PICTURE” icon ( ) is selected, then press ENTER.



3 Press ↑ or ↓ to select the desired item (e.g., “PICTURE MODE”), then press ENTER.



Select	To
“PICTURE MODE”	choose either “DYNAMIC”, “STANDARD”, “SOFT”, “PERSONAL”*, or “ADJUST” (see page 11).
“WIDE MODE”	choose either “ON” or “OFF” (see page 12).
“INTELLIGENT PIC”	optimize picture quality. Press ↑ or ↓ to select “ON”, then press ENTER. To cancel, select “OFF”, then press ENTER.

* When the “PERSONAL” mode is selected, you can receive the last adjusted picture settings from the “ADJUST” option (see page 19).

Adjusting the “ADJUST” items under “PICTURE MODE”

1 Press ↑ or ↓ to select the desired item (e.g.,“COLOR”), then press ENTER.

2 Adjust the value according to the following table, then press ENTER.

For	Press ↓ or ← to	Press ↑ or → to
“PICTURE”	decrease picture contrast.	increase picture contrast.
“COLOR”	decrease color intensity.	increase color intensity.
“BRIGHT”	darken the picture.	brighten the picture.
“HUE”	increase red picture tones.	increase green picture tones.
“SHARP”	soften the picture.	sharpen the picture.

3 Repeat the above steps to adjust other items.

The adjusted settings will be received when you select “PERSONAL”.

Notes

- “HUE” can be adjusted for the NTSC color system only.
- Reducing sharpness (“SHARP”) can also reduce picture noise.

■ Changing the “SOUND” setting

The “SOUND” menu allows you to adjust the sound settings.

1 Press MENU.

2 Press ↑ or ↓ to select the “SOUND” icon (♪), then press ENTER.



3 Press ↑ or ↓ to select the desired item (e.g., “SOUND MODE”), then press ENTER.



Select	To
“SOUND MODE”	choose either “DYNAMIC”, “DRAMA”, “SOFT”, “PERSONAL”*, or “ADJUST” (see page 11).
“SURROUND”	choose either “TruSurround”, “SIMULATED” or “OFF” (see page 12).
“INTELLIGENT VOL”	adjust the volume of all program numbers and video inputs automatically. Press ↑ or ↓ to select “ON”, then press ENTER. To cancel, select “OFF”, then press ENTER.

* When the “PERSONAL” mode is selected, you can receive the last adjusted sound settings from the “ADJUST” option (see page 21).

Adjusting the “ADJUST” items under “SOUND MODE”

1 Press ↑ or ↓ to select the desired item (e.g., “BALANCE”), then press ENTER.



2 Adjust the value according to the following table, then press ENTER .

For	Press ↓ or ← to	Press ↑ or → to
“BASS”	decrease the bass.	increase the bass.
“TREBLE”	decrease the treble.	increase the treble.
“BALANCE”	increase the left speaker’s volume.	increase the right speaker’s volume.
“BBE”	select “HIGH” for higher enhancement of sound clarity; select “LOW” for lower enhancement of sound clarity; select “OFF” to cancel BBE sound.	

3 Repeat the above steps to adjust other items.

The adjusted settings will be received when you select “PERSONAL”.

■ Changing the “SETUP” setting

The “SETUP” menu allows you to change the menu language, adjust the picture position, set up your program numbers and select the color system.

1 Press MENU.

2 Press ↑ or ↓ to select the “SETUP” icon (), then press ENTER.



3 Press ↑ or ↓ to select the desired item (e.g., “COLOR SYS”), then press ENTER.



Select	To
“LANGUAGE”	change the menu language. Press ↑ or ↓ to select either “ENGLISH”, “中文” (Chinese), “ عربي ” (Arabic), or “ ไทย ” (Thai), then press ENTER. The selected menu language appears.
“PIC ROTATION”	adjust the picture position when it is not aligned with the TV screen. Press ↑ , → , ↓ or ← to adjust the picture position, then press ENTER.
“PROGRAM SETUP”	adjust each channel settings (see **Adjusting each program number settings (“PROGRAM SETUP”)** on page 23).
“COLOR SYS”	select the color system. Normally, set this to “AUTO”.

Adjusting each program number settings (“PROGRAM SETUP”)

1 Select “PROGRAM SETUP” from the “SETUP” menu.

2 Select “PR” and press ENTER. Press ↑ or ↓ to select the desired program number you want to adjust, then press ENTER.



3 Press ↑ or ↓ to select the desired item (e.g., “SKIP”), then press ENTER.



Select	To
“PR”	select the desired program number.
“SKIP”	skip unwanted or unused program number. Press ↑ or ↓ to select “ON”, then press ENTER. To cancel, select “OFF”, then press ENTER.
“CHILD LOCK”	prevent children from watching this selected program number. Press ↑ or ↓ to select “ON”, then press ENTER. The lock symbol (🔒) appears on the screen. To cancel, select “OFF”, then press ENTER. If you preset a locked program number, that program number will be unlocked automatically.

4 To continue adjusting other program numbers, press ↑ or ↓ to select “PR”, then repeat step 2 and 3.

■ Changing the Channel Preset ("CH PRESET") setting

The "CH PRESET" menu allows you to preset channels automatically, manually preset channels and select the TV system.

1 Press MENU.

2 Press ↑ or ↓ to select the "CH PRESET" icon (), then press ENTER.



3 Press ↑ or ↓ to select the desired item (e.g., "AUTO PROGRAM"), then press ENTER.



Select	To
"AUTO PROGRAM"	preset channels automatically.
"MANUAL PROGRAM"	manually preset desired channels and channels that cannot be preset automatically (see **Presetting channels manually** on page 25).
"TV SYS"	select the TV system. Press ↑ or ↓ to select either "B/G", "I", "D/K" or "M", then press ENTER.

Presetting channels manually

1 After selecting "MANUAL PROGRAM", select the program number to which you want to preset a channel.

(1) Make sure "PR" is selected, then press ENTER.



(2) Press ↑ or ↓ until the program number you want to preset (e.g., program number "10") appears on the menu, then press ENTER.



2 Select the desired channel.

(1) Make sure either "VHF LOW", "VHF HIGH", or "UHF" is selected, then press ENTER.



(2) Press ↑ or ↓ until the desired channel's broadcast appears on the TV screen, then press ENTER.



3 If the sound of the desired channel is abnormal, select the appropriate TV system.

(1) Press ↑ or ↓ to select "TV SYS", then press ENTER.



(2) Press ↑ or ↓ until the sound becomes normal, then press ENTER.



Tip

- You can also select the program number with the PROGR +/– or number buttons.

continue

continued

4 If you are not satisfied with the picture and sound quality, you may be able to improve them by using the "FINE" tuning feature.

(1) Press ↑ or ↓ to select "FINE", then press ENTER.



(2) Press ↑ or ↓ to select "MANUAL", then press ENTER.



(3) Press ↑, ↓, ← or → until the picture and sound quality are optimal, then press ENTER.
The + or – icon on the menu flashes while tuning.



Note

- If you connect a VCR to ⅂⌐ (antenna input), preset the signal output from the VCR to the program number 0 on the TV.

■ Connecting optional components

Connecting to the video input terminal (⇦)



Connecting to the monitor output terminal (⇨)



continue

continued

Connecting a DVD player to the component video input terminal ( )

1 Using an audio cable, connect R and L under (component video input) on your TV to the LINE OUT, AUDIO R and L output connectors on your DVD player.

2 Using a component video cable, connect Y, C_B, and C_R under (component video input) on your TV to the COMPONENT VIDEO OUT Y, C_B, and C_R output connectors on your DVD player.

3 Press DVD on the remote to watch the (component video input) and "DVD" will appear on your screen.



Notes

- If your DVD player can ouput interlace and progressive mode signals, select the interlace output when connecting to (component video input) on your TV. Your TV can receive either 525i/60Hz or 625i/50Hz interlace signals.
- Some DVD player terminals may be labeled differently:

Connect	To (on the DVD player)
Y (green)	Y
C_B (blue)	C_B, P_B, C_b or B-Y
C_R (red)	C_R, P_R, C_r or R-Y

- When both (S video) and (video) for 1 or 3 are connected at the same time, (S video) is automatically selected. To view (video), disconnect the S video cable.
- If you select "DVD" on your TV screen, the signal from the (monitor output) jacks will not be output properly. This does not indicate a malfunction.

■ Troubleshooting

If you have any problem while viewing your TV, you can either use the Reset function or check the Troubleshooting guide below. If the problem persists, contact your Sony dealer.



Reset function

Press the RESET button on your remote control. Your TV will go blank for about half a second then the picture will reappear with "RESET" displayed on your TV screen for about 10 seconds.

Pressing RESET will set your TV to the factory setting, but certain problems may be solved.

Troubleshooting guide

Symptom	Possible cause	Solutions	Page
Snowy picture  **Noisy sound** 	• The connection is loose or the cable is damaged.	• Check the antenna cable and connection on the TV, VCR and at the wall.	27
	• The antenna setup is inappropriate.	• Check the antenna setup. Contact a Sony dealer for advice.	–
	• Channel presetting is inappropriate or incomplete.	• Display the "CH PRESET" menu and select "MANUAL PROGRAM" to preset the channel again.	25
	• Signal transmission is low.	• Try using a booster.	–
Distorted picture **Noisy sound** 	• Broadcast signals are too strong.	• Turn off or disconnect the booster if it is in use.	–
Good picture **Noisy sound** 	• The TV system setting is inappropriate.	• Display the "CH PRESET" menu and select the appropriate TV system ("TV SYS").	25

continue

continued

Symptom	Possible cause	Solutions	Page
No picture **No sound** 	• The power cord, antenna or VCR is not connected.	• Check the power cord, antenna and VCR connections.	27
	• The TV is not turned on.	• Press I/⏻ (power). • Press ⏻ (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	9 8
Good picture **No sound** 	• The volume level is too low.	• Press + to increase the volume level.	9
	• The sound is muted.	• Press 🔇 to cancel the muting.	9
Dotted lines or stripes 	• There is local interference from cars, neon signs, hair dryers, power generators, etc.	• Do not use a hair dryer or other equipment near the TV. • Check the antenna setup. Contact a Sony dealer for advice.	– –
Double images or "ghosts" 	• Broadcast signals are reflected by nearby mountains or buildings.	• Use a highly directional antenna. • Use the fine tuning ("FINE") function.	– 26
	• The antenna setup is inappropriate.	• Check the antenna setup. Contact a Sony dealer for advice.	–
	• Use of a booster is inappropriate.	• Turn off or disconnect the booster if it is in use.	–
No color 	• The color level setting is too low.	• Display the "PICTURE" menu and select "ADJUST" of "PICTURE MODE", then adjust the "COLOR" level.	19
	• The color system setting is inappropriate.	• Display the "SETUP" menu and check the color system ("COLOR SYS") setting (usually set this to "AUTO").	22
	• The antenna setup is inappropriate.	• Check the antenna setup. Contact a Sony dealer for advice.	–

Symptom	Possible cause	Solutions	Page
Picture slant 	• The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.	• Keep external speakers or other electrical equipment away from the TV. • Display the "SETUP" menu and adjust "PIC ROTATION" so that the picture position is optimal.	– 22
Abnormal color patches 	• The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.	• Keep external speakers or other equipment away from the TV. Do not move the TV while the TV is turned on. Press ⏻ (main power) on the TV to turn off the TV for about 15 minutes, then turn it on again to demagnetize the TV.	–
TV cannot receive stereo broadcast sound.	• The stereo reception setting is inappropriate.	• Press A/B until "AUTO" appears on the screen.	13
or	• The connection is loose or the cable is damaged.	• Check the antenna cable and connection on the TV, VCR and on the wall.	27
Stereo broadcast sound switches on and off or is distorted.	• The antenna setup is inappropriate.	• Check the antenna setup. Contact a Sony dealer for advice.	–
The ⏻ (standby) indicator on your TV flashes red several times after every three seconds.	• Your TV's self-diagnosis function indicates the possible problems.	• Count the number of times the ⏻ (standby) indicator flashes. Press ⏻ (main power) to turn off your TV. Contact your nearest Sony service center.	–
Cannot play shooting game.	• Some shooting games which involve pointing a light beam at the TV screen with an electronic gun or rifle cannot be used with your TV. For details, see the instruction manual supplied with the video game software.	—	–
TV cabinet creaks.	• Changes in room temperature sometimes make the TV cabinet expand or contract, causing a noise. This does not indicate a malfunction.	—	–
A small "boom" sound is heard when the TV is turned on.	• The TV's demagnetizing function is working. This does not indicate a malfunction.	—	–

■ Specifications

	KV-AR29M90	Note
Power requirements	220-240 V AC, 50/60 Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	B/G, I, D/K, M	
Color system	PAL, PAL 60, SECAM, NTSC3.58, NTSC4.43	
Stereo/Bilingual system	NICAM Stereo/Bilingual B/G, I; A2 Stereo/Bilingual B/G	
Channel coverage		
B/G	VHF : E2 to E12 UHF : E21 to E69 CATV: S01 to S03, S1 to S41	
I	UHF : B21 to B68 CATV: S01 to S03, S1 to S41	
D/K	VHF : C1 to C12, R1 to R12 UHF : C13 to C57, R21 to R60 CATV: S01 to S03, S1 to S41, Z1 to Z39	
M	VHF : A2 to A13 UHF : A14 to A79 CATV: A-8 to A-2, A to W+4, W+6 to W+84	
⅂ (Antenna)	75-ohm external terminal	
Audio output (Speaker)	8W + 8W	
Number of terminal		
(Video)	Input: 4* Output: 1 Phono jacks; 1 Vp-p, 75 ohms	* Three input lines available
♪ (Audio)	Input: 4* Output: 1 Phono jacks; 500 mVrms	* Three input lines available
(S Video)	Input: 2 Y: 1 Vp-p, 75 ohms, unbalanced, sync negative C: 0.286 Vp-p, 75 ohms	
(Component Video)	Input: 1 Phono jacks; Y: 1 Vp-p, 75 ohms, sync negative C_B: 0.7 Vp-p, 75 ohms C_R: 0.7 Vp-p, 75 ohms Audio: 500 mVrms	
(Headphone)	Output: 1 Stereo minijack	
Picture tube	29 in.	
Tube size (cm)	72	Measured diagonally
Screen size (cm)	68	Measured diagonally
Dimensions (w/h/d, mm)	765 × 578 × 502	
Mass (kg)	49	

Design and specifications are subject to change without notice.

http://www.sony.net/
Sony Corporation